



KEY NO.	DESCRIPTION	PART NO.		KEY NO.	DESCRIPTION	PART NO.	
		S20	S30			S20	S30
1	SPACE WASHER	1195751	1195751	41	PINION	1195566	1195567
2	O-RING	1195755	1195755	42	HANDLE SCREW COVER	1279193	1279193
3	BEARING SLEEVE	1195758	1195758	43	SCREW (6 REQ)	1279198	1279198
4	BUSHING	1279159	1279159	44	BEARING RETAINER(2 REQ)	1279287	1279287
5	SEAL	1195761	1195761	45	SCREW	1195720	1195720
6	SPOOL SHAFT WASHER	1195763	1195763	46	OSCILLATION MOUNT	1279290	1279290
7	SPOOL SHAFT	1221451	1221451	47	IDLER GEAR	1195766	1195767
8	SCREW	1195642	1195642	48	SCREW	1221496	1221496
9	SCREW (2 REQ)	1221453	1221453	49	GEAR BOX	1279293	1279293
10	WASHER(2 REQ)	1252583	1252583	50	SCREW (2 REQ)	1279218	1279218
11	BAIL ARM	1279321	1279321	51	SWITCH SPRING	1221500	1221500
12	BALL BEARING	1195641	1195641	52	SWITCH LEVER	1221501	1221501
13	LINE ROLLER	1279323	1279323	53	IAR SWITCH	1279223	1279223
14	POM BUSHING	1279234	1279234	54	CLIP	1221504	1221504
15	BRASS BUSHING	1279238	1279238	55	STEM	1279296	1279298
16	O-RING	1195591	1195591	56	GUIDE BAR	1221428	1221428
17	CLIP	1195592	1195592	57	MAIN GEAR	1221509	1221510
18	BAIL HOLDER	1279325	1279325	58	SHIM	1195560	1195560
19	BAIL WIRE	1279274	1279275	59	HANDLE ASSEMBLY	1279301	1279303
20	SCREW	1221460	1221460	60	SPACER	1195778	1195778
21	ROTOR LOCKING PLATE	1195770	1195770	61	OSCILLATION GEAR	1195801	1195801
22	ROTOR NUT	1195643	1195643	62	POM BUSHING (2 REQ)	1279234	1279234
23	SCREW (2 REQ)	1221462	1221462	63	BRASS BUSHING	1279239	1279239
24	BAIL ARM COVER	1279277	1279277	64	SCREW	1195659	1195659
25	PIVOT LEVER	1195617	1195617	65	SCREW	1195812	1195812
26	BAIL SPRING BUSHING	1195619	1195619	66	OSCILLATION SLIDER	1195651	1195651
27	BAIL SPRING	1195613	1195613	67	DRAG KNOB	1279354	1279354
28	BAIL TRIP BAR	1221465	1221466	68	SPOOL	1279306	1279308
29	BUSHING (2 REQ)	1221467	1221467	69	LINE CLIP SPRING	1195693	1195693
30	ROTOR	1279280	1279282	70	LINE CLIP	1279256	1279256
31	BAIL HOLDER COVER	1279285	1279285	71	KEYED WASHER (2 REQ)	1221544	1221545
32	ROTOR BRAKE LINKAGE	1221474	1221474	72	DRAG WASHER 1	1279258	1279360
33	ROTOR BRAKE SPRING	1221475	1221475	73	DRAG WASHER 2	1195729	1221548
34	ROTOR BRAKE PAD	1221476	1221476	74	SPOOL WASHER	1221549	1221550
35	SCREW (3 REQ)	1221477	1221477	75	O-RING	1195716	1221553
36	BEARING HOLDER COVER	1221478	1221479	76	SPOOL CLICK RETAINER	1221554	1221554
37	BALL BEARING (4 REQ)	1181780	1181780	77	SPOOL CLICK	1221555	1221555
38	BEARING HOLDER	1195573	1195573	78	SPOOL BOTTOM	1221556	1221557
39	CLUTCH SPRING	1221480	1221480	79	SPOOL ASSEMBLY	1279311	1279313
40	CLUTCH ASSEMBLY	1195773	1195773	80	SPARE SPOOL (If Provided)	1279316	1279318