

MODEL: ABU SP REV02 INS30

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1380223	41	RUBBER SLEEVE	1378853
2	SPOOL	1380244	42	ROTOR SCREW (3REQ)	1207341
2A	SPOOL ASSY	1380245	43	ROTOR	1380247
3	KEY WASHER (2REQ)	1378909	44	CARBON PLATE	1380248
4	DRAG WASHER (2REQ)	1206635	45	ROTOR SLEEVE	1380127
5	EARED WASHER	1378910	46	ROTOR NUT	1378801
6	SPOOL CLICK RETAINER	1378765	47	ROTOR NUT WASHER	1378802
7	SPOOL CLICK	1378766	48	SCREW	1378803
8	O-RING	1378767	49	PINION GEAR BUSHING	1378804
9	SPOOL BOTTOM	1378839	50	WASHER	1378805
10	CLIP	1378769	51	SCREW (3REQ)	1210692
11	LINE CLIP SHIM	1378770	52	BEARING COVER ASSY	1378902
12	LINE CLIP	1380226	53	BEARING	1380233
13	LINE CLIP SPRING	1216569	54	BEARING SLEEVE	1378808
14	SPACE WASHER	1378773	55	ONE WAY CLUTCH	1378809
15	O-RING	1378774	56	CLUTCH SPRING	1378810
16	BEARING SLEEVE	1378840	57	BEARING (3REQ)	1378807
17	BUSHING	1378927	58	PINION GEAR	1378858
18	SEAL	1378841	59	SCREW (2REQ)	1378884
19	SPOOL SHAFT WASHER	1378777	60	SCREW	1207636
20	MAIN SHAFT	1378942	61	IAR SWITCH COVER	1380236
21	SCREW (2REQ)	1378779	62	DUST CAP ASSY	1380237
22	BAIL HOLDER	1380246	63	SCREW (6REQ)	1378818
23	BUSHING (2REQ)	1378844	64	BEARING RETAINER (2REQ)	1380238
24	BAIL WIRE UNDERLAY	1378782	65	SIDE COVER	1380239
25	BAIL WIRE	1378845	66	SHIM	1378822
26	LOWER BUSHING	1380122	67	DRIVE GEAR	1378936
27	UPPER BUSHING	1380123	68	SHIM	1378824
28	LINE ROLLER	1378785	69	HANDLE ASSY	1380240
29	BEARING	1380228	70	O/S SLIDER	1378891
30	LINE ROLLER COLLAR	1378846	71	SCREW	1201875
31	BAIL ARM	1380229	72	O/S GEAR PIN	1378827
32	SCREW	1378789	73	O/S GEAR BUSHING	1380241
33	SCREW	1378790	74	O/S GEAR	1378903
34	BAIL ARM COVER	1380125	75	O/S GEAR BUSHING	1378829
35	BAIL ARM SPRING	1378849	76	SCREW	1378830
36	SPRING SEAT	1378793	77	UPPER O/S SLIDER GUIDE	1378892
37	PIVOT LEVER	1378794	78	LOWER O/S SLIDER GUIDE	1378893
38	TRIP PLUNGER	1378850	79	TRANSFER GEAR	1378833
39	ROTOR BRAKE	1378851	80	REAR COVER	1380249
40	ROTOR BRAKE SPRING	1378852	81	BODY ASSY	1380250

EXPLODED VIEW

