

MODEL: ABU SP REVO2 PRM20

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1380148	40	ROTOR BRAKE SPRING	1378797
2	SPOOL	1380149	41	ROTOR	1380154
2A	SPOOL ASSY	1380150	42	CARBON PLATE	1378799
3	KEY WASHER (2REQ)	1378909	43	ROTOR SLEEVE	1378800
4	DRAG WASHER (2REQ)	1206635	44	ROTOR SCREW (3REQ)	1207341
5	EARED WASHER	1378910	45	ROTOR NUT	1378801
6	SPOOL CLICK RETAINER	1378765	46	ROTOR NUT WASHER	1378802
7	SPOOL CLICK	1378766	47	SCREW	1378803
8	O-RING	1378767	48	PINION GEAR BUSHING	1378804
9	SPOOL BOTTOM	1378768	49	WASHER	1378805
10	CLIP	1378769	50	SCREW (3REQ)	1210692
11	LINE CLIP SHIM	1378770	51	BEARING COVER	1378806
12	LINE CLIP	1378771	52	BEARING (4REQ)	1378807
13	LINE CLIP SPRING	1378772	53	BEARING SLEEVE	1378808
14	SPACE WASHER	1378773	54	ONE WAY CLUTCH	1378809
15	O-RING	1378774	55	CLUTCH SPRING	1378810
16	BEARING SLEEVE	1378775	56	PINION GEAR	1378811
17	BEARING	1224308	57	SCREW (2REQ)	1380156
18	SEAL	1378776	58	SWITCH SPRING	1378885
19	SPOOL SHAFT WASHER	1378777	59	IAR SWITCH	1378816
20	MAIN SHAFT	1395733	60	DUST CAP ASSY	1378887
21	SCREW (2REQ)	1378779	61	SCREW (6REQ)	1378818
22	BAIL HOLDER	1380151	62	BEARING RETAINER (2REQ)	1380157
23	BUSHING (2REQ)	1378781	63	SIDE COVER	1380158
24	BAIL WIRE UNDERLAY	1378782	64	SHIM	1378822
25	BAIL WIRE	1378783	65	DRIVE GEAR	1378823
26	SHIM	1378784	66	SHIM	1378824
27	BEARING (2REQ)	1395730	67	HANDLE ASSY	1380159
28	LINE ROLLER	1378785	68	O/S SLIDER	1378826
29	LINE SLIDER WASHER	1378786	69	SCREW	1395731
30	LINE ROLLER COLLAR	1378787	70	O/S GEAR PIN	1378827
31	BAIL ARM	1380152	71	O/S GEAR BEARING	1393642
32	SCREW	1378789	72	O/S GEAR	1378828
33	SCREW	1378790	73	O/S GEAR BUSHING	1378829
34	BAIL ARM COVER	1378791	74	SCREW	1395732
35	BAIL ARM SPRING	1378792	75	UPPER O/S SLIDER GUIDE	1378831
36	SPRING SEAT	1378793	76	LOWER O/S SLIDER GUIDE	1380160
37	PIVOT LEVER	1378794	77	TRANSFER GEAR	1378833
38	TRIP PLUNGER	1378795	78	REAR COVER	1380161
39	ROTOR BRAKE	1378796	79	BODY ASSY	1380162

EXPLODED VIEW

