

MODEL: ABU SP REV02 PRM30

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAW KNOB ASSY	1378870	41	RUBBER SLEEVE	1378853
2	SPOOL	1378896	42	ROTOR SCREW (3REQ)	1207341
2A	SPOOL ASSY	1378897	43	ROTOR	1378900
3	KEY WASHER (2REQ)	1378909	44	CARBON PLATE	1378855
4	DRAW WASHER (2REQ)	1206635	45	ROTOR SLEEVE	1378856
5	EARED WASHER	1378910	46	ROTOR NUT	1378801
6	SPOOL CLICK RETAINER	1378765	47	ROTOR NUT WASHER	1378802
7	SPOOL CLICK	1378766	48	SCREW	1378803
8	O-RING	1378767	49	PINION GEAR BUSHING	1378804
9	SPOOL BOTTOM	1378839	50	WASHER	1378805
10	CLIP	1378769	51	SCREW (3REQ)	1210692
11	LINE CLIP SHIM	1378770	52	BEARING COVER ASSY	1378902
12	LINE CLIP	1378771	53	BEARING (4REQ)	1378807
13	LINE CLIP SPRING	1216569	54	BEARING SLEEVE	1378808
14	SPACE WASHER	1378773	55	ONE WAY CLUTCH	1378809
15	O-RING	1378774	56	CLUTCH SPRING	1378810
16	BEARING SLEEVE	1378840	57	PINION GEAR	1378858
17	BEARING	1224308	58	SCREW (2REQ)	1378884
18	SEAL	1378841	59	SWITCH SPRING	1378885
19	SPOOL SHAFT WASHER	1378777	60	IAR SWITCH	1378861
20	MAIN SHAFT	1395734	61	DUST CAP	1378887
21	SCREW (2REQ)	1378779	62	SCREW (6REQ)	1378818
22	BAIL HOLDER	1378898	63	BEARING RETAINER (2REQ)	1378888
23	BUSHING (2REQ)	1378781	64	SIDE COVER	1378889
24	BAIL WIRE UNDERLAY	1378782	65	SHIM	1378822
25	BAIL WIRE	1378845	66	DRIVE GEAR	1378823
26	SHIM	1378784	67	SHIM	1378824
27	BEARING (2REQ)	1395730	68	HANDLE ASSY	1378890
28	LINE ROLLER	1378785	69	O/S SLIDER	1403860
29	LINE SLIDER WASHER	1378786	70	SCREW	1395731
30	LINE ROLLER COLLAR	1378846	71	O/S GEAR PIN	1378827
31	BAIL ARM	1378877	72	O/S GEAR BEARING	1393642
32	SCREW	1378789	73	O/S GEAR	1403861
33	SCREW	1378790	74	O/S GEAR BUSHING	1378829
34	BAIL ARM COVER	1378848	75	SCREW	1395732
35	BAIL ARM SPRING	1378849	76	UPPER O/S SLIDER GUIDE	1378892
36	SPRING SEAT	1378793	77	LOWER O/S SLIDER GUIDE	1378893
37	PIVOT LEVER	1378794	78	TRANSFER GEAR	1403857
38	TRIP PLUNGER	1378850	79	REAR COVER	1378904
39	ROTOR BRAKE	1378851	80	BODY ASSY	1378905
40	ROTOR BRAKE SPRING	1378852			

EXPLODED VIEW

