

MODEL: ABU SP REV02 PRM40

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1378870	42	RUBBER SLEEVE	1378853
2	SPOOL	1378871	43	ROTOR SCREW (3REQ)	1207341
2A	SPOOL ASSY	1378872	44	ROTOR	1378880
3	KEY WASHER (3REQ)	1378909	45	CARBON PLATE	1378881
4	DRAG WASHER (4REQ)	1409747	46	ROTOR SLEEVE	1378882
5	EARED WASHER	1378911	47	ROTOR NUT	1378801
6	EARED WASHER	1378910	48	ROTOR NUT WASHER	1378802
7	SPOOL CLICK RETAINER	1378765	49	SCREW	1378803
8	SPOOL CLICK	1378766	50	PINION GEAR BUSHING	1404814
9	O-RING	1216516	51	WASHER	1378805
10	SPOOL BOTTOM	1378839	52	SCREW (3REQ)	1210692
11	CLIP	1378769	53	BEARING COVER ASSY	1378883
13	LINE CLIP	1378771	54	BEARING (4REQ)	1378807
14	LINE CLIP SPRING	1216569	55	BEARING SLEEVE	1378808
15	SPACE WASHER	1378773	56	ONE WAY CLUTCH	1380128
16	O-RING	1378774	57	CLUTCH SPRING	1378810
17	BEARING SLEEVE	1378840	58	PINION GEAR	1432246
18	BEARING	1224308	59	SCREW (2REQ)	1378884
19	SEAL	1378841	60	SWITCH SPRING	1378885
20	SPOOL SHAFT WASHER	1378777	61	IAR SWITCH	1378861
21	MAIN SHAFT	1378874	62	DUST CAP	1378887
22	SCREW (2REQ)	1378779	63	SCREW (6REQ)	1378818
23	BAIL HOLDER	1378875	64	BEARING RETAINER (2REQ)	1378888
24	BUSHING (2REQ)	1378781	65	SIDE COVER	1378889
25	BAIL WIRE UNDERLAY	1378782	66	SHIM	1378822
26	BAIL WIRE	1378876	67	DRIVE GEAR	1378823
27	SHIM	1378784	68	SHIM	1378824
28	BEARING (2REQ)	1395730	69	HANDLE ASSY	1378890
29	LINE ROLLER	1378785	70	O/S SLIDER	1409802
30	LINE SLIDER WASHER	1378786	71	SCREW	1395731
31	LINE ROLLER COLLAR	1378846	72	O/S GEAR PIN	1378827
32	BAIL ARM	1378877	73	O/S GEAR BEARING	1393642
33	SCREW	1378789	74	O/S GEAR	1403859
34	SCREW	1378790	75	O/S GEAR BUSHING	1378829
35	BAIL ARM COVER	1378878	76	SCREW	1395732
36	BAIL ARM SPRING	1378849	77	UPPER O/S SLIDER GUIDE	1378892
37	SPRING SEAT	1378793	78	LOWER O/S SLIDER GUIDE	1378893
38	PIVOT LEVER	1378794	79	TRANSFER GEAR	1403857
39	TRIP PLUNGER	1378879	80	REAR COVER	1378894
40	ROTOR BRAKE	1378851	81	BODY ASSY	1378895
41	ROTOR BRAKE SPRING	1378852			

EXPLODED VIEW

