

MODEL: ABU SP REV02X20

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1446955	38	ROTOR NUT	1378801
2	STOP RING	1262749	39	ROTOR NUT WASHER	1378802
3	KEY WASHER (2REQ)	1446956	40	SCREW	1378803
4	EARED WASHER	1446957	41	WASHER	1378805
5	DRAG WASHER	1225637	42	SCREW (3REQ)	1210692
6	SPOOL	1446972	43	BEARING COVER	1378806
6A	SPOOL ASSY	1446973	44	BEARING (4REQ)	1378807
7	LINE CLIP SPRING	1378772	45	BEARING SLEEVE	1378808
8	LINE CLIP	1378771	46	ONE WAY CLUTCH	1380128
9	SPOOL CLICK	1446960	47	CLUTCH SPRING	1378810
10	SPOOL SPRING	1214415	48	PINION GEAR ASSY	1446964
11	SCREW	1216396	49	SCREW (2REQ)	1380156
12	SHEET WASHER	1201745	50	SWITCH SPRING	1378885
13	CLICK GEAR	1446961	51	IAR SWITCH	1446965
14	SPOOL SHAFT WASHER	1378777	52	DUST CAP	1380131
15	MAIN SHAFT	1380185	53	SCREW (6REQ)	1378818
16	SCREW (2REQ)	1378779	54	BEARING RETAINER (2REQ)	1380191
17	BAIL HOLDER	1380186	55	SIDE COVER	1378820
18	BUSHING (2REQ)	1378781	56	DRIVE GEAR	1380133
19	BAIL WIRE ASSY	1380197	57	SHIM	1378822
20	LOWER BUSHING	1380122	58	HANDLE ASSY	1446966
21	UPPER BUSHING	1380123	59	O/S SLIDER	1409748
22	LINE ROLLER	1378785	60	SCREW	1395731
23	BEARING	1395730	61	O/S GEAR PIN	1378827
24	LINE ROLLER COLLAR	1378846	62	O/S GEAR BEARING	1393642
25	BAIL ARM	1378788	63	O/S GEAR	1403867
26	SCREW	1378789	64	O/S GEAR BUSHING	1378829
27	SCREW	1378790	65	SCREW	1395732
28	BAIL ARM COVER	1446962	66	UPPER O/S SLIDER GUIDE	1378831
29	BAIL ARM SPRING	1378792	67	LOWER O/S SLIDER GUIDE	1380160
30	SPRING SEAT	1378793	68	TRANSFER GEAR	1403857
31	PIVOT LEVER	1378794	69	REAR COVER	1446975
32	TRIP PLUNGER	1378795	70	BODY ASSY	1446968
33	ROTOR BRAKE	1378796	71	HANDLE SUB-ASSY	1446969
34	ROTOR BRAKE SPRING	1378797	72	BUSHING (2REQ)	1438531
35	ROTOR	1446974	73	T KNOB	1446970
36	ROTOR SLEEVE	1380200	74	SCREW	1241728
37	ROTOR SCREW (3REQ)	1207341	75	HANDLE KNOB COVER	1446971

EXPLODED VIEW

