




Please specify reel model number and number in reelfoot when ordering parts.

Vid beställning av reservdelar bör alltid rulltyp och nummer beteckning under rullfoten anges.

Ambassadeur
1292730

SX6600 23 00
34-12984-0

ITEM#	PART#	DESCRIPTION
1	1307908	FRAME COMPLETE
2	1307916	THUMB REST
3	1160960	LEFT INNER SIDE PLATE
4	1121550	MIDDLE GEAR
5	1133385	E RING
6	1307920	LEFT SIDE COVER SUB ASSEMBLY
7	1116093	PLASTIC WASHER
8	1122204	SCREW
9	1121606	WORM SHAFT
10	1307926	LINE GUIDE
11	1121607	LINE GUIDE SHAFT
12	1122207	LEVEL WIND GUARD
13	1206527	PAWL
14	1307928	PAWL SUPPORT
15	1121556	BEARING OF WORM SHAFT
16	1124736	COG GEAR
17	1124735	BALL BEARING
18	1121968	BRAKE WEIGHT (6X)
19	1124734	BRAKE WEIGHT HOLDER
20	1307930	SPOOL
21	1307933	SPOOL PIN
22	1307935	SPOOL COMPLETE
23	1121599	C RING
24	1122206	BALL BEARING
25	1133388	SCREW
26	1307938	MAIN GEAR SHAFT
27	1121597	RATCHET WHEEL
28	1121596	METAL WASHER
29	1126099	DRAG WASHER
30	1121593	MAIN GEAR
31	1121595	DRAG WASHER
32	1121592	METAL WASHER
33	1121591	EARED WASHER
34	1121590	METAL WASHER
35	1133389	IAR SLEEVE

ITEM#	PART#	DESCRIPTION
36	1160962	CLUTCH PLATE COMP.
37	1121563	PIN OF KICK LEVER
38	1121565	KICK LEVER
39	1121569	LIFT CURVE
40	1121566	SCREW
41	1121568	TWISTING SPRING
42	1121564	TWISTING SPRING
43	1121567	YOKE
44	1121571	YOKE SPRING
45	1121570	PINION
46	1307942	RIGHT SIDE COVER SUB ASSEMBLY
47	1122205	SCREW
48	1133387	O RING
49	1121573	BASE WASHER
50	1307948	MECHANICAL BRAKE KNOB
51	1121589	SPRING WASHER
52	1307949	STAR WHEEL COMPLETE
53	1121577	SPRING WASHER
54	1307953	HANDLE ARM COMPLETE
55	1307955	HANDLE ARM RIVETED
56	1307957	HANDLE KNOB
57	1307958	HANDLE BUSHING
58	1307959	HANDLE SCREW
59	1307960	HANDLE KNOB CAP
60	1133390	HANDLE NUT
61	1160954	NUT COVER
62	1133391	SCREW
63	1206553	WASHER
64	1121604	CLICKER COMPLETE
65	1124738	SLIDE BLOCK
66	1124740	CLICK GEAR
67	1124769	CLICK SPRING
68	1124770	ALARM BRACKET
69	1121602	TWISTING SPRING
70	1161136	LINE ALARM BUTTON