


# SPINNING REEL

## BLACK GOLD BG-13



| Key No. | Parts No.  | Parts Name                  | Key No. | Parts No.  | Parts Name                     |
|---------|------------|-----------------------------|---------|------------|--------------------------------|
| 1       | 6-740-3311 | Drag knob                   | 32      | 6-B32-0201 | Bail spring cover              |
| 2       | 6-170-4601 | Drag washer retainer        | 33      | 6-351-7701 | Bail spring cover screw        |
| 3       | 6-374-4802 | Drag D washer               | 34      | 6-501-9901 | Spring holder                  |
| 4       | 6-373-3701 | Disc washer                 | 35      | 6-145-0901 | Anti-reverse claw spring       |
| 5       | 6-373-3603 | Drag A washer               | 36      | 6-280-9001 | Ratchet                        |
| 6       | 6-373-3704 | Drag washer A               | 37      | 6-501-9801 | Spacer                         |
| 7       | 6-733-5005 | Spool                       | 38      | 6-321-0901 | Ball bearing ret. washer       |
| 8       | 6-B07-5302 | Spool click claw            | 39      | 6-351-0901 | Ball bearing ret. washer screw |
| 9       | 6-320-5901 | Spool click claw retainer   | 40      | 6-635-4801 | Ball bearing                   |
| 10      | 6-144-1211 | Spool click claw spring     | 41      | 6-403-2201 | Pinion gear                    |
| 11      | 6-375-5701 | Spool washer                | 42      | 6-B31-8001 | Body                           |
| 12      | 6-720-1721 | Spool metal                 | 43      | 6-B32-1701 | Cam kick plate                 |
| 13      | 6-151-7211 | Spool metal leaf spring     | 44      | 6-363-2911 | Cam kick plate screw           |
| 14      | 6-B31-7601 | Main shaft                  | 45      | 6-111-8201 | Anti-reverse claw              |
| 15      | 6-637-0102 | Oscillating support         | 46      | 6-041-7101 | Anti-reverse claw plate        |
| 16      | 6-351-5311 | Oscillating slider screw    | 47      | 6-363-9301 | Anti-reverse claw screw        |
| 17      | 6-B10-5701 | Rotor nut                   | 48      | 6-461-7104 | Anti-reverse cam               |
| 18      | 6-B31-7901 | Rotor                       | 49      | 6-144-0321 | Anti-reverse cam spring        |
| 19      | 6-B18-4701 | Bail kick lever spring      | 50      | 6-371-6903 | Anti-reverse lever washer      |
| 20      | 6-B32-1801 | Bail kick lever             | 51      | 6-541-6801 | Anti-reverse lever             |
| 21      | 6-B32-7801 | Bail kick lever cover       | 52      | 6-353-4401 | Anti-reverse lever screw       |
| 22      | 6-351-7701 | Bail kick lever cover screw | 53      | 6-637-5701 | Ball bearing                   |
| 23      | 6-353-8201 | Bail holder screw           | 54      | 6-414-1312 | Drive gear                     |
| 24      | 6-B18-5003 | Bail                        | 55      | 6-481-2101 | Oscillating slider             |
| 25      | 6-250-4221 | Line roller                 | 56      | 6-375-8500 | Drive gear washer              |
| 26      | 6-501-1601 | Roller collar               | 57      | 6-637-5701 | Ball bearing                   |
| 27      | 6-353-8201 | Arm lever screw             | 58      | 6-B31-7501 | Body cover                     |
| 28      | 6-B18-4501 | Arm lever                   | 59      | 6-353-0001 | Body cover screw               |
| 29      | 6-375-1001 | Bail washer                 | 60      | 6-B03-4802 | Handle screw cap               |
| 30      | 6-353-8201 | Bail screw                  | 61      | 6-B36-8401 | Handle                         |
| 31      | 6-B18-4401 | Bail spring                 |         |            |                                |

Sold as one unit  
 Spool assembly  
 6-B06-0205