




Key No	Part No	Description
1	M08-4601	DRAG KNOB
2	J54-7101	DRAG RING
3	M03-7701	DRAG RATCHET
4	J54-7001	DRAG DISK WASHER
5	M20-6501	ATD DRAG WASHER ((25BGMQ-3)
6	J54-6902	DRAG LIP WASHER
7	J55-8101	LINE STOPPER PLATE
8	J55-8001	LINE STOPPER
9	J31-4801	LINE STOPPER SPRING
10	M11-1201	SPOOL ASSY
11	M03-7401	SPOOL WASHER(A)
12	G46-9005	SPOOL BALL BEARING
13	B41-1706	SPOOL WASHER(B)
14	E39-8003	SPOOL WASHER(C -03mm)
15	E46-7101	SPOOL WASHER(D)
16	M02-1401	CLICK HOLDER
17	H41-6101	CLICK LEAF SPRING
18	J70-3101	SPOOL WASHER(D)
19	H98-6901	ROTOR NUT PACKING
20	H96-1101	ROTOR NUT
21	J80-8500	ROTOR NUT COLLAR
22	H02-2701	ROTOR NUT SCREW
23	H96-0062	ROTOR
24	H41-3601	KICK LEVER SPRING
25	J03-8501	KICK LEVER ASSY
26	H41-7701	KICK LEVER SCREW
27	H41-4101	ARM LEVER SHAFT
28	H57-6101	ARM LEVER SPRING COLLAR
29	H54-5701	ARM LEVER SPRING
30	H41-4301	ARM LEVER SPRING HOLDER
31	H96-0201	ARM LEVER COVER
32	G27-0801	ARM LEVER COVER SCREW
33	H72-8927	ARM LEVER
34	H96-2401	ARM LEVER COLLAR
35	G20-5001	ARM LEVER SCREW
36	G19-5602	ROLLER SCREW
37	J56-6101	ROLLER COLLAR(A)
38	G22-0701	ROLLER COLLAR(B)
39	J08-9902	LINE ROLLER
40	G87-4201	ROLLER COLLAR(C)
41	J37-5101	BAIL ASSY
43	M03-7101	SEALED PACKING
44	M03-7001	SEALED PACKING COLLAR
45	M03-7301	SEALED CAP
46	M03-7201	SEALED CAP O RING
47	J63-9902	ONE WAY CLUTCH WASHER
48	J38-8402	ONE WAY CLUTCH
49	M03-6902	CLUTCH RING
50	J00-0901	BEARING PLATE SCREW
51	J77-8201	BEARING PLATE
52	G53-5104	PINION BALL BEARING (A)
53	375-8502	PINION BEARING (A) WASHER01mm

Key No	Part No	Description
54	Z02-5620	PINION + DRIVE GEAR UNIT
55	H81-4902	PINION SPRING WASHER
56	E09-6501	PINON BEARING (B) WASHER01MM
57	G53-8007	PINON BALL BEARING (B)
58	J55-2001	PINION BEARING (B) COLLAR
59	M11-4901	BODY ASSY
60	J00-1101	BAIL KICK COLLAR
61	G94-0408	BAIL KICK COLLAR SCREW(A)
62	H53-1510	BAIL KICK COLLAR SCREW(B)
63	M03-6202	MAIN SHAFT ASSY
64	H61-4301	OSHRATING POST
65	M03-9401	OSHRATING POST COLLAR
66	M03-9501	REAR CAP PACKING
67	M03-9601	REAR CAP
68	M03-6601	REAR CAP SCREW
69	H59-5701	OSCILATE GEAR WASHER
70	J13-6101	OSCILATE GEAR
71	G46-6001	OSCILATE GEAR O RING
72	H12-9201	OSCILATE BEARING WASHER01mm
74	G94-0402	OSCILATE SCREW
75	G67-0501	DRIVE O RING
77	G46-7302	DRIVE BALL BEARING (A)
78	J55-3001	BODY COVER PACKING
79	M03-9301	BODY COVER
80	J13-0201	HANDLE PACKING
81	M08-4801	HANDLE ASSY
82	G52-2706	DRIVE BALL BEARING (B)
83	G47-2401	DRIVE BEARING RING
84	G16-2401	HANDLE CAP O-RING
85	J41-8102	HANDLE CAP

BGMQ4000D-XH Special Parts

Key No	Part No	Description
1	M03-7801	DRAG KNOB
7	J56-8601	LINE STOPPER PLATE
10	M03-7501	SPOOL ASSY
20	M18-1301	ROTOR NUT
23	J56-7516	ROTOR
25	J56-7601	KICK LEVER ASSY
27	H57-2001	ARM LEVER SHAFT
29	H41-4201	ARM LEVER SPRING
30	J08-9401	ARM LEVER SPRING HOLDER
31	J56-7801	ARM LEVER COVER
38	M17-8101	ROLLER COLLAR(B)
40	M17-8001	ROLLER COLLAR(C)
41	M05-3501	BAIL ASSY
53	375-8500	PINION BEARING (A) WASHER01mm
59	M03-5901	BODY ASSY
63	M03-6201	MAIN SHAFT ASSY
70	M03-6701	OSCILATE GEAR
81	M03-7901	HANDLE ASSY