




Please quote by part number, not key number when ordering
spares@daiwaaustralia.com.au PH: 02 8644 8644

2019 CERTATE LT 2500-XH





Please quote by part number, not key number when ordering
spares@daivawaustralia.com.au PH: 02 8644 8644

2019 CERTATE LT 2500-XH

Key No.	Part Number	Description	Key No.	Part Number	Description	Key No.	Part Number	Description
1	61775201	DRAW KNOB ASSY	36	61254601	ARM LEVER SHAFT	72	6G279602	PINION BALL BEARING(A)
2	61556701	DRAW RING	37	61254701	ARM LEVER SHAFT COLLAR	73	63758500	PINION BEARING(A) WASHER
3	61556601	DRAW RATCHET	38	61537101	ARM LEVER HOLDER COVER	74	62024670	PINION+DRIVE GEAR SET
4	61679101	ATD DRAW WASHER(LT3-3pcs)	39	61255201	ARM LEVER HOLDER COVER SCREW	75	6H814900	PINION BEARING(B) SPRING WASHER
5	61561201	DRAW DISC WASHER	40	61254801	ARM LEVER	76	6E096500	PINION BEARING(B) WASHER
6	61556501	DRAW RIP WASHER	41	61254901	ARM LEVER SCREW COLLAR	77	6G538007	PINION BALL BEARING(B)
7	6B358702	SPOOL COLLAR RING	42	61255001	ARM LEVER SCREW	78	61552001	PINION BEARING(B) COLLAR
8	61546701	SPOOL COLLAR	43	61257001	ROLLER CREW	79	61773302	BODY ASSY
9	61879401	SPOOL ASSY (ATD)	44	61538001	ROLLER MAG COLLAR (B)	80	61832701	MAIN SHAFT
10	61558001	LINE STOPPER	45	61538401	ROLLER MAGNET ASSEMBLY(A)	81	61774301	OSCILLATING POST
11	61558101	LINE STOPPER PLATE	46	61256702	ROLLER BALL BEARING (B)	82	61774401	REAR CAP PACKING
12	61314801	LINE STOPPER SPRING	47	61256601	ROLLER COLLAR(A)	83	61774501	REAR CAP
13	61546300	SPOOL WASHER (A)	48	61256301	ROLLER COLLAR(B)	84	61774601	REAR CAP SCREW (B)
14	61549501	SPOOL METAL	49	61256501	LINE ROLLER	85	6H158201	BAIL KICK COLLAR SCREW
15	61558201	SPOOL METAL SCREW	50	61256401	ROLLER COLLAR(A)	86	61553501	BAIL KICK COLLAR
16	6H624801	SPOOL METAL COLLAR	51	61537801	ROLLER MAGNET ASSEMBLY(B)	87	61553603	REAR CAP SCREW (A)
17	61602201	SPOOL WASHER (B)	52	61890701	BAIL ASSY	88	6G818902	DRIVE BALL BEARING (A)
18	61546201	CLICK HOLDER	53	61254901	BAIL HOLDER SCREW COLLAR	89	61555501	DRIVE BEARING (A) WASHER
19	61525101	CLICK REEF SPRING	54	61255001	BAIL HOLDER SCREW	90	61774102	ENGINE PLATE(R)
20	6G471501	ROTOR NUT PLATE	55	6G471803	BAIL SHAFT	91	6G399702	HANDLE CAP O-RING
21	61729101	ROTOR NUT PACKING	56	6G685401	BAIL SHAFT WASHER	92	61555901	HANDLE CAP
22	63755202	ROTOR NUT WASHER	57	6G685301	BAIL SHAFT SPRING	93	6G610104	OSCILLATING GEAR WASHER
23	6H959602	ROTOR NUT BALL BEARING	58	6G471601	BAIL SHAFT SPRING COLLAR	94	61551501	OSCILLATING GEAR
24	61690201	ROTOR NUT BEARING COLLAR	59	61537701	BAIL HOLDER COVER	95	6G683301	OSCILLATING GEAR O-RING
25	61253001	ROTOR NUT	60	61255201	BAIL HOLDER COVER SCREW	96	6H129200	OSCILLATING GEAR WASHER
26	61808500	ROTOR NUT COLLAR	61	61554901	STOPPER LEVER PACKING(A)	97	6G686904	OSCILLATING GEAR BALL BEARING
27	63712836	ROTOR NUT WASHER	62	61774701	STOPPER LEVER	98	6G940403	OSCILLATING GEAR SCREW
28	6H022701	ROTOR NUT SCREW	63	61782101	STOPPER LEVER SCREW	99	61552701	DRIVE GEAR RING
29	61538101	ROTOR COVER	64	61553802	MAGSEALED PLATE	100	6H739701	DRIVE BALL BEARING (B)
30	6H022701	ROTOR COVER SCREW	65	6H842807	MAGSEALED PLATE SCREW	101	6G613400	DRIVE BEARING (B) WASHER
31	61536801	ROTOR	66	6H502200	ONEWAY CLUCH WASHER	102	61553001	ENGINE PLATE PACKING)
32	61435201	KICK LEVER SPRING	67	6H412602	ONEWAY CLUCH	103	61774205	ENGINE PLATE(L)
33	61339500	KICK LEVER WASHER	68	61553701	STOPPER LEVER PACKING(B)	104	6H866201	HANDLE PACKING
34	61536901	KICK LEVER ASSY	69	61774801	CLUCH RING	105	61775301	HANDLE ASSY
35	6H417701	KICK LEVER SCREW	70	61552102	PINION BEARING PLATE	106	6G315302	REAR CAP SCREW WASHER(A)
			71	61552202	PINION BEARING PLATE SCREW	107	6G315301	REAR CAP SCREW WASHER(B)