




Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	J35-3601	DRAG KNOB	53	G47-1601	BAIL SPRING HOLDER
2	F74-2501	DRAG WASHER RET	54	J28-7301	BAIL SPRING COVER
3	F90-8701	DRAG KNOB CLICK PLT	55	J25-5201	SCREW
4	J39-8201	ATD-DRAG WASHER KIT	56	H41-3201	SCREW
7	H41-6301	DRAG COLLAR	57	H53-2602	MAGNET HOLDER
8	J31-8201	SPOOL ASSEMBLY	58	H41-3001	O RING
9	G47-2401	BEARING RET	59	H51-9309	COVER
10	H41-6301	DRAG COLLAR	60	H41-2601	ROLLER CLUTCH
11	H80-6300	WASHER	61	H41-2501	SPACING SLEEVE
12	H41-6001	CLICK HOLDER	62	H44-2201	BEARING RET
13	H41-6101	CLICK LEAF SPRING	63	E13-4509	SCREW
14	J18-0801	SPOOL METAL NUT	64	G46-7305	BALL BEARING
15	G37-5001	PIN	65	H41-1401	WASHER
16	H41-5901	SPOOL METAL	66 + 90	Z02-2672	PINION + DIVE GEAR UNIT
17	G47-1501	BEARING RET	67	H41-1301	SPRING WASHER
18	H41-5701	ROTOR NUT PACKING	68	E09-6501	WASHER
19	375-5201	WASHER	69	G53-8007	BALL BEARING
20	J25-3201	BALL BEARING	70	H41-1201	COLLAR
21	J30-5301	COLLAR	71	J31-7401	MAIN SHAFT
22	J30-5201	NUT	72	J31-7301	BODY
23	372-7601	WASHER	73	H44-2101	BAIL TRIP PLT
24	H02-2701	SCREW	74	H45-5407	SCREW
25	J28-7401	COLLAR	75	H41-0002	A/R CAM
27	J28-6701	ROTOR	76	H41-0106	A/R LEVER
28	H44-3301	BAIL TRIP LEVER SPRING	78	H41-0201	A/R CAM SPRING
29	J30-4701	KICK LEVER	79	H44-3001	PACKING
30	H41-7701	SCREW	80	H44-3101	REAR COVER
31	J25-4601	SHAFT	81	H35-2801	WASHER
32	J25-4701	BAIL SPRING HOLDER	82	H51-2401	SCREW
33	J28-7001	BAIL SPRING COVER	83	H60-7901	WASHER
34	J25-5201	BAIL SPRING COVER SCREW	84	Z01-9605	OSC GEAR
35	J25-4801	BAIL ARM	85	G89-8301	O RING
36	J25-4901	COLLAR	86	H12-9201	WASHER
37	J25-5001	BAIL ARM SCREW	87	G46-9002	BALL BEARING
38	J25-7001	SCREW	88	G94-0402	SCREW
39	J25-6801	MAGNETIC WASHER	89	G73-6201	O RING
40	J25-6701	BALL BEARING	91	J03-0301	BALL BEARING
41	J25-6401	COLLAR	92	H44-2903	SIDE COVER
42	J25-6301	COLLAR	93	H43-1001	SCREW
43	J25-6501	LINE ROLLER	94	B27-0703	DRAG SCREW WASHER
44	J25-6201	COLLAR	95	J31-8002	BODY COVER
45	J25-6001	MAGNETIC WASHER	96	H74-0302	SCREW
47	J30-4901	BAIL ASSEMBLY	97	J31-8101	HANDLE ASSEMBLY
48	J25-4901	COLLAR	98	G39-9702	O RING
49	J25-5001	BAIL ARM SCREW	99	H41-7201	HANDLE SCREW CAP
50	G47-1803	BAIL SPRING SHAFT	100	J33-9500	WASHER
51	G68-5401	BAIL SPRING WASHER	100	J33-9501	WASHER (THICKNESS 0.05)
52	J30-4801	SPRING	100	J33-9502	WASHER (THICKNESS 0.1)