


JUPITER-X2500T



Key No.	Parts No.	Parts Name
2-9	F61-0701	SPOOL
1	F32-2106	DRAG KNOB
2	171-7701	DRAG WASHER RET
3	E46-7201	KEY WASHER
4	E13-6003	DRAG WASHER
5	373-3603	EARED WASHER
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	E46-7101	SPOOL WASHER
11	270-6501	CLICK GEAR
12	F61-9401	MAIN SHAFT
13	F39-5801	OSC SLIDER
14	351-0315	OSC SLIDER SCREW
15	341-9201	ROTOR NUT
16	F31-1404	ROTOR
17	B67-9305	LINE ROLLER SCREW
18	F61-9202	BAIL ARM
19	B84-2102	BAIL ARM SCREW
20	F44-6302	LINE ROLLER COLLAR
21	F44-6202	LINE ROLLER WASHER
22	F47-3401	LINE ROLLER BUSHING
23	F45-4901	LINE ROLLER
24	F61-9602	BAIL
25	E45-1601	BAIL TRIP LEVER

Key No.	Parts No.	Parts Name
26	F12-8901	BAIL SPRING
27	F31-0312	BAIL SPRING COVER
28	E36-4201	BAIL SPRING COVER SCREW
29	F31-0405	BAIL TRIP COVER
30	F31-1502	A/R RATCHET
31	E38-5501	SPRING HOLDER
32	L03-6601	BALL BEARING
33	L01-3902	PINION GEAR
34	F61-0501	BODY
35	L00-1801	A/R PAWL SCREW
36	L01-4401	A/R PAWL
37	L01-4302	A/R PAWL COLLAR
38	L00-1501	A/R PAWL SPRING
39	E03-7801	BEARING RET SCREW
40	F38-5901	A/R CAM SPRING
41	F08-5110	A/R LEVER
42	F60-6001	OSC GEAR
43	F08-4801	DRIVE GEAR
44	373-7802	DRIVE GEAR WASHER
45	F61-0601	SIDE COVER
46	B83-5001	SIDE COVER SCREW
47	B92-4902	HANDLE LOCK WASHER
48	B92-5004	HANDLE LOCK SCREW
49	E49-3801	HANDLE