




Key No.	Parts No.	Parts Name
2-9	F72-8001	SPOOL
1	F32-9501	DRAG KNOB
2	171-7701	DRAG WASHER RET
3	F09-4901	KEY WASHER
4	E13-6003	DRAG WASHER
5	373-3603	EARED WASHER
7	B07-5304	CLICK PAWL
8	E40-3101	CLICK SPRING
9	320-5901	CLICK RET
10	F09-4701	SPOOL WASHER
11	E46-2701	CLICK GEAR
12	F61-9501	MAIN SHAFT
13	F09-1301	OSC SLIDER
14	352-1502	OSC SLIDER SCREW
15	340-6602	ROTOR NUT
16	F62-0305	ROTOR
17	B67-9304	LINE ROLLER SCREW
18	F61-9301	BAIL ARM
19	E49-3501	BAIL ARM SCREW
20	320-5901	BAIL ARM SCREW RET
21	F44-6302	LINE ROLLER COLLAR
22	F44-6202	LINE ROLLER WASHER
23	F47-3401	LINE ROLLER BUSHING
24	F45-4901	LINE ROLLER
25	F61-9903	BAIL
26	B84-2102	BAIL ARM SCREW
27	E46-2101	BAIL TRIP LEVER
28	F18-0010	TRIGGER LEVER
29	E36-9901	TRIGGER SPRING

Key No.	Parts No.	Parts Name
30	E37-0003	TRIGGER SCREW
31	F12-8901	BAIL SPRING
32	F31-4509	BAIL SPRING COVER
33	E36-4202	BAIL SPRING COVER SCREW
34	F31-4609	BAIL TRIP COVER
35	E46-2001	SPRING HOLDER
36	F24-8901	A/R RATCHET
37	L03-6502	BALL BEARING A
38	E52-0101	PINION GEAR
39	F72-7702	BODY
40	E00-7101	A/R PAWL SCREW
41	E46-1302	A/R PAWL
42	E46-1201	A/R PAWL SPRING
43	E03-7801	BEARING RET SCREW
44	F38-5901	A/R CAM SPRING
45	F08-5125	A/R LEVER
46	F13-1601	OSC GEAR COLLAR
47	E46-1501	OSC GEAR
48	631-6901	BALL BEARING B
49	E52-0201	DRIVE GEAR
50	373-7808	DRIVE GEAR WASHER
51	631-6901	BALL BEARING C
52	F72-7802	SIDE COVER
53	B83-5002	SIDE COVER SCREW A
54	E15-8602	SIDE COVER SCREW B
55	F72-7901	HANDLE
56	B92-4902	HANDLE LOCK SCREW WASHER
57	F03-5605	HANDLE LOCK SCREW