


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



BAITCASTING REEL LEXA 300HL/300HSL/300HSL-P/300PWRL



KEY NO.	PART NO.	PART NAME	KEY NO.	PART NO.	PART NAME
1	460-5570	SET PLATE SCREW	58	540-7010	SPACER(F)
2	510-4450	SET PLATE SPRING	59	240-2550	ANTI-REVERSE RATCHET
3	550-1611	BRAKE ADJUST KNOB	60	530-0860	ANTI-REVERSE PAWL
4	510-6180	BRAKE CLICK SPRING	61	250-1360	DRIVE GEAR
5	200-0530	BRAKE DIAL RETAINER(A)	62	540-6890	DRAG WASHER
6	230-2370	LEFT SIDE PLATE	63	540-8010	KEY WASHER
7	410-1911	BRAKE DIAL RETAINER(B)	64	150-2200	GEAR SHAFT COLLAR
8	230-2390	SET PLATE	65	140-1370	ROLLER CLUTCH
9	460-3220	SCREW	66	140-0570	BALL BEARING
10	240-1952	MAGNET HOLDER	67	540-1570	SPACING WASHER
11	430-1070	MAGNET HOLDER RET. RING	68	410-2220	PLATE
12	540-5990	SPACER(A)	69	510-4760	LEAF SPRING(A)
13	140-1500	BALL BEARING(A)	70	540-6390	DRAG SPRING WASHER
14	430-1061	BEARING RETAINER	71	700-7180	STAR DRAG
15-17	700-9510	SPOOL ASSEMBLY	72	510-3260	LEAF SPRING(B)
18	410-1970	SPACER(B)	73	700-8440	HANDLE ASSEMBLY
19	090-0280	CLUTCH LEVER	74	380-0880	HANDLE NUT
20	410-1960	SPACER(C)	75	180-2471	HANDLE NUT PLATE
21	110-1040	FRAME ASSEMBLY	76	460-0440	SCREW
22	200-0530	WORM SHAFT RETAINER	77	430-1080	D-RING
23	400-2250	SPOOL PIN	78	540-9020	WASHER(D)
24	540-6060	WORM SHAFT WASHER	79	400-3310	KICK LEVWE PIN
25	170-1271	CLUTCH CAM	80	330-2850	KICK LEVER
26	410-2620	CLUTCH CAM PLT	81	510-5140	KICK LEVER SPRING
27	510-5170	SPRING	82	200-0570	DRIVE SHAFT WASHER A
28	460-1290	SCREW	83	400-2660	PILLAR
29	460-5370	SEREW	84	200-1160	DRIVE SHAFT WASHER B
30	410-1920	YOKE	85	400-2570	PIN
31	510-5190	YOKE SPRING	86	540-8030	WASHER
32	540-6020	WASHER	87	540-8020	TOP WASHER
33	260-1750	PINION GEAR	88	540-7030	WASHER
34	430-1061	BEARING RETAINER	89	540-8080	WASHER
35	150-2060	BUSH	90	540-5380	WASHER
36	230-2380	RIGHT SIDE PLATE	91	540-6600	WASHER
37	460-7010	SCREW			
38	460-5600	SCREW			
39	540-6850	SPACER(D)			
40	540-4340	SPACER(E)			
41	380-1661	CAST CONTROL CAP			
42	460-4980	LONG SCREW			
43	490-1080	LINE GUIDE			
44	400-2540	LINE GUIDE PAWL			
45	540-3980	WASHER(C)			
46	380-0780	LINE PAWL CAP			
47	270-0810	LEVEL WIND GUIDE			
48	470-1960	WORM SHAFT			
49	240-2210	WORM SHAFT GEAR			
50	200-0530	GEAR RETANER			
51	550-1640	FRAME PLATE			
52	140-1280	BALL BEARING			
53	200-0580	DRIVE GEAR SHAFT RETAINER(B)			
54	410-2550	PLATE			
55	460-5290	SCREW			
56	470-1970	DRIVE SHAFT			
57	240-2200	DRIVE SHAFT GEAR			

LEXA 300HSL SPECIAL PARTS		
KEY NO.	PART NO.	PART NAME
33	260-1760	PINION GEAR
36	230-2340	RIGHT SIDE PLATE
61	250-1370	DRIVE GEAR

LEXA 300HSL-P SPECIAL PARTS		
KEY NO.	PART NO.	PART NAME
33	260-1761	PINION GEAR
36	230-2341	RIGHT SIDE PLATE
61	250-1370	DRIVE GEAR
73	700-8450	HANDLE ASSEMBLY

LEXA 300PWRL SPECIAL PARTS		
KEY NO.	PART NO.	PART NAME
33	260-1950	PINION GEAR
36	230-2342	RIGHT SIDE PLATE
41	380-1780	CAST CONTROL CAP
61	250-1510	DRIVE GEAR