




BAITCASTING REEL

Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

LEXA 400HL/400HSL/400HSL-P



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	460-5620	SET PLATE SCREW	56	140-2030	BALL BEARING
2	510-4450	SET PLATE SPRING	57	200-0580	RET
3	550-1700	BRAKE ADJ KNOB	58	410-2740	DRIVE SHAFT PLATE
4	510-5340	BRAKE CLICK SPRING	59	460-5290	SCREW
5	200-0530	BRAKE DIAL RET	60	540-6600	WASHER
6	700-0930	LEFT SIDE PLATE	61	240-2260	OSC GEAR
7	410-2720	BRAKE DIAL RET B	62	470-2440	DRIVE SHAFT
8	230-2600	SET PLATE	63	460-5370	SCREW
9	460-3220	LEFT SET PLT SCREW	64	530-0860	A/R PAWL
10	240-2290	MAGNET HOLDER	65	240-3030	A/R RATCHET
11	430-1070	MAGNET HOLDER RET	66	540-6670	WASHER
12	540-8110	SPACER A	67	250-1560	DRIVE GEAR
13	140-1790	BALL BEARING	68	540-8090	DRAG WASHER
14	430-0440	BEARING RET	69	540-8060	KEY WASHER
15-18	700-9620	SPOOL	70	540-8100	KEY WASHER
19	410-2670	SPACER B	71	540-7100	WASHER
20	090-0290	CLUTCH LEVER	72	540-8070	KEY WASHER
21	410-2680	SPACER C	73	150-2270	GEAR SHAFT COLLAR
22	110-1180	FRAME	74	140-2000	ROLLER CLUTCH
23	400-2570	PIN	75	140-2040	BALL BEARING
24	200-0580	RET	76	540-6250	WASHER
25	150-2260	WORM SHAFT WASHER	77	410-2220	CLICK LEAF SPRING HOLDER
26	170-1380	CLUTCH CAM	78	510-4760	LEAF SPRING A
27	410-2730	CLUTCH CAM PLATE	79	540-6390	DRAG SPRING WASHER
28	510-5330	SPRING	80	540-9020	WASHER
29	460-1290	SCREW	81	700-7350	STAR DRAG
30	400-3310	KICK LEVER PIN	82	510-3260	LEAF SPRING A
31	330-2850	KICK LEVER	83	700-8520	HANDLE
32	510-5320	KICK LEVER SPRING	84	380-1930	HANDLE NUT
33	410-2750	YOKE	85	410-2500	HUNDLE NUT PLATE
34	510-6040	YOKE SPRING	86	460-7050	SCREW
35	200-0570	E-CLIP	87	400-3380	PILLAR
36	260-2010	PINION GEAR	88	200-1160	E-CLIP
37	430-1061	BEARING RET	89	150-1050	BUSHING
38	150-2060	BUSH	90	510-5310	SPRING
39	230-2590	RIGHT SIDE PLATE	91	400-2720	PIN
40	460-7040	SCREW	92	540-5380	WASHER
41	460-5630	SCREW	93	210-2410	KICK LEVER SPRING BUSHING
42	430-1000	O-RING	94	540-8120	SPACER
43	540-6460	WASHER			
44	540-5980	SPACER			
45	380-1770	CAST CONTROL CAP			
46	460-5320	LONG SCREW			
47	550-1720	FRONT PLATE			
48	490-1100	LINE GUIDE			
49	400-2540	LINE GUIDE NUT			
50	540-3980	OCS PAWL WASHER			
51	380-0780	LINE GUIDE NUT			
52	270-0870	LEVEL WIND GUARD			
53	470-2430	WORM SHAFT			
54	240-2300	WORM SHAFT GEAR			
55	200-0530	BRAKE DIAL RET			

LEXA 400HSL SPECIAL PARTS		
Key No.	Part No.	Part Name
36	260-2020	PINION GEAR
39	230-2581	LEFT SIDE PLATE
67	250-1570	DRIVE GEAR

LEXA 400HSL-P SPECIAL PARTS		
Key No.	Part No.	Part Name
36	260-2020	PINION GEAR
39	230-2582	RIGHT SIDE PLATE
67	250-1570	DRIVE GEAR
83	700-8540	HANDLE