


LEXA-CC400H/400PWR-P



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	460-7440	SET PLATE SCREW	58	540-5380	WASHER
2	510-4450	SET PLATE SPRING	59	510-6040	YOKE SPRING
3	230-2924	LEFT SIDE PLATE	60	260-2001	PINION GEAR
4	330-3050	CLICK BUTTON	61	540-7220	WASHER
5	190-1271	CLICK PAWL	62	140-2030	BALL BEARING
6	540-5990	SPACER A	63	470-2422	DRIVE SHAFT
7	410-3350	PLATE	64	540-6600	WASHER
8	460-2580	SCREW	65	410-2700	DRIVE SHAFT PLATE
9	510-6290	CLICK SPRING	66	460-5370	SCREW
10	460-7470	SET PLATE SCREW	67	240-3030	A/R RATCHET
11	240-2340	COG WHEEL	68	530-0860	A/R LEVER
12	540-9770	WASHER	69	540-6670	WASHER
13	210-2580	COLLAR	70	250-1550	DRIVE GEAR
14	460-4900	SCREW	71	540-7100	WASHER
15	220-3130	SET PLATE	72	540-8060	KEY WASHER
16	430-1131	RING HOLDER	73	540-9890	WASHER
17	240-3090	SPOOL GEAR	74	540-8100	KEY WASHER
18	140-1550	BALL BEARING	75	540-8090	DRAG WASHER
19	210-2670	BRAKE COLLAR	76	540-8070	KEY WASHER
20-25	701-2360	SPOOL ASSEMBLY	77	150-2270	GEAR SHAFT COLLAR
26	110-2024	FRAME	78	140-2000	ROLLER CLUTCH
27	490-1100	LINE GUIDE	79	701-2880	RIGHT SIDE PLATE
28	400-2540	LINE GUIDE PAWL	80	150-2060	BUSHING
29	540-3980	WASHER	81	430-1061	BEARING RETAINER
30	380-0780	LINE GUIDE NUT	82	430-1000	O'RING
31	270-0930	LEVEL WIND GUARD	83	540-6460	WASHER
32	470-4570	WORM SHAFT	84	540-5980	SPACER D
33	140-0970	BALL BEARING	85	380-3320	CAST CONTROL CAP
34	410-3370	PLATE	86	460-5790	SCREW
35	460-5290	SCREW	87	460-7430	SCREW
36	400-3380	PILLAR	88	460-4870	SCREW
37	200-1160	RETAINER	89	140-2040	BALL BEARING
38	540-9750	WASHER	90	540-6250	WASHER
39	240-3240	WORM SHAFT GEAR	91	510-5370	CLICK LEAF SPRING HOLDER
40	460-5320	LONG SCREW	92	540-6391	WASHER
41	550-1710	FRONT PLATE	93	540-9021	WASHER
42	410-2680	SPACER B	94	700-7340	STAR DRAG
43	410-2670	SPACER C	95	510-3260	LEAF SPRING
44	090-0290	CLUTCH LEVER	96	701-2300	HANDLE ASSEMBLY
45	400-2570	PIN	97	380-1441	HANDLE NUT
46	510-5310	SPRING	98	410-2500	HANDLE NUT PLATE
47	400-2720	PIN	99	460-4260	HANDLE LOCK SCREW
48	170-1370	CLUTCH CAM	100	200-0530	RETAINER
49	410-2690	CLUTCH CAM PLATE	101	200-0580	RETAINER
50	400-3310	KICK LEVER PIN			
51	330-2940	KICK LEVER			
52	210-2410	BUSHING			
53	200-0570	E-CLIP			
54	510-5290	KICK LEVER SPRING			
55	510-5300	SPRING			
56	460-1290	SCREW			
57	410-2711	YOKE			

SPECIAL PARTS LEXA-CC400PWR-P		
Key No.	Part No.	Part Name
102	260-2041	PINION GEAR
103	250-1860	DRIVE GEAR
104	701-2900	RIGHT SIDE PLATE
105	701-2280	HANDLE ASSEMBLY