


LEXA-LC400HL/400PWRL-P



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	330-3050	CLICK BUTTON	58	540-5380	WASHER
2	230-2894	RIGHT SIDE PLATE	59	510-6040	YOKE SPRING
3	190-1271	CLICK PAWL	60	260-2011	PINION GEAR
4	540-5990	SPACER	61	540-7220	WASHER
5	410-3350	PLATE	62	140-2030	BALL BEARING
6	260-2430	GEAR	63	470-2442	DRIVE SHAFT
7	460-2930	SCREW	64	540-6600	WASHER
8	240-2820	COUNTER GEAR	65	410-2740	DRIVE SHAFT PLATE
9	460-5660	COUNTER GEAR SCREW	66	460-5290	SCREW
10	550-6100	COUNTER ASSEMBLY	67	460-5370	SCREW
11	701-2200	COUNTER COVER	68	240-3030	A/R RATCHET
12	460-1980	SCREW	69	530-0860	A/R PAWL
13	460-6030	SCREW	70	540-6670	WASHER
14	510-6310	CLICK SPRING	71	250-1560	DRIVE GEAR
15	460-7470	SET PLATE SCREW	72	540-7100	WASHER
16	240-2340	COG WHEEL	73	540-8060	KEY WASHER
17	540-9770	WASHER	74	540-9890	WASHER
18	210-2580	COLLAR	75	540-8100	KEY WASHER
19	460-4900	SCREW	76	540-8090	DRAG WASHER
20	220-3140	SET PLATE	77	540-8070	KEY WASHER
21	240-3090	SPOOL GEAR	78	150-2270	GEAR SHAFT COLLAR
22	140-1550	BALL BEARING	79	140-2000	ROLLER CLUTCH
23-26	701-2270	SPOOL ASSEMBLY	80	701-2330	LEFT SIDE PLATE
27	110-1184	FRAME	81	150-2060	BUSHING
28	490-1100	LINE GUIDE	82	430-1061	BEARING RETAINER
29	400-2540	LINE GUIDE PAWL	83	430-1000	O'RING
30	540-3980	WASHER	84	540-6460	SPACER
31	380-0780	LINE GUIDE NUT	85	540-5980	SPACER
32	270-0870	LEVEL WIND GUARD	86	380-3320	CAST CONTROL CAP
33	470-4550	WORM SHAFT	87	460-5790	SCREW
34	150-1050	BUSHING	88	460-7420	LONG SCREW
35	150-2260	BUSHING	89	460-7430	SCREW
36	210-2610	COLLAR	90	460-4870	SCREW
37	240-3240	WORM SHAFT GEAR	91	140-2040	BALL BEARING
38	240-2950	WORM SHAFT GEAR	92	540-6250	WASHER
39	200-1440	RETAINER	93	510-5370	CLICK LEAF SPRING HOLDER
40	550-1910	FRONT PLATE	94	540-6391	WASHER
41	460-5320	LONG SCREW	95	540-9021	WASHER
42	410-2670	SPACER	96	700-7350	STAR DRAG
43	410-2680	SPACER	97	510-3260	LEAF SPRING
44	090-0290	CLUTCH LEVER	98	701-2300	HANDLE ASSEMBLY
45	400-2570	PIN	99	380-1930	HANDLE NUT
46	510-5310	SPRING	100	410-2500	HANDLE NUT PLATE
47	400-2720	PIN	101	460-4260	HANDLE LOCK SCREW
48	170-1380	CLUTCH CAM	102	200-0530	RETAINER
49	410-2730	CLUTCH CAM PLATE	103	200-0580	RETAINER
50	400-3310	KICK LEVER PIN			
51	330-2950	KICK LEVER			
52	200-0570	E-CLIP			
53	210-2410	COLLAR			
54	510-5320	KICK LEVER SPRING			
55	510-5330	SPRING			
56	460-1290	SCREW			
57	410-2751	YOKE			

LEXA-LC400PWRL-P SPECIAL PARTS		
Key No.	Part No.	Part Name
104	260-2420	PINION GEAR
105	250-1870	DRIVE GEAR
106	701-2310	LEFT SIDEPLATE
107	701-2280	HANDLE ASSEMBLY