


LEXA-LC400H/400PWR-P

Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	330-3050	CLICK BUTTON	59	470-2422	DRIVE SHAFT
2	230-2874	LEFT SIDE PLATE	60	540-6600	WASHER
3	190-1271	CLICK PAWL	61	410-2700	DRIVE SHAFT PLATE
4	540-5990	SPACER	62	460-5370	SCREW
5	410-3350	PLATE	63	460-5290	SCREW
6	460-2580	SCREW	64	240-3030	A/R RATCHET
7	510-6290	CLICK SPRING	65	530-0860	A/R PAWL
8	460-7470	SET PLATE SCREW	66	540-6670	WASHER
9	240-2340	COG WHEEL	67	250-1550	DRIVE GEAR
10	540-9770	WASHER	68	540-7100	WASHER
11	210-2580	COLLAR	69	540-8060	KEY WASHER
12	460-4900	SCREW	70	540-9890	WASHER
13	220-3130	SET PLATE	71	540-8100	KEY WASHER
14	240-3090	SPOOL GEAR	72	540-8090	DRAG WASHER
15	140-1550	BALL BEARING	73	540-8070	KEY WASHER
16-19	701-2270	SPOOL ASSEMBLY	74	150-2270	GEAR SHAFT COLLAR
20	110-2024	FRAME	75	140-2000	ROLLER CLUTCH
21	490-1100	LINE GUIDE	76	701-2290	RIGHT SIDE PLATE
22	400-2540	LINE GUIDE PAWL	77	150-2060	BUSHING
23	540-3980	WASHER	78	430-1061	BEARING RETAINER
24	380-0780	LINE GUIDE NUT	79	430-1000	O'RING
25	270-0870	LEVEL WIND GUARD	80	540-6460	SPACER
26	470-4540	WORM SHAFT	81	540-5980	SPACER
27	150-1050	BUSHING	82	380-3320	CAST CONTROL CAP
28	240-3210	WORM SHAFT GEAR (A)	83	550-6100	COUNTER ASSEMBLY
29	200-1440	RETAINER	84	701-2200	COUNTER COVER
30	150-2260	BUSHING	85	460-4870	SCREW
31	210-2610	COLLAR	86	460-1980	SCREW
32	540-3930	WASHER	87	460-6030	SCRW
33	240-3240	WORM SHAFT GEAR (B)	88	240-2820	COUNTER GEAR
34	550-1900	FRONT PLATE	89	460-5390	SCREW
35	460-5320	LONG SCREW	90	460-5790	SCREW
36	240-3220	WORM SHAFT GEAR ©	91	460-7430	SCREW
37	240-3230	SHAFT	92	460-4870	SCREW
38	410-2680	SPACER	93	460-7420	LONG SCREW
39	410-2670	SPACER	94	140-2040	BALL BEARING
40	090-0290	CLUTCH LEVER	95	540-6250	WASHER
41	400-2570	PIN	96	510-5370	CLICK LEAF SPRING HOLDER
42	510-5310	SPRING	97	540-6391	WASHER
43	400-2720	PIN	98	540-9021	WASHER
44	170-1370	CLUTCH CAM	99	700-7340	STAR DRAG
45	410-2690	CLUTCH CAM PLATE	100	510-3260	LEAF SPRING
46	400-3310	KICK LEVER PIN	101	701-2300	HANDLE ASSEMBLY
47	330-2940	KICK LEVER	102	380-1441	HANDLE NUT
48	200-0570	E-CLIP	103	410-2500	HANDLE NUT PLATE
49	210-2410	BUSHING	104	460-4260	HANDLE LOCK SCREW
50	510-5290	KICK LEVER SPRING	105	200-0530	E-CLIP
51	510-5300	SPRING	106	200-0580	E-CLIP
52	460-1290	SCREW			
53	410-2711	YOKE			
54	540-5380	WASHER			
55	510-6040	YOKE SPRING			
56	260-2001	PINION GEAR			
57	540-7220	SPACER			
58	140-2030	BALL BEARING			

LEXA-LC400PWR-P SPECIAL PARTS		
Key No.	Part No.	Part Name
107	260-2410	PINION GEAR
108	250-1860	DRIVE GEAR
109	701-2250	RIGHT SIDE PLATE
110	701-2280	HANDLE ASSEMBLY