




Please quote by part number, not key number when ordering
 spares@daiwaaustralia.com.au PH: 02 8644 8644

2015 LUVIAS 2500



50631BA

DAIWA FISHING.COM.AU



Please quote by part number, not key number when ordering
spares@daiwaaustralia.com.au PH: 02 8644 8644

2015 LUVIAS 2500

Key No.	Part Number	Description	Key No.	Part Number	Description
1	6J217801	Drag Knob	47	6G205001	Screw(F)
2	6F710001	Drag Washer Retainer	48	6H596502	Screw(G)
3	6F895307	Drag Knob Click Plate	49	6J354401	Magnet Assembly
4	6J398301	ATD DRAG WASHER	50	6J354801	"O" Ring (A)
5	6F635201	Eared Washer	51	6J431807	Cover(C)
6	6F635101	Key Washer	52	6H979201	Spring Washer(A)
7	6H416301	Collar (A)	53	6H412601	Roller Clutch
2~8	6J316101	Spool Assembly	54	6H879601	Spacing Sleeve
9	6G472401	Collar Retainer	55	6G997301	Screw(H)
10	6G818902	Ball Bearing(A)	56	6H739101	Bearing Retainer(B)
11	6H806300	Washer (A)	57	6G279602	Ball Bearing(D)
12	6H416001	Click Leaf spring Holder	58	63758500	Washer (D)
13	6H416101	Spool Click Leaf spring	59	6Z021282	Pinion Gear+Drive Gear
14	6J180801	Spool Metal Nut	60	6H814900	Spring Washer(B)
15	6H415901	Spool Metal	61	6E096500	Washer (E)
16	6G375001	Pin	62	6H738902	Ball Bearing(E)
17	6G471501	Bearing Retainer(A)	63	6H411201	Collar(H)
18	6H415701	Packing(A)	64	6J180201	Main Shaft
19	6G466103	Washer (B)	65	6H738701	Stabilizer Bar
20	6G466205	Ball Bearing(B)	66	6H738801	Collar(I)
21	6H805801	Rotor Nut	67	6J217201	Body
22	63712824	Washer (C)	68	6H737801	Bail Trip Plate
23	6H854801	Collar (B)	69	6H809201	Anti-Reverse Cam Spring
24	6H022701	Screw(A)	70	6H738201	Anti-Reverse Cam
25	6H960016	Rotor	71	6H410106	Anti-Reverse Lever
26	6H413601	Bail Trip Lever Spring	72	6H836702	Rear Cover
27	6J038501	Bail Trip Lever	73	6H836801	Screw (I)
28	6H417701	Screw(B)	74	6H607902	Washer (F)
29	6H414101	Bail Spring Shaft	75	6H738301	Oscillating Gear
30	6H576101	Bail Spring Plate	76	6G683301	"O" Ring (B)
31	6H545701	Bail Spring	77	6H129200	Washer (G)
32	6H414301	Bail Spring Holder	78	6G469005	Ball Bearing(F)
33	6H960201	Cover(A)	79	6G997001	Screw(J)
34	6G270801	Screw(C)	80	6H455601	Ring
35	6H960104	Bail Arm	81	6H739703	Ball Bearing(G)
36	6H962401	Collar (C)	82	6H740108	Side Cover
37	6G205001	Screw(D)	83	63511010	Screw(K)
38	6H697701	Screw(E)	84	6G997701	Screw (L)
39	6H961001	Collar (D)	85	6G468000	Washer (H)
40	6H038301	Packing(B)	86	6J216001	Bearing Retainer(C)
41	6G686903	Ball Bearing(C)	87	6H740301	Screw (M)
42	6H960901	Collar(E)	88	6H866201	Packing(C)
43	6G686703	Line Roller	89	6J316001	Handle Assembly
44	6H960801	Collar(F)	90	6H740001	Screw (N)
45	6H960701	Collar(G)	91	6G399702	"O" Ring (C)
46	6H960301	Bail Assembly	92	6H745101	Handle Screw Cap