




# 21LUVIAS AIRITY

Feel Alive.

Please quote by part number, not key number when ordering.  
spares@daiwaaustralia.com.au PH: (02) 8644 8644



|                             |         |
|-----------------------------|---------|
| 21LUVIAS AIRITY LT2500      | S36421J |
| 21LUVIAS AIRITY LT2500-XH   | S36422J |
| 21LUVIAS AIRITY LT3000S-C   | S36521J |
| 21LUVIAS AIRITY LT3000S-CXH | S36522J |
| 21LUVIAS AIRITY LT3000      | S36621J |
| 21LUVIAS AIRITY LT3000-XH   | S36622J |
| 21LUVIAS AIRITY LT4000-C    | S36721J |
| 21LUVIAS AIRITY LT4000-CXH  | S36722J |

| REEL NAME                   | MGFT CODE | KEY NO | PARTS CODE | DESCRIPTION              |
|-----------------------------|-----------|--------|------------|--------------------------|
| 21LUVIAS AIRITY LT3000S-CXH |           | 1      | 6M136401   | DRAW KNOB                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 2      | 6J556701   | DRAW RING                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 3      | 6J556601   | DRAW DISC WASHER(A)      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 4      | 6J561101   | DRAW WASHER              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 5      | 6J561201   | DRAW LIP WASHER          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 6      | 6J556501   | DRAW METAL               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 7      | 6B358702   | BEARING RETAINER         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 8      | 6G212503   | SPOOL BALL BEARING       |
| 21LUVIAS AIRITY LT3000S-CXH |           | 9      | 6M136901   | SPOOL ASSY               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 10     | 6J558001   | LINE STOPPER             |
| 21LUVIAS AIRITY LT3000S-CXH |           | 11     | 6J558101   | LINE STOPPER PLATE       |
| 21LUVIAS AIRITY LT3000S-CXH |           | 12     | 6J314801   | LINE STOPPER SPRING      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 13     | 6J546304   | SPOOL WASHER (A )        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 14     | 6J549501   | SPOOL METAL              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 15     | 6J558201   | SPOOL METAL SCREW        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 16     | 6H624801   | SPOOL METAL COLLAR       |
| 21LUVIAS AIRITY LT3000S-CXH |           | 17     | 6J602201   | SPOOL WASHER ( B )       |
| 21LUVIAS AIRITY LT3000S-CXH |           | 18     | 6M021401   | CLICK HOLDER             |
| 21LUVIAS AIRITY LT3000S-CXH |           | 19     | 6H416101   | CLICK LEAF SPRING        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 20     | 6G471501   | ROTOR NUT PLATE          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 21     | 6J729101   | ROTOR NUT PACKING        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 22     | 63755202   | ROTOR NUT BB WASHER      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 23     | 6H959602   | ROTOR NUT BALL BEARING   |
| 21LUVIAS AIRITY LT3000S-CXH |           | 24     | 6J690201   | ROTOR NUT BB COLLAR      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 25     | 6J253001   | ROTOR NUT                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 26     | 6J808501   | ROTOR NUT COLLAR         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 27     | 63712836   | ROTOR NUT WASHER         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 28     | 6H022701   | ROTOR NUT SCREW          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 29     | 6J257101   | ROTOR COVER              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 30     | 6H022701   | ROTOR COVER SCREW        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 31     | 6J254307   | ROTOR                    |
| 21LUVIAS AIRITY LT3000S-CXH |           | 32     | 6J435201   | KICK LEVER SPRING        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 33     | 6J339502   | KICK LEVER WASHER        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 34     | 6J254401   | KICK LEVER ASSY          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 35     | 6H417701   | KICK LEVER SCREW         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 36     | 6J254601   | ARM LEVER SHAFT          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 37     | 6J254701   | ARM LEVER SHAFT HOLDER   |
| 21LUVIAS AIRITY LT3000S-CXH |           | 38     | 6J255103   | ARM LEVER SPRING COVER   |
| 21LUVIAS AIRITY LT3000S-CXH |           | 39     | 6J255201   | COVER SCREW              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 40     | 6J254807   | ARM LEVER                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 41     | 6J254901   | ARM LEVER SCREW COLLAR   |
| 21LUVIAS AIRITY LT3000S-CXH |           | 42     | 6J255001   | ARM LEVER SCREW          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 43     | 6J257001   | ROLLER SCREW             |
| 21LUVIAS AIRITY LT3000S-CXH |           | 44     | 6J538001   | ROLLER COLLAR (A)        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 45     | 6J538401   | ROLLER MAGNET ASSY(A)    |
| 21LUVIAS AIRITY LT3000S-CXH |           | 46     | 6J256702   | ROLLER BALL BEARING      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 47     | 6J256601   | ROLLER COLLAR (B)        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 48     | 6J256301   | ROLLER COLLAR (C)        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 49     | 6J256501   | LINE ROLLER              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 50     | 6J256401   | ROLLER COLLAR (D)        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 51     | 6J256702   | ROLLER BALL BEARING      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 53     | 6J891101   | BAIL ASSY                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 54     | 6J254901   | BAIL HOLDRE SCREW COLLAR |
| 21LUVIAS AIRITY LT3000S-CXH |           | 55     | 6J255001   | BAIL HOLDRE SCREW        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 56     | 6G471803   | BAIL SPRING SHAFT        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 57     | 6G685401   | BAIL SPRING SHAFT WASHER |
| 21LUVIAS AIRITY LT3000S-CXH |           | 58     | 6J255301   | BAIL SPRING              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 59     | 6G471601   | BAIL SPRING SHAFT HOLDER |
| 21LUVIAS AIRITY LT3000S-CXH |           | 60     | 6J255903   | BAIL HOLDER COVER        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 61     | 6J255201   | BAIL HOLDER COVER SCREW  |

| REEL NAME                   | MGFT CODE | KEY NO | PARTS CODE | DESCRIPTION                     |
|-----------------------------|-----------|--------|------------|---------------------------------|
| 21LUVIAS AIRITY LT3000S-CXH |           | 62     | 6J554901   | MAGSEALED CAP PACKING(A)        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 63     | 6J774701   | MAGSEALED CAP                   |
| 21LUVIAS AIRITY LT3000S-CXH |           | 64     | 6J782101   | MAGSEALED CAP SCREW(A)          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 65     | 6J782101   | MAGSEALED CAP SCREW(B)          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 66     | 6H842808   | MAGSEALED PLATE SCREW           |
| 21LUVIAS AIRITY LT3000S-CXH |           | 67     | 6J553803   | MAGSEALED PLATE ASSY            |
| 21LUVIAS AIRITY LT3000S-CXH |           | 68     | 6H502203   | MAGSEALED PLATE WASHER          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 69     | 6H412602   | ONEWAY CLUTCH                   |
| 21LUVIAS AIRITY LT3000S-CXH |           | 70     | 6J553701   | MAGSEALED CAP PACKING(B)        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 71     | 6J554801   | CLUTCH RING                     |
| 21LUVIAS AIRITY LT3000S-CXH |           | 72     | 6J536202   | CLUTCH RING COLLAR              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 73     | 6J552203   | PINION BEARING PLATE SCREW      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 74     | 6J552101   | PINION BALLBEARING PLATE        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 75     | 6G279602   | PINION BALLBEARING (A)          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 76     | 63758502   | PINION BALLBEARING (A)WASHER    |
| 21LUVIAS AIRITY LT3000S-CXH |           | 77     | 6Z024670   | PINION DRIVE GEAR SET           |
| 21LUVIAS AIRITY LT3000S-CXH |           | 78     | 6H814902   | PINION BALLBEARING (B)SP WASHER |
| 21LUVIAS AIRITY LT3000S-CXH |           | 79     | 6E096500   | PINION BALLBEARING (B) WASHER   |
| 21LUVIAS AIRITY LT3000S-CXH |           | 80     | 6G538007   | PINION BALLBEARING (B)          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 81     | 6J552001   | PINION BALLBEARING COLLAR       |
| 21LUVIAS AIRITY LT3000S-CXH |           | 82     | 6M135701   | BODY                            |
| 21LUVIAS AIRITY LT3000S-CXH |           | 83     | 6J601901   | MAIN SHAFT                      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 84     | 6J553605   | REAR CAP SCREW                  |
| 21LUVIAS AIRITY LT3000S-CXH |           | 85     | 6G315301   | REAR CAP WASHER(A)              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 86     | 6G315302   | REAR CAP WASHER(B)0125          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 87     | 6G683301   | OSCILLATING POST O RING         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 88     | 6G712401   | OSCILLATING POST WASHER         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 89     | 6J553101   | OSCILLATING POST                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 90     | 6J553201   | REAR CAP PACKING                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 91     | 6J553301   | REAR CAP                        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 92     | 6J609106   | KICK COLLAR SCREW               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 93     | 6J718501   | KICK COLLAR WASHER              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 94     | 6J718601   | KICK COLLAR O RING              |
| 21LUVIAS AIRITY LT3000S-CXH |           | 95     | 6J571801   | KICK COLLAR                     |
| 21LUVIAS AIRITY LT3000S-CXH |           | 96     | 6G818902   | DRIVE BALL BEARING(A)           |
| 21LUVIAS AIRITY LT3000S-CXH |           | 97     | 6J551301   | SET PLATE O RING                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 98     | 6J551203   | SET PLATE                       |
| 21LUVIAS AIRITY LT3000S-CXH |           | 99     | 6J555501   | DRIVE BEARING WASHER(A)         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 100    | 6J552805   | DRIVE BEARING COVER (A) R       |
| 21LUVIAS AIRITY LT3000S-CXH |           | 101    | 6G399702   | HANDLE CAP O RING               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 102    | 6J555901   | HANDLE CAP                      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 103    | 6J551401   | OSCILLATING GEAR WASHER         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 104    | 6J601701   | OSCILLATING GEAR                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 105    | 6G869601   | OSCILLATING GEAR O-RING         |
| 21LUVIAS AIRITY LT3000S-CXH |           | 106    | 6H129201   | OSCILLATING BEARING WASHER      |
| 21LUVIAS AIRITY LT3000S-CXH |           | 107    | 6G686904   | OSCILLATING BALL BEARING        |
| 21LUVIAS AIRITY LT3000S-CXH |           | 108    | 6G940402   | OSCILLATING GEAR SCREW          |
| 21LUVIAS AIRITY LT3000S-CXH |           | 109    | -          | -                               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 110    | -          | -                               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 111    | 6J552701   | DRIVEGEAR RING                  |
| 21LUVIAS AIRITY LT3000S-CXH |           | 112    | 6H739702   | DRIVE BEARING (B)               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 113    | 6G613401   | DRIVE BEARING (B) WASHER002     |
| 21LUVIAS AIRITY LT3000S-CXH |           | 114    | 6J553001   | BODY COVER O RING               |
| 21LUVIAS AIRITY LT3000S-CXH |           | 115    | 6M135803   | BODY COVER (A) L                |
| 21LUVIAS AIRITY LT3000S-CXH |           | 116    | 6H866201   | HANDLE PACKING                  |
| 21LUVIAS AIRITY LT3000S-CXH |           | 117    | 6M137301   | HANDLE ASSY                     |
|                             |           |        |            |                                 |