


# DAWA SPINNING REEL

## LUVIAS 2510PE-H

Please order by parts number, not key number  
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



| Key No. | Part No. | Part Name              | Key No. | Part No. | Part Name                |
|---------|----------|------------------------|---------|----------|--------------------------|
| 1       | J21-7801 | DRAG KNOB              | 47      | H43-1201 | SCREW                    |
| 2       | F71-0001 | DRAG WASHER RETAINER   | 48      | H59-6502 | SCREW                    |
| 3       | F89-5307 | DRAG KNOB CLICK PLT    | 49      | H74-0901 | MAGNET                   |
| 4       | H80-6501 | DRAG WASHER            | 50      | H74-1401 | O RING                   |
| 5       | F63-5201 | EARED WASHER           | 51      | H74-0702 | COVER                    |
| 6       | F63-5101 | KEY WASHER             | 52      | H97-9201 | WASHER                   |
| 7       | H41-6301 | DRAG COLLAR            | 53      | H41-2601 | ROLLER CLUTCH            |
| 8       | J21-8801 | SPOOL ASSEMBLY         | 54      | H87-9601 | SPACING SLEEVE           |
| 9       | G47-2401 | BEARING RETAINER       | 55      | G99-7301 | SCREW                    |
| 10      | G81-8902 | BALL BEARING           | 56      | H73-9101 | BEARING RETAINER         |
| 11      | H80-6300 | WASHER                 | 57      | G27-9602 | BALL BEARING             |
| 12      | H41-6001 | CLICK HOLDER           | 58      | 375-8500 | WASHER                   |
| 13      | H41-6101 | CLICK LEAF SPRING      | 59      | Z02-1280 | PINION + DRIVE GEAR UNIT |
| 14      | J18-0801 | SPOOL METAL NUT        | 60      | H81-4900 | SPRING WASHER            |
| 15      | H41-5901 | SPOOL METAL            | 61      | H73-8902 | BALL BEARING             |
| 16      | G37-5001 | PIN                    | 62      | H41-1201 | COLLAR                   |
| 17      | G47-1501 | BEARING RETAINER       | 63      | J18-0201 | MAIN SHAFT               |
| 18      | H41-5701 | ROTOR NUT PACKING      | 64      | H73-8701 | STABILIZER BAR           |
| 19      | G46-6103 | WASHER                 | 65      | H73-8801 | COLLAR                   |
| 20      | G46-6201 | BALL BEARING           | 66      | J21-7201 | BODY                     |
| 21      | H80-5801 | ROTOR NUT              | 67      | H73-7801 | BAIL TRIP PLT            |
| 22      | 371-2824 | WASHER                 | 68      | H80-9201 | A/R CAM SPRING           |
| 23      | H85-4801 | COLLAR                 | 69      | H73-8201 | A/R CAM                  |
| 24      | H02-2701 | SCREW                  | 70      | H41-0106 | A/R LEVER                |
| 25      | H96-0016 | ROTOR                  | 71      | H83-6703 | REAR COVER               |
| 26      | H41-3601 | BAIL TRIP LEVER SPRING | 72      | H83-6801 | SCREW                    |
| 27      | J03-8501 | BAIL TRIP LEVER        | 73      | H60-7902 | WASHER                   |
| 28      | H41-7701 | SCREW                  | 74      | H73-8301 | OSC GEAR                 |
| 29      | H41-4101 | BAIL SPRING SHAFT      | 75      | G68-3301 | O RING                   |
| 30      | H57-6101 | BAIL SPRING PLT        | 76      | H12-9200 | WASHER                   |
| 31      | H54-5701 | BAIL SPRING            | 77      | G46-9005 | BALL BEARING             |
| 32      | H41-4301 | BAIL SPRING HOLDER     | 78      | G99-7001 | SCREW                    |
| 33      | H96-0201 | COVER (A)              | 79      | H45-5601 | O RING                   |
| 34      | H43-1301 | SCREW                  | 80      | H73-9703 | BALL BEARING             |
| 35      | H96-0104 | BAIL ARM               | 81      | H74-0108 | SIDE COVER               |
| 36      | H96-2401 | COLLAR                 | 82      | 351-1010 | SCREW                    |
| 37      | H43-1201 | SCREW                  | 83      | G99-7701 | SCREW                    |
| 38      | H69-7701 | SCREW                  | 84      | G46-8000 | WASHER                   |
| 39      | H96-1001 | COLLAR                 | 85      | J21-6001 | BODY COVER (A)           |
| 40      | H03-8301 | PACKING                | 86      | F62-3305 | SCREW                    |
| 41      | G68-6903 | BALL BEARING           | 87      | H86-6201 | PACKING                  |
| 42      | H96-0901 | COLLAR                 | 88      | J21-9201 | HANDLE ASSEMBLY          |
| 43      | G68-6703 | LINE ROLLER            | 89      | G99-7503 | SCREW                    |
| 44      | H96-0801 | COLLAR                 | 90      | G39-9702 | O RING                   |
| 45      | H96-0701 | COLLAR                 | 91      | H74-5101 | HANDLE SCREW CAP         |
| 46      | H96-0301 | BAIL ASSEMBLY          |         |          |                          |