


SEABORG 500FE



Key

No.	Parts No.	Parts Name
1	G58-7804	IC MODULE L/S PLT SET
2	E03-3201	BRAKE CLICK SPRING
4	F46-2002	BRAKE ADJ KNOB
5	B17-5503	MECHANICAL BRAKE WASHER A
6	375-7405	MECHANICAL BRAKE WASHER B
7	351-0901	SET PLT SCREW
8	F46-2201	SET PLT
9	F54-0701	IDLE GEAR A COLLAR
10	F46-2301	IDLE GEAR A
11	F11-3401	IDLE GEAR A SCREW
12	F46-2404	IDLE GEAR B
13	F46-2701	IDLE GEAR C COLLAR
14	F46-2802	IDLE GEAR C
15	B86-4101	IDLE GEAR C RET
16	G07-0101	SET PLT GEAR
17	G07-0301	BALL BEARING A
18	G07-0201	BEARING RET
19	353-8212	SET PLT GEAR SCREW
20	637-2102	BALL BEARING B
21	E28-0201	MOTOR GEAR B BUSHING
22	F46-3106	SPOOL
23	G57-9501	SPOOL SHAFT
24	G28-1602	BALL BEARING C
25	G53-6001	BALL BEARING D
26	G24-1101	SPOOL SHAFT GEAR
27	F55-0501	R/S PLT SCREW RET
28	G58-0601	SPOOL GEAR
29	G42-7201	BALL BEARING E
30	G57-9901	SPOOL PLT
31	B39-5503	BEARING RET SCREW
32	G53-6001	BALL BEARING E
33	G08-7501	SPOOL SHAFT GEAR
34	320-8702	SPOOL SHAFT GEAR RET
35	B41-1701	SPOOL SHAFT WASHER
36	E29-2702	BALL BEARING F
37	F65-7305	FRAME
38	G24-1801	MOTOR
39	G24-2101	MOTOR HOLDER
40	F46-6601	MOTOR CASE RING

Key

No.	Parts No.	Parts Name
41	G17-3401	CORD SHIELD
42	G07-3001	MOTOR WASHER A
43	351-1801	MOTOR HOLDER SCREW
44	B27-0708	MOTOR WASHER B
46	G07-5601	MOTOR GEAR A BUSHING
47	G24-2301	MOTOR GEAR A
48	F65-7801	MOTOR GEAR O RING
49	G24-2901	MOTOR CASE PLT
50	F27-4501	MOTOR CASE O RING
51	F46-6601	MOTOR CASE RING
52	G24-1601	BALL BEARING G
53	G24-2701	MOTOR GEAR B
54	320-8702	MOTOR GEAR B RET
55	G58-0701	LINE GUIDE
56	122-0602	LINE GUIDE PAWL
57	F95-0200	LINE GUIDE WASHER
58	E35-4101	PAWL CAP
59	G58-0801	WORM SHAFT
60	F65-8201	WORM SHAFT GEAR
61	320-5901	WORM SHAFT GEAR RET
62	F46-7201	WORM SHAFT BUSH
63	F46-7301	WORM SHIELD
64	F46-7201	WORM SHAFT BUSH
65	B41-1702	WORM SHAFT HOLDER WASHER
66	320-5901	WORM SHAFT RET
67	F46-7401	LEVEL WIND POST
68	B86-4101	LEVEL WIND POST RET
69	F71-6101	DRIVE SHAFT BUSH
70	F72-5501	DRIVE SHAFT
71	F48-1201	DRIVE SHAFT COLLAR
72	320-7601	DRIVE SHAFT RET
73	F54-1701	FRAME SCREW A
74	F46-7601	FRAME SCREW B
75	F46-7717	MOTOR COVER
77	F46-7801	YOKE PLT
78	E25-2102	YOKE
79	G58-1201	PINION GEAR
80	E03-7704	YOKE WASHER
81	F93-5201	YOKE SPRING

Key

No.	Parts No.	Parts Name
82	F67-3401	A/R PAWL SPRING
83	F46-8101	A/R PAWL
84	F65-8701	A/R PAWL SCREW
85	E29-0801	RATCHET
86	374-6604	DRIVE SHAFT WASHER
87	F65-7801	O RING A
88	G24-2801	DRIVE GEAR
89	F65-9305	DRAG WASHER
90	F65-9403	EARED WASHER
91	F65-9503	KEY WASHER
92	F65-7801	O RING B
93	F65-9601	DRAG COLLAR SHIELD
94	G13-9401	DRAG COLLAR A
95	F86-0901	DRAG COLLAR B
96	G58-1401	R/S PLT
97	F46-9011	CLUTCH LEVER
98	F46-9201	CLUTCH CAM
99	G34-1101	CLUTCH CAM SPRING
100	160-8001	LOCK WASHER
101	353-8212	CLUTCH CAM SCREW
102	E28-6001	LINE HOLDER
103	F46-9614	FINGER GUARD
104	F46-9701	R/S PLT SCREW
105	F28-5901	POWER LEVER WASHER
106	F30-3102	POWER LEVER NUT A
107	F42-9701	POWER LEVER
108	342-4004	POWER LEVER NUT B
109	F43-0002	POWER LEVER COVER
110	E25-3501	DRAG SPRING WASHER
111	F86-2901	DRAG HOLDER
112	B74-7702	DRAG HOLDER LEAF SPRING
114	F47-0211	STAR DRAG
115	F47-0303	HANDLE COLLAR
116	G58-1601	HANDLE
117	B86-2102	HANDLE NUT
118	F47-1207	HANDLE NUT PLT
119	F66-1001	CONNECTOR CAP
120	G86-8701	ELECTRIC POWER CORD
122	371-6904	WORM SHAFT WASHER