


Please order by parts number, not key number
Bitte, Best.-Nr. angeben (Nicht "Key"-Nr.)
Veuillez indiquer le numero de la pièce (Non "Key" No.)

PROCASTER TOURNAMENT100-4Bi



Key No.	Parts No.	Parts Name
1	6W0181010	Handle nut plate screw
2	6W0270010	Handle nut retainer
3	6W0184010	Handle nut
4	6W0271010	Handle assembly
5	6W0187010	Friction washer
6	6W0272010	Star drag
7	6W0190010	Spacing sleeve
8	6W0191010	Drag spring washer
9	6W0273010	Right side plate
10	6W0194010	Roller clutch
11	6W0195010	Gear shaft collar
12	6W0196010	Key washer
13	6W0197010	Drag washer
14	6W0198010	Drive gear (A)
15	6W0199010	Drive shaft washer
16	6W0200010	Anti-reverse ratchet
17	6W0201010	Drive gear (B)
18	6W0202010	Drive shaft
19	6W0203010	Drive shaft retainer (A)

20	6W0204010	Drive shaft retainer (B)
21	6W0205010	Bushing (A)
22	6W0206010	Screw (A)
23	6W0207010	Bearing retainer
24	6W0274010	Ball bearing (C)
25	6W0209010	Right side plate screw
26	6W0210010	"O"ring
27	6W0211010	Pinion shaft
28	6W0212010	Spacer (A)
29	6W0213010	Spacer (B)
30	6W0275010	Cast control cap
31	6W0216010	Clutch cam spring (A)
32	6W0217010	Screw (B)
33	6W0218010	Clutch cam washer
34	6W0219010	Clutch cam (A)
35	6W0220010	Clutch cam spring (B)
36	6W0221010	Pinion gear
37	6W0222010	Yoke spring
38	6W0223010	Yoke

39	6W0224010	Ball bearing (A)
40	6W0225010	Clutch cam (B)
41	6W0226010	Worm shaft gear retainer
42	6W0227010	Worm shaft gear
43	6W0228010	Worm shaft washer (A)
44	6W0229010	Level wind guard
45	6W0230010	Line guide
46	6W0231010	Line guide pawl
47	6W0232010	Line guide washer
48	6W0233010	Pawl cap
49	6W0234010	Worm shaft
50	6W0235010	Worm shaft holder
51	6W0236010	Worm shaft washer (B)
52	6W0237010	Worm shaft retainer
53	6W0238010	Stabilizer bar
54	6W0239010	Front plate screw
55	6W0276010	Front plate
56	6W0242010	Frame assembly
57	6W0243010	Clutch lever

58	6W0277010	Spool assembly
59	6W0246010	Magnet holder ret. ring
60	6W0247010	Magnet holder
61	6W0207010	Bearing retainer
62	6W0248010	Ball bearing (B)
63	6W0250010	Spacer (C)
64	6W0212010	Spacer (A)
65	6W0206010	Screw (A)
66	6W0251010	Brake dial retainer
67	6W0217010	Screw (B)
68	6W0252010	Left set plate
69	6W0278010	Left side plate
70	6W0255010	Brake click spring
71	6W0256010	Brake dial washer
72	6W0257010	Brake dial retainer
73	6W0279010	Brake adjusting knob
74	6W0260010	Set plate spring
75	6W0280010	Set plate screw