


# SPINNING REEL REGAL RG-X2505B



| Key No. | Parts No. | Parts Name               | Key No. | Parts No. | Parts Name                 |
|---------|-----------|--------------------------|---------|-----------|----------------------------|
| 2-9     | F42-0601  | Spool assembly           | 29      | E41-7801  | Trigger screw              |
| 1       | F42-0901  | Drag knob                | 30      | F12-8901  | Bail spring                |
| 2       | F37-3301  | Drag washer retainer     | 31      | F31-0504  | Bail spring cover          |
| 3       | E46-7201  | Key washer               | 32      | E36-4202  | Bail spring cover screw    |
| 4       | E13-6001  | Drag washer              | 33      | F31-0604  | Bail trip cover            |
| 5       | 373-3603  | Eared washer             | 34      | E49-2402  | Anti-reverse ratchet       |
| 6       | F42-0701  | Spool                    | 35      | F38-4701  | Anti-reverse pawl spring A |
| 7       | B07-5304  | Click pawl               | 36      | F37-5101  | Spring holder              |
| 8       | E40-3101  | Click spring             | 37      | L03-6601  | Ball bearing               |
| 9       | 320-5901  | Click retainer           | 38      | F37-7501  | Pinion gear                |
| 10      | E46-7101  | Spool washer             | 39      | E24-3301  | Pinion collar              |
| 11      | 270-6501  | Click gear               | 40      | F42-2601  | Body assembly              |
| 12      | F38-9601  | Main shaft               | 41      | L00-1801  | Anti-reverse pawl screw    |
| 13      | E45-1401  | Oscillating slider       | 42      | F37-5001  | Anti-reverse pawl          |
| 14      | 351-0315  | Oscillating slider screw | 43      | L01-4302  | Anti-reverse pawl collar   |
| 15      | 341-9201  | Rotor nut                | 44      | L00-1501  | Anti-reverse pawl spring B |
| 16      | F42-0801  | Rotor assembly           | 45      | E03-7801  | Bearing retainer screw     |
| 17      | B67-9306  | Line roller screw        | 46      | E32-7801  | Anti-reverse cam spring    |
| 18      | F17-9803  | Bail arm                 | 47      | F08-5121  | Anti-reverse lever         |
| 19      | E49-3501  | Bail arm screw           | 48      | E45-1301  | Oscillating gear           |
| 20      | 320-5901  | Bail arm screw retainer  | 49      | F17-0001  | Drive gear                 |
| 21      | F06-6301  | Line roller collar       | 50      | 373-7808  | Drive gear washer          |
| 22      | F31-6801  | Line roller bushing      | 51      | F42-2801  | Side cover                 |
| 23      | E50-6001  | Line roller              | 52      | B00-9701  | Side cover screw           |
| 24      | F32-7401  | Bail assembly            | 53      | F42-0501  | Handle assembly            |
| 25      | B84-2102  | Bail trip cam screw      | 54      | F40-4801  | Handle collar              |
| 26      | E45-1601  | Bail trip lever          | 55      | B92-5006  | Handle lock screw          |
| 27      | F18-0003  | Trigger lever            |         |           |                            |
| 28      | E36-9901  | Trigger spring           |         |           |                            |