


SPINNING REEL REGAL RG-X5500-2B/RG-X6000-2B



Key No.	Parts No.	Parts Name
2-9	L13-6302	Spool assembly (Aluminum Spool)
	E51-4105	Spool assembly (Extra Spool)
1	F36-9802	Drag knob
2	171-7701	Drag washer retainer
3	L03-1301	Key washer
4	373-3712	Drag washer
5	B89-9501	Eared washer
6	L13-6402	Spool assembly
7	B07-8201	Click pawl
8	145-2101	Click spring
9	320-1402	Click retainer
10	F22-5501	Spool washer
11	L11-8501	Click gear
12	F42-9501	Main shaft
13	F42-9101	Oscillating slider
14	351-8901	Oscillating slider screw
15	B02-1601	Rotor nut holding plate
16	L01-1702	Rotor nut holding plate screw
17	340-8301	Rotor nut
18	F39-4402	Rotor
19	E45-4002	Line roller screw
20	160-8401	Lock washer
21	F39-4302	Bail arm
22	E00-7601	Bail arm screw
23	F08-8301	Line roller collar
24	E50-5901	Line roller bushing
25	E50-6001	Line roller
26	F39-3802	Bail assembly
27	F41-3401	Bail trip lever
28	F43-6401	Bail spring
29	F39-3302	Bail spring cover
30	E24-8101	Bail spring cover screw
31	F39-3402	Bail trip cover
32	F21-2001	Anti-reverse pawl spring A
33	L07-0701	Anti-reverse pawl spring B
34	F39-4201	Anti-reverse ratchet
35	LC3-6401	Ball bearing A
36	L11-4401	Pinion gear
37	L00-6001	Pinion collar

Key No.	Parts No.	Parts Name
38	E53-5101	Body assembly
42	L06-6501	Anti-reverse pawl screw
43	L06-6401	Anti-reverse pawl spring C
44	L07-8601	Anti-reverse pawl
45	L01-1601	Bearing retainer screw
46	E01-1801	Anti-reverse cam -Spring
47	L10-0702	Anti-reverse lever
48	B47-4101	Oscillating gear collar
49	L11-4701	Oscillating gear
50	L07-1701	Drive gear
51	371-2821	Drive gear washer
52	B54-6001	Ball bearing B
53	E53-5301	Side cover
54	BS3-5002	Side cover screw
55	F40-9001	Handle collar
56	L00-9102	Handle lock screw
57	F41-4601	Handle assembly
58	F43-1001	Ratchet washer

RG-X6000-2B Special Parts

2-9	F43-2501	Spool assembly (Aluminum Spool)
	F43-2601	Spool assembly (Extra Spool)
18	F39-4702	Rotor assembly
26	F39-4002	Bail assembly
27	F39-3501	Bail trip lever
38	E53-4902	Body assembly
53	E53-5303	Side cover