


SPINNING REEL REGAL-X1505-2B



Key NO.	Parts No.	Parts Name
2-9	F33-0601	Spool assembly
1	F32-8502	Drag knob
2	F37-3301	Drag washer retainer
3	E46-7201	Key washer
4	E13-6001	Drag washer
5	373-3603	Eared washer
6	F33-0701	Spool assembly
7	B07-5304	Click pawl
8	E40-3101	Click spring
9	320-5901	Click retainer
10	E46-7101	Spool washer
11	270-6501	Click gear
12	E49-8401	Main shaft
13	F12-2301	Oscillating slider
14	351-0311	Oscillating slider screw
15	341-9201	Rotor nut
16	F33-1402	Rotor
17	B67-9306	Line roller screw
18	F17-3101	Bail arm
19	E49-3501	Bail arm screw
20	320-5901	Bail arm screw retainer
21	F06-6301	Line roller collar
22	F31-6801	Line roller bushing
23	E50-6001	Line roller
24	F33-1502	Bail assembly
25	B84-2102	Bail trip cam screw
26	E49-6401	Bail trip lever

Key NO.	Parts No.	Parts Name
27	E49-3403	Trigger lever
28	E36-9901	Trigger spring
29	E37-0002	Trigger screw
30	E49-6801	Bail spring
31	F32-4102	Bail spring cover
32	E24-8101	Bail spring cover screw
33	F32-6502	Bail trip cover
34	F12-2101	Anti-reverse pawl spring A
35	E49-8501	Anti-reverse ratchet
36	634-1301	Ball bearing
37	F12-1601	Pinion gear
38	F33-0802	Body assembly
39	F12-5701	Anti-reverse pawl screw
40	F12-1901	Anti-reverse pawl
41	F12-3501	Anti-reverse pawl collar
42	F12-3401	Anti-reverse pawl spring B
43	E03-7801	Bearing retainer screw
44	F12-2001	Anti-reverse cam spring
45	F08-5104	Anti-reverse lever
46	F12-2201	Oscillating gear
47	F12-1501	Drive gear
48	375-8502	Drive gear washer
49	634-1301	Ball bearing
50	F33-0402	Side cover
51	E15-8602	Side cover screw
52	F33-0501	Handle assembly
53	501-8501	Handle collar
54	B92-5004	Handle lock screw