


# SPINNING REEL REGAL-X3505-2B



| Key NO. | Parts No. | Parts Name               | Key NO. | Parts No. | Parts Name                 |
|---------|-----------|--------------------------|---------|-----------|----------------------------|
| 2-9     | E52-0504  | Spool assembly           | 31      | F31-4502  | Bail spring cover          |
| 1       | F32-9502  | Drag knob                | 32      | E24-8101  | Bail spring cover screw    |
| 2       | 171-7701  | Drag washer retainer     | 33      | F31-4602  | Bail trip cover            |
| 3       | F09-4901  | Key washer               | 34      | E46-2001  | Anti-reverse pawl spring A |
| 4       | E13-6003  | Drag washer              | 35      | F11-1301  | Anti-reverse ratchet       |
| 5       | 373-3603  | Eared washer             | 36      | L03-6502  | Bail bearing A             |
| 6       | E52-0602  | Spool assembly           | 37      | E52-0101  | Pinion gear                |
| 7       | B07-5304  | Click pawl               | 38      | F33-2902  | Body assembly              |
| 8       | E40-3101  | Click spring             | 39      | E00-7101  | Anti-reverse pawl screw    |
| 9       | 320-5901  | Click retainer           | 40      | E46-1302  | Anti-reverse pawl          |
| 10      | F09-4701  | Spool washer             | 41      | E46-1201  | Anti-reverse pawl spring B |
| 11      | E46-2701  | Click gear               | 42      | E03-7801  | Bearing retainer screw     |
| 12      | E48-5301  | Main shaft               | 43      | E32-7801  | Anti-reverse cam spring    |
| 13      | F09-1301  | Oscillating slider       | 44      | F08-5109  | Anti-reverse lever         |
| 14      | 352-1502  | Oscillating slider screw | 45      | F13-1601  | Oscillating gear collar    |
| 15      | 340-6602  | Rotor nut                | 46      | E46-1501  | Oscillating gear           |
| 16      | F33-3502  | Rotor                    | 47      | E52-0201  | Drive gear                 |
| 17      | B67-9304  | Line roller screw        | 48      | 373-7802  | Drive gear washer          |
| 18      | F17-9801  | Bail arm                 | 49      | 631-6901  | Bail bearing B             |
| 19      | E49-3501  | Bail arm screw           | 50      | F33-3002  | Side cover                 |
| 20      | 320-5901  | Bail arm screw retainer  | 51      | B83-5002  | Side cover screw A         |
| 21      | F06-6301  | Line roller collar       | 52      | E15-8602  | Side cover screw B         |
| 22      | E50-5901  | Line roller bushing      | 53      | F33-5401  | Handle assembly            |
| 23      | E50-6001  | Line roller              | 54      | E12-7501  | Handle collar              |
| 24      | F33-3602  | Bail assembly            | 55      | B92-5001  | Handle lock screw          |
| 25      | B84-2102  | Bail trip cam screw      |         |           |                            |
| 26      | E46-2101  | Bail trip lever          |         |           |                            |
| 27      | F18-0001  | Trigger lever            |         |           |                            |
| 28      | E36-9901  | Trigger spring           |         |           |                            |
| 29      | E37-0003  | Trigger screw            |         |           |                            |
| 30      | F12-8901  | Bail spring              |         |           |                            |