




Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

RG2000H-AB – 3000H-AB



Key No.	Part No.	Part Name	Part No.	Part Name	Part No.	Part Name
1	Q28-6701	DRAG KNOB	Q28-6201	DRAG KNOB	Q28-6201	DRAG KNOB
2	F37-3301	DRAG WASHER RET	F37-3301	DRAG WASHER RET	F37-3301	DRAG WASHER RET
3	E13-6901	DRAG WASHER	E13-6901	DRAG WASHER	E13-6901	DRAG WASHER
4	E46-7201	KEY WASHER	E46-7201	KEY WASHER	E46-7201	KEY WASHER
5	-	EARED WASHER	373-3606	EARED WASHER	373-3606	EARED WASHER
2-6	Q28-6501	SPOOL ASSEMBLY	Q28-6001	SPOOL ASSEMBLY	Q28-7101	SPOOL ASSEMBLY
7	G21-3001	O RING	G21-3001	O RING	G21-3001	O RING
8	E33-2501	BALL BEARING	G46-9005	BALL BEARING	G46-9005	BALL BEARING
9	B41-1706	WASHER	B41-1706	WASHER	B41-1706	WASHER
10	E39-8000	WASHER	E39-8000	WASHER	E39-8000	WASHER
11	E46-7101	WASHER	E46-7101	WASHER	E46-7101	WASHER
12	G83-9301	CLICK GEAR	G83-9301	CLICK GEAR	G83-9301	CLICK GEAR
13	Q12-2401	ROTOR NUT	Q12-2401	ROTOR NUT	Q12-2401	ROTOR NUT
14	H02-2701	SCREW	H02-2701	SCREW	H02-2701	SCREW
15	Q13-9511	ROTOR	Q12-0510	ROTOR	Q12-9208	ROTOR
16	H44-3301	BAIL TRIP LEVER SPRING	H41-3601	BAIL TRIP LEVER SPRING	H41-3601	BAIL TRIP LEVER SPRING
17	Q13-9601	BAIL TRIP LEVER	Q12-0701	BAIL TRIP LEVER	Q12-9301	BAIL TRIP LEVER
18	H41-7701	SCREW	H41-7701	SCREW	H41-7701	SCREW
19	Q13-9801	BAIL SPRING SHAFT	Q12-1201	BAIL SPRING SHAFT	Q12-9501	BAIL SPRING SHAFT
20	H57-6101	BAIL SPRING PLT	H57-6101	BAIL SPRING PLT	H57-6101	BAIL SPRING PLT
21	H44-2401	BAIL SPRING	H54-5701	BAIL SPRING	H41-4201	BAIL SPRING
22	Q12-1501	BAIL SPRING HOLDER	Q12-1501	BAIL SPRING HOLDER	Q12-1501	BAIL SPRING HOLDER
23	Q14-6502	ARM LEVER SPRING COVER	Q12-1802	ARM LEVER SPRING COVER	Q12-9602	ARM LEVER SPRING COVER
24	G27-0801	SCREW	G27-0801	SCREW	G27-0801	SCREW
25	Q12-1609	BAIL ARM	Q12-1609	BAIL ARM	Q12-1609	BAIL ARM
26	Q12-1701	COLLAR	Q12-1701	COLLAR	Q12-1701	COLLAR
27	G20-5001	SCREW	G20-5001	SCREW	G20-5001	SCREW
28	G19-5602	SCREW	G19-5602	SCREW	G19-5602	SCREW
29	G19-5501	COLLAR	G19-5501	COLLAR	G19-5501	COLLAR
30	G22-0701	COLLAR	G22-0701	COLLAR	G22-0701	COLLAR
31	J08-9902	LINE ROLLER	J08-9902	LINE ROLLER	J08-9902	LINE ROLLER
32	Q20-3401	COLLAR	Q20-3401	COLLAR	Q20-3401	COLLAR
33	Q28-1601	BAIL ASSEMBLY	Q28-1001	BAIL ASSEMBLY	Q28-2401	BAIL ASSEMBLY
34	G83-7101	SCREW	G83-7101	SCREW	G83-7101	SCREW
35	Q13-9401	SEALED CAP	Q12-0101	SEALED CAP	Q12-9901	SEALED CAP
36	H99-2901	ROLLER CLUTCH	H99-2901	ROLLER CLUTCH	H99-2901	ROLLER CLUTCH
37	J00-1401	SPACING SLEEVE	J00-1401	SPACING SLEEVE	J00-1401	SPACING SLEEVE
38	Q12-6201	SCREW	Q12-6201	SCREW	Q12-6201	SCREW
39	H44-2201	BEARING RETAINER	H44-2201	BEARING RETAINER	H41-1501	BEARING RETAINER
40	G46-7302	BALL BEARING	G46-7302	BALL BEARING	G53-5104	BALL BEARING
41	375-8500	WASHER	375-8500	WASHER	375-8500	WASHER
42	Q24-3501	PINION GEAR	Q24-3501	PINION GEAR	Q24-5001	PINION GEAR
43	H93-1701	SPRING WASHER	H93-1701	SPRING WASHER	H93-1701	SPRING WASHER
44	H95-9601	BALL BEARING	H95-9601	BALL BEARING	G46-6202	BALL BEARING
45	Q28-6301	BODY	Q28-5701	BODY	Q28-6801	BODY
46	Q16-8401	MAIN SHAFT	Q16-8501	MAIN SHAFT	Q16-8601	MAIN SHAFT
47	Q12-6301	SPABILIZER BAR	Q12-6301	SPABILIZER BAR	Q12-6302	SPABILIZER BAR
48	Q11-9101	STABILIZER BAR	Q11-9101	STABILIZER BAR	Q11-9102	STABILIZER BAR
49	Q11-8101	A/R CAM	Q11-8101	A/R CAM	Q11-8101	A/R CAM
50	H69-7801	A/R CAM SPRING	H69-7801	A/R CAM SPRING	H69-7801	A/R CAM SPRING
51	Q11-8001	A/R LEVER	Q11-8001	A/R LEVER	Q11-8001	A/R LEVER
52	Q12-0302	REAR COVER	Q12-0302	REAR COVER	Q12-9102	REAR COVER
53	G27-0801	SCREW	G27-0801	SCREW	G27-0801	SCREW
54	H59-5701	WASHER	H59-5701	WASHER	H59-5701	WASHER
55	Q13-9001	OSC GEAR	Q11-8401	OSC GEAR	Q12-8201	OSC GEAR
56	H77-0601	O RING	H77-0601	O RING	G46-6001	O RING
57	H12-9200	WASHER	H12-9200	WASHER	H12-9200	WASHER
58	G46-9005	BALL BEARING	G46-9005	BALL BEARING	G46-9005	BALL BEARING
59	Q12-6101	SCREW	Q12-6101	SCREW	Q12-6101	SCREW
60	G67-0501	O RING	G67-0501	O RING	G67-0501	O RING
61	Q13-2201	DRIVE GEAR	Q13-2201	DRIVE GEAR	Q16-7201	DRIVE GEAR
62	375-8500	WASHER	375-8500	WASHER	375-8500	WASHER
63	G46-7302	BALL BEARING	G46-7302	BALL BEARING	G46-7302	BALL BEARING
64	Q28-5801	SIDE COVER	Q28-5801	SIDE COVER	Q28-6901	SIDE COVER
65	G11-5001	SCREW	G11-5001	SCREW	G11-5001	SCREW
66	Q28-6401	HANDLE ASSEMBLY	Q28-5901	HANDLE ASSEMBLY	Q28-7001	HANDLE ASSEMBLY
67	G52-2706	BALL BEARING	G52-2706	BALL BEARING	G52-2706	BALL BEARING
68	G47-2401	BEARING RETAINER	G47-2401	BEARING RETAINER	G47-2401	BEARING RETAINER
69	F72-1001	COLLAR	F72-1001	COLLAR	F72-1001	COLLAR
70	160-8401	LOCK WASHER	160-8401	LOCK WASHER	160-8401	LOCK WASHER
71	Q13-2402	HANDLE SCREW	Q13-2402	HANDLE SCREW	Q13-2402	HANDLE SCREW