



Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
19 REVROS LT 5000-C	S41803U	1	6Q352901	DRAG KNOB
19 REVROS LT 5000-C	S41803U	2	6Q346101	DRAG RING
19 REVROS LT 5000-C	S41803U	3	6J547001	DRAG DISC WASHER
19 REVROS LT 5000-C	S41803U	4	6J546801	DRAG WASHER
19 REVROS LT 5000-C	S41803U	5	6Q346001	-----
19 REVROS LT 5000-C	S41803U	6	6Q480901	SPOOL ASSEMBLY (2 - 6)
19 REVROS LT 5000-C	S41803U	7	6E398000	SPOOL WASHER(A)
19 REVROS LT 5000-C	S41803U	8	6Q348502	SPOOL WASHER(B)
19 REVROS LT 5000-C	S41803U	9	6Q457701	CLICK LEAF SPRING
19 REVROS LT 5000-C	S41803U	10	6Q457601	CLICK HOLDER
19 REVROS LT 5000-C	S41803U	11	6Q344001	CLICK HOLDER WASHER
19 REVROS LT 5000-C	S41803U	12	6Q122401	ROTOR NUT
19 REVROS LT 5000-C	S41803U	13	6H022701	ROTOR NUT SCREW
19 REVROS LT 5000-C	S41803U	14	6Q129215	ROTOR
19 REVROS LT 5000-C	S41803U	15	6H413601	KICK LEVER SPRING
19 REVROS LT 5000-C	S41803U	16	6Q129301	KICK LEVER
19 REVROS LT 5000-C	S41803U	17	6H417701	KICK LEVER SCREW
19 REVROS LT 5000-C	S41803U	18	6Q129501	ARM LEVER SHAFT
19 REVROS LT 5000-C	S41803U	19	6H576101	ARM LEVER PLATE
19 REVROS LT 5000-C	S41803U	20	6H414201	ARM LEVER SPRING
19 REVROS LT 5000-C	S41803U	21	6Q121501	ARM LEVER SPRING HOLDER
19 REVROS LT 5000-C	S41803U	22	6Q129601	ARM LEVER SPRING COVER
19 REVROS LT 5000-C	S41803U	23	6G205001	COVER SCREW
19 REVROS LT 5000-C	S41803U	24	6Q121606	ARM LEVER
19 REVROS LT 5000-C	S41803U	25	6Q121701	ARM LEVER COLLAR
19 REVROS LT 5000-C	S41803U	26	6G205001	ARM LEVER SCREW
19 REVROS LT 5000-C	S41803U	27	6G195602	ROLLAR SCREW
19 REVROS LT 5000-C	S41803U	28	6G195501	ROLLAR COLLAR(A)
19 REVROS LT 5000-C	S41803U	29	6G220701	ROLLAR COLLAR(B)
19 REVROS LT 5000-C	S41803U	30	6J089902	LINE ROLLER
19 REVROS LT 5000-C	S41803U	31	6Q203401	ROLLAR COLLAR(C)
19 REVROS LT 5000-C	S41803U	32	6Q167901	BAIL ASSEMBLY
19 REVROS LT 5000-C	S41803U	33	-----	-----
19 REVROS LT 5000-C	S41803U	34	6G837101	SHIELD CAP SCREW
19 REVROS LT 5000-C	S41803U	35	6Q129001	SHEILD CAP
19 REVROS LT 5000-C	S41803U	36	6Q308301	ONEWAY CLUCH
19 REVROS LT 5000-C	S41803U	37	6J001401	CLUCH RING
19 REVROS LT 5000-C	S41803U	38	6Q126201	PINION BALL BEARING PLATE SCREW
19 REVROS LT 5000-C	S41803U	39	6H411501	PINION BALL BEARING PLATE
19 REVROS LT 5000-C	S41803U	40	6G535104	PINION BALL BEARING
19 REVROS LT 5000-C	S41803U	41	6Q463501	PINION GEAR
19 REVROS LT 5000-C	S41803U	42	-----	PINION COLLAR
19 REVROS LT 5000-C	S41803U	43	6Q480201	BODY
19 REVROS LT 5000-C	S41803U	44	6Q351001	MAIN SHAFT
19 REVROS LT 5000-C	S41803U	45	6Q126302	-----
19 REVROS LT 5000-C	S41803U	46	6Q119102	OSCILLATING POST(B)
19 REVROS LT 5000-C	S41803U	47	6Q118101	STOPPER CAM
19 REVROS LT 5000-C	S41803U	48	6H697801	STOPPER CAM SPRING
19 REVROS LT 5000-C	S41803U	49	6Q118001	STOPPER LEVER
19 REVROS LT 5000-C	S41803U	50	6Q129101	REAR CAP
19 REVROS LT 5000-C	S41803U	51	6G270801	REAR CAP SCREW
19 REVROS LT 5000-C	S41803U	52	6H595701	OSCILLATING GEAR WASHER
19 REVROS LT 5000-C	S41803U	53	6Q350901	OSCILLATING GEAR
19 REVROS LT 5000-C	S41803U	54	6G466001	OSCILLATING GEAR ORING
19 REVROS LT 5000-C	S41803U	55	6H129200	OSCILLATING GEAR BEARING WASHER
19 REVROS LT 5000-C	S41803U	56	6G469005	OSCILLATING GEAR BALL BEARING
19 REVROS LT 5000-C	S41803U	57	6Q126101	OSCILLATING GEAR SCREW
19 REVROS LT 5000-C	S41803U	58	6G670501	DRIVE GEAR ORING
19 REVROS LT 5000-C	S41803U	59	6Q351401	DRIVE GEAR
19 REVROS LT 5000-C	S41803U	60	63758500	DRIVE WASHER
19 REVROS LT 5000-C	S41803U	61	6G467302	DRIVE BALL BEARING(A)
19 REVROS LT 5000-C	S41803U	62	6Q480301	BODY COVER
19 REVROS LT 5000-C	S41803U	63	6G115001	BODY COVER SCREW
19 REVROS LT 5000-C	S41803U	64	6Q483101	HANDLE ASSEMBLY
19 REVROS LT 5000-C	S41803U	65	6G522706	DRIVE BALL BEARING(B)
19 REVROS LT 5000-C	S41803U	66	6G472401	DRIVE BALL BEARING RING
19 REVROS LT 5000-C	S41803U	67	6F721001	HANDLE COLLAR
19 REVROS LT 5000-C	S41803U	68	61608401	HANDLE WASHER
19 REVROS LT 5000-C	S41803U	69	6Q132401	HANDLE SCREW