


DAIWA

SPINNING REEL

REVRLT2500_2500-XH_3000C

*Please order by parts number, not key number.



Key No	Part No	Description
1	Q81-0401	DRAG KNOB
2	Q34-6101	DRAG WASHER RETAINER
3	Q62-1901	KEY WASHER
4	Q91-7601	DRAG WASHER
5	Q34-6001	EARED WASHER
2 6	Q85-8201	SPOOL ASSY
7	E39-8003	SPOOL WASHER (A)
8	Q34-8502	SPOOL WASHER (B)
9	Q79-7701	CLICK LEAF SPRING
10	Q79-8201	CLICK SPRING HOLDER
11	Q34-4001	SPOOL WASHER (C)
12	Q90-6401	ROTOR NUT
13	Q85-8101	ROTOR NUT COLLAR
14	372-7602	ROTOR NUT WASHER
15	H02-2701	ROTOR NUT SCREW
16	Q80-8205	ROTOR
17	Q81-0801	BAIL TRIP LEVER SPRING
18	M19-4601	BAIL TRIP LEVER SPRING WASHER
19	Q80-8301	BAIL TRIP LEVER
20	Q95-7301	BAIL TRIP LEVER SCREW
21	Q81-0901	BAIL SPRING SHAFT
22	Q80-8501	BAIL SPRING COLLAR
23	Q81-1701	BAIL SPRING
24	Q80-8601	BAIL SPRING HOLDER
25	Q81-2001	BAIL CLICK SPRING
26	Q80-8701	BAIL CLICK PIN
27	Q81-2201	BAIL SPRING COVER SCREW
28	Q80-9201	BAIL SPRING COVER
29	Q80-8801	BAIL ARM
30	Q80-9101	BAIL ARM COLLAR
31	B33-9801	BAIL ARM RETAINER
32	Q81-0001	ROLLER COLLAR (A)
33	Q80-9901	ROLLER COLLAR (B)
34	Q80-9803	LINE ROLLER
35	Q80-9901	ROLLER COLLAR (C)
36	Q81-0101	ROLLER WASHER
37	Q80-9301	BAIL ASSY
38	Q80-9701	ROLLER SCREW COLLAR
39	373-1306	ROLLER SCREW WASHER
40	M39-8901	ROLLER SCREW
41	Q41-6203	BAIL HOLDER WASHER
42	Q81-2301	BAIL HOLDER SCREW
43	---	---
44	G83-7101	SHIELD COVER SCREW
45	Q13-9401	SHIELD COVER
46	J38-8401	ONEWAY CLUTCH
47	J00-1403	CLUTCH RING
48	Q12-6201	PINION BEARING PLATE SCREW
49	Q19-5601	PINION BEARING PLATE
50	G46-7302	PINION BALL BEARING

Key No	Part No	Description
51	Q90-5901	PINION GEAR
52	---	---
53	Q80-7801	BODY
54	Q81-6501	MAIN SHAFT
55	Q12-6301	OSCILLATING POST (A)
56	Q11-9101	OSCILLATING POST (B)
57	Q11-8101	ANTI REVERSE CAM
58	H69-7801	ANTI REVERSE CAM SPRING
59	Q11-8001	ANTI REVERSE LEVER
60	Q80-8101	REAR COVER
61	G27-0801	REAR COVER SCREW
62	H59-5701	OSCILLATING GEAR WASHER
63	Q13-9001	OSCILLATING GEAR
64	H77-0601	OSCILLATING GEAR O RING
65	H12-9201	OSCILLATING GEAR BEARING WASHER
66	G46-9005	OSCILLATING GEAR BALL BEARING
67	Q12-6101	OSCILLATING GEAR SCREW
68	G67-0501	DRIVE GEAR RING
69	Q34-1901	DRIVE GEAR
70	375-8502	DRIVE WASHER
71	G46-7302	DRIVE BALL BEARING (A)
72	Q80-8001	SIDE COVER
73	G11-5001	SIDE COVER SCREW
74	Q47-7801	HANDLE ASSY
75	G52-2706	DRIVE BALL BEARING (B)
76	G47-2401	DRIVE BEARING RETAINER
77	F72-1001	HANDLE COLLAR
78	160-8401	HANDLE WASHER
79	Q13-2401	HANDLE SCREW
80	F03-7404	BAIL HOLDER SCREW WASHER

REVRLT2500-XH Special Parts

Key No	Part No	Description
2 6	Q81-0501	SPOOL ASSY
51	Q90-5801	PINION GEAR
69	Q36-0501	DRIVE GEAR

REVRLT3000-C Special Parts

Key No	Part No	Description
2 6	Q81-7501	SPOOL ASSY
16	Q81-6804	ROTOR
19	Q81-6901	BAIL TRIP LEVER
28	Q81-7101	BAIL SPRING COVER
37	Q81-7201	BAIL ASSY
51	Q90-5901	PINION GEAR
53	Q81-6701	BODY
54	Q46-1501	MAIN SHAFT
63	Q11-8401	OSCILLATING GEAR
69	Q34-1901	DRIVE GEAR
74	Q47-9601	HANDLE ASSY