




Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	J17-5402	DRAG KNOB	50	F76-5401	ROLLER CLUTCH
2	H61-6701	WASHER	51	G15-8101	WASHER
3	F71-0001	DRAG WASHER RET	52	F20-6902	SCREW
4	G16-5603	DRAG KNOB CLICK PLT	53	H50-1901	BEARING RET
5	H24-7202	DRAG WASHER	54	G42-6301	BALL BEARING
6	G16-5902	EARED WASHER	55	H68-3501	COLLAR
7	G16-2702	KEY WASHER	56	E26-2701	A/R RATCHET
8	G15-6801	G15-6801	57	372-7603	WASHER
2-9	J19-0101	SPOOL ASSEMBLY	58	372-7600	WASHER
10	G33-9202	SPOOL METAL	59	Z02-1716	PINION+DRIVE GEAR UNIT
11	G33-9401	O-RING	60	B86-1703	BALL BEARING
12	G33-9101	O-RING	61	H68-3001	COLLAR
13	G31-4901	BALL BEARING	62	J18-8703	BODY
14	G34-1501	WASHER	63	G33-9301	PIN
15	G34-1401	CLICK LEAF SPRING	64	G33-8901	PIN
16	G34-1301	CLICK LEAF SPRING HOLDER	65	J18-8901	MAIN SHAFT
17	G33-9001	SPOOL METAL	66	H68-4301	PACKING
18	H50-3901	SCREW	67	G68-4801	WASHER
19	H68-5701	COLLAR	68	H68-4403	REAR COVER
20	H68-5601	PACKING	69	G94-6802	SCREW
21	H68-5501	COLLAR	70	G33-4901	OSC GEAR
22	B86-1702	BALL BEARING	71	G15-7401	SPRING
23	H68-5402	ROTOR NUT	72	H68-2601	OSC GEAR
24	H68-5301	PLATE	73	G21-3001	O-RING
25	F27-4501	O-RING	74	B86-1702	BALL BEARING
26	H68-4503	ROTOR	75	H34-7101	SCREW
27	H78-2801	SPRING	76	H68-3601	A/R PAWL
28	E27-2501	WASHER	77	G33-6201	COLLAR
29	H68-4601	SHAFT	78	351-6413	SCREW
30	H68-4701	BAIL SPRING HOLDER	79	G33-6601	SPRING
31	G41-8101	BAIL SPRING	80	G33-9401	O-RING
32	G33-7301	BAIL SPRING SHAFT	81	G33-4703	DRIVE IDLE GEAR
33	H68-4901	BAIL	82	G33-6701	O-RING
34	E09-6500	WASHER	83	G33-9401	O-RING
35	J04-2801	COLLAR	84	J04-8701	BALL BEARING
36	J04-2901	LINE ROLLER	85	H68-3901	PACKING
37	J01-9302	BALL BEARING	86	H68-3810	SIDE COVER
38	H50-3605	ARM LEVER	87	G16-0101	SCREW
39	H50-4701	SCREW	88	H50-5201	SCREW
40	H84-2801	SCREW	89	J04-8601	O-RING
41	H50-3701	SCREW	90	H50-2200	WASHER
42	H68-4801	COVER	91	J18-8804	BODY COVER (A)
43	H50-3901	SCREW	92	G94-6801	SCREW
44	H68-7201	WASHER	93	J04-8701	BALL BEARING
45	G33-8401	O-RING	94	J04-8601	O-RING
46	H68-8601	CLUTCH RING	95	J18-8804	BODY COVER (A)
47	J18-9101	INFINITE COVER	96	G94-6801	SCREW
48	H53-5301	MAGNET ASSEMBLY	97	J18-9601	HANDLE CAP
49	H50-2601	O-RING	98	J18-9201	HANDLE ASSEMBLY