


SALTIGA LD60-2SPEED



Key No.	Part No.	Part Name.	Key No.	Part No.	Part Name.
1	E67-8801	FRAME	50	E68-3101	DRIVE SHAFT NUT
2	B33-9801	RETAINER(A)	51	E68-2401	DRIVE SHAFT SPRING(B)
3	E67-9201	CLICK PLATE	52	E68-2301	COLLAR(A)
4	E65-6501	CLICK SPRING(A)	53	E64-4502	SCREW(F)
5	E67-9101	CLICK BUTTON	54	E64-4301	COLLAR(B)
6	E67-9401	CLICK BUTTON WASHER	55	E59-1601	SCREW(G)
7	E67-9301	CLICK PAWL	56	E68-3901	WASHER(B)
8	320-1402	CLICK PAWL RETAINER	57	E64-3901	SPRING(B)
9	E67-9501	CLICK SPRING(B)	58	E65-9901	PIN
10	E67-1401	RING HOLDER	59	E68-4101	DRAG LEVER
11	E67-1501	SCREW(A)	60	E68-4201	COLLAR (C)
12	E67-9601	FRAME PLATE	61	E68-4401	DRAG LEVER PLATE(A)
13	F50-5703	SCREW(B)	62	E68-4301	DRAG LEVER PLATE(B)
14	E67-9801	SPOOL	63	E64-1501	SCREW(H)
15	E67-9901	DRAG WASHER	64	E68-4501	PRE-SET CAM(A)
16	E68-0301	BALL BEARING(A)	65	E68-4601	RING
17	373-7816	WASHER(A)	66	E68-4701	PRE-SET CAM(B)
18	E68-0201	DRAG SPRING WASHER	67	171-1001	"O"RING(A)
19	E68-0701	MAIN SHAFT	68	E68-4801	CLICK LEAF SPRING
20	E68-0801	DRAG CLICK CAP	69	H48-4801	DRAG KNOB SPRING
21	G29-7001	SCREW (C)	70	E68-4901	PRE-SET DRAG KNOB
22	E68-1401	PIN	71	G43-9401	BALL BEARING(F)
23	B35-2701	BRAKE COLLAR	72	E68-5001	COLLAR
24	G53-5101	BALL BEARING(B)	73-79	E68-5101	HANDLE ASSEMBLY
25	E68-0601	SPRING(A)	80	E68-5401	HANDLE SCREW(A)
26	G53-5101	BALL BEARING (C)	81	E68-5501	HANDLE BUTTON
27	E68-1001	DRAG METAL	82	320-5901	RETAINER(B)
28	E68-1201	DRAG WASHER COVER	83	350-8912	SCREW(I)
29	E68-1301	PACKING	84	H42-6101	HANDLE CAP(A)
30	E66-8901	SCREW(D)	85	H42-6301	PLATE
31	E68-3401	DRAG RATCHET	86	H42-6201	SPRING(C9)
32	E68-3301	PINION GEAR(A)	87	H42-6401	HANDLE LEVER
33	E68-3201	PINION GEAR(B)	88	H56-2101	HANDLE CAP(B)
34	E68-5601	BALL BEARING(D)	89	G04-0815	HANDLE SCREW(B)
35	E68-1601	RIGHT SIDE PLATE	90	H60-0701	CLAMP BOLT
36	E68-3501	DRAG PAWL	91	J01-4401	ROD CLAMP
37	E64-3701	DRAG PAWL RETAINER	92	H60-0801	CLAMP NUT
38	E64-3801	SCREW(E)	93	E68-2601	DRIVE GEAR COLLAR(D)
39	E68-1901	DRIVE SHAFT(B)	94	E68-6201	SPRING(D)
40	F64-1602	BALL BEARING	95	E68-1701	PUSH BUTTON
41	E68-2701	DRIVE GEAR COLLAR(A)	96	E68-3801	PIN(B)
42	E68-2001	DRIVE SHAFT PIN(B)	97	E67-7201	HARNES LUG(A)
43	E68-2101	DRIVE SHAFTSPRING(A)	98	E67-7101	HARNES LUG(B)
44	E68-2201	DRIVE SHAFT SCREW	99	E68-5901	SCREW
45	E66-6501	DRIVE SHAFT PIN ©	100	E68-6101	DRAG METAL SCREW
46	E68-2801	DRIVE GEAR(A)	101	E68-1101	DRAG PLATE
47	E68-2901	DRIVE GEAR COLLAR(B)	102	E68-6301	"O"RING(B)
48	E68-3001	DRIVE GEAR(B)	103	E68-6500	WASHER(D)
49	E68-2701	DRIVE GEAR COLLAR (C)	104	E64-4001	PIN (C)