




16 SALTIST NERO 4500

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S28306U	16 SALTIST NERO 4500
S28406U	16 SALTIST NERO 5000
S28706U	16 SALTIST NERO 6500
S28906U	16 SALTIST NERO 8000

S28306U
S28406U
S28706U
S28906U

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
16 SALTIST NERO 4500	S28306U	1	6H368601	DRAG KNOB
16 SALTIST NERO 4500	S28306U	2	6F710001	DRAG RING
16 SALTIST NERO 4500	S28306U	3	6G165602	DRAG RATCHET
16 SALTIST NERO 4500	S28306U	4	6J562101	ATD DRAG WASHER ASS(3pcs pack)
16 SALTIST NERO 4500	S28306U	5	6G165902	DRAG LIP WASHER
16 SALTIST NERO 4500	S28306U	6	6G162702	DRAG DISC WASHER
16 SALTIST NERO 4500	S28306U	7	6E453901	SPOOL BALL BEARING
16 SALTIST NERO 4500	S28306U	8	6J467201	SPOOL ASSEMBLY(2-8)
16 SALTIST NERO 4500	S28306U	9	6G163201	SPOOL O RING
16 SALTIST NERO 4500	S28306U	10	6F137502	SPOOL WASHER
16 SALTIST NERO 4500	S28306U	11	6B747701	SPOOL CLICK LEAF SPRING
16 SALTIST NERO 4500	S28306U	12	6E122301	CLICK HOLDER
16 SALTIST NERO 4500	S28306U	13	6G224101	SPOOL METAL PIN
16 SALTIST NERO 4500	S28306U	14	6G203801	SPOOL METAL
16 SALTIST NERO 4500	S28306U	15	6G270801	ROTOR COVER SCREW
16 SALTIST NERO 4500	S28306U	16	6J322501	ROTOR COVER
16 SALTIST NERO 4500	S28306U	17	6H995201	ROTOR NUT PACKING
16 SALTIST NERO 4500	S28306U	18	6J394101	ROTOR NUT
16 SALTIST NERO 4500	S28306U	19	6G392202	ROTOR PLATE
16 SALTIST NERO 4500	S28306U	20	6J321601	ROTOR
16 SALTIST NERO 4500	S28306U	21	6H503401	ROTOR BRAKE SPRING
16 SALTIST NERO 4500	S28306U	22	6G685401	ROTOR BRAKE WASHER
16 SALTIST NERO 4500	S28306U	23	6H503301	ROTOR BRAKE SHAFT
16 SALTIST NERO 4500	S28306U	24	6J322001	ARM LEVER SPRING HOLDER
16 SALTIST NERO 4500	S28306U	25	6J321901	ARM LEVER SPRING
16 SALTIST NERO 4500	S28306U	26	6J321801	ARM LEVER WASHER
16 SALTIST NERO 4500	S28306U	27	6J321701	ARM LEVER SHAFT
16 SALTIST NERO 4500	S28306U	28	6H945501	ARM LEVER COLLAR
16 SALTIST NERO 4500	S28306U	29	6J309701	ARM LEVER
16 SALTIST NERO 4500	S28306U	30	6G455601	ARM LEVER COVER SCREW
16 SALTIST NERO 4500	S28306U	31	6J322103	ARM LEVER SPRING COVER
16 SALTIST NERO 4500	S28306U	32	6G270801	ROTOR COVER SCREW
16 SALTIST NERO 4500	S28306U	33	6J393602	BAIL ASS
16 SALTIST NERO 4500	S28306U	34	6G455601	BAIL HOLDER SCREW
16 SALTIST NERO 4500	S28306U	35	6J416001	ROLLAR BALL BEARING
16 SALTIST NERO 4500	S28306U	36	6H246103	LINE ROLLER
16 SALTIST NERO 4500	S28306U	37	6J310401	LINE ROLLAR COLLAR
16 SALTIST NERO 4500	S28306U	38	6F608901	LINE ROLLAR SCREW
16 SALTIST NERO 4500	S28306U	39	6J393301	MAGSEALED ASSEMBLY
16 SALTIST NERO 4500	S28306U	40	6J001601	MAGSEALED SCREW
16 SALTIST NERO 4500	S28306U	41	6J212901	MAGSEALED ORING
16 SALTIST NERO 4500	S28306U	42	6J393201	MAGSEALED CAP
16 SALTIST NERO 4500	S28306U	43	6J690401	CLUTCH RING
16 SALTIST NERO 4500	S28306U	44	6J309101	ONEWAY CLUTCH
16 SALTIST NERO 4500	S28306U	45	6J001602	PINION BEARING PLATE SCREW
16 SALTIST NERO 4500	S28306U	46	6J308401	PINION BEARING PLATE
16 SALTIST NERO 4500	S28306U	47	6G426301	PINION BALL BEARING(A)
16 SALTIST NERO 4500	S28306U	48	6G613404	PINION BEARING COLLAR
16 SALTIST NERO 4500	S28306U	49	6E262701	RATCHET
16 SALTIST NERO 4500	S28306U	50	6G613404	PINION BALL BEARING WASHER(A)
16 SALTIST NERO 4500	S28306U	51+68	6Z023041	PINION + DRIVGE GEAR UNIT
16 SALTIST NERO 4500	S28306U	52	6G522706	PINION BALL BEARING (B)
16 SALTIST NERO 4500	S28306U	53	6J320901	PINION BALL BEARING COLLAR
16 SALTIST NERO 4500	S28306U	54	6J461201	BODY ASS
16 SALTIST NERO 4500	S28306U	55	6G162801	MAIN SHAFT PIN
16 SALTIST NERO 4500	S28306U	56	6J421201	MAIN SHAFT
16 SALTIST NERO 4500	S28306U	57	6J320801	OSCILLATING POST
16 SALTIST NERO 4500	S28306U	58	6J321501	REAR CAP
16 SALTIST NERO 4500	S28306U	59	6J001801	REAR CAP SCREW
16 SALTIST NERO 4500	S28306U	60	6H243301	STOPER COLLAR

[illegible]