




16 SALTIST NERO 5000

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S28306U	16 SALTIST NERO 4500
S28406U	16 SALTIST NERO 5000
S28706U	16 SALTIST NERO 6500
S28906U	16 SALTIST NERO 8000

S28306U
S28406U
S28706U
S28906U

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
16 SALTIST NERO 5000	S28406U	1	6H368601	DRAW KNOB
16 SALTIST NERO 5000	S28406U	2	6F710001	DRAW RING
16 SALTIST NERO 5000	S28406U	3	6G165602	DRAW RATCHET
16 SALTIST NERO 5000	S28406U	4	6J562101	ATD DRAW WASHER ASS(3pcs pack)
16 SALTIST NERO 5000	S28406U	5	6G165902	DRAW LIP WASHER
16 SALTIST NERO 5000	S28406U	6	6G162702	DRAW DISC WASHER
16 SALTIST NERO 5000	S28406U	7	6E453901	SPOOL BALL BEARING
16 SALTIST NERO 5000	S28406U	8	6J466201	SPOOL ASSEMBLY(2-8)
16 SALTIST NERO 5000	S28406U	9	6G163201	SPOOL O RING
16 SALTIST NERO 5000	S28406U	10	6F137502	SPOOL WASHER
16 SALTIST NERO 5000	S28406U	11	6B747701	SPOOL CLICK LEAF SPRING
16 SALTIST NERO 5000	S28406U	12	6E122301	CLICK HOLDER
16 SALTIST NERO 5000	S28406U	13	6G224101	SPOOL METAL PIN
16 SALTIST NERO 5000	S28406U	14	6G203801	SPOOL METAL
16 SALTIST NERO 5000	S28406U	15	6G270801	ROTOR COVER SCREW
16 SALTIST NERO 5000	S28406U	16	6J322501	ROTOR COVER
16 SALTIST NERO 5000	S28406U	17	6H995201	ROTOR NUT PACKING
16 SALTIST NERO 5000	S28406U	18	6J394101	ROTOR NUT
16 SALTIST NERO 5000	S28406U	19	6G392202	ROTOR PLATE
16 SALTIST NERO 5000	S28406U	20	6J321601	ROTOR
16 SALTIST NERO 5000	S28406U	21	6H503401	ROTOR BRAKE SPRING
16 SALTIST NERO 5000	S28406U	22	6G685401	ROTOR BRAKE WASHER
16 SALTIST NERO 5000	S28406U	23	6H503301	ROTOR BRAKE SHAFT
16 SALTIST NERO 5000	S28406U	24	6J322001	ARM LEVER SPRING HOLDER
16 SALTIST NERO 5000	S28406U	25	6J321901	ARM LEVER SPRING
16 SALTIST NERO 5000	S28406U	26	6J321801	ARM LEVER WASHER
16 SALTIST NERO 5000	S28406U	27	6J321701	ARM LEVER SHAFT
16 SALTIST NERO 5000	S28406U	28	6H945501	ARM LEVER COLLAR
16 SALTIST NERO 5000	S28406U	29	6J309701	ARM LEVER
16 SALTIST NERO 5000	S28406U	30	6G455601	ARM LEVER COVER SCREW
16 SALTIST NERO 5000	S28406U	31	6J322103	ARM LEVER SPRING COVER
16 SALTIST NERO 5000	S28406U	32	6G270801	ARM LEVER SPRING COVER SCREW
16 SALTIST NERO 5000	S28406U	33	6J393602	BAIL ASS
16 SALTIST NERO 5000	S28406U	34	6G455601	BAIL HOLDER SCREW
16 SALTIST NERO 5000	S28406U	35	6J416001	ROLLAR BALL BEARING
16 SALTIST NERO 5000	S28406U	36	6H246103	LINE ROLLER
16 SALTIST NERO 5000	S28406U	37	6J310401	LINE ROLLAR COLLAR
16 SALTIST NERO 5000	S28406U	38	6F608901	LINE ROLLAR SCREW
16 SALTIST NERO 5000	S28406U	39	6J393301	MAGSEALED ASSEMBLY
16 SALTIST NERO 5000	S28406U	40	6J001601	MAGSEALED SCREW
16 SALTIST NERO 5000	S28406U	41	6J212901	MAGSEALED ORING
16 SALTIST NERO 5000	S28406U	42	6J393201	MAGSEALED CAP
16 SALTIST NERO 5000	S28406U	43	6J690401	CLUTCH RING
16 SALTIST NERO 5000	S28406U	44	6J309101	ONEWAY CLUTCH
16 SALTIST NERO 5000	S28406U	45	6J001602	PINION BEARING PLATE SCREW
16 SALTIST NERO 5000	S28406U	46	6J308401	PINION BEARING PLATE
16 SALTIST NERO 5000	S28406U	47	6G426301	PINION BALL BEARING(A)
16 SALTIST NERO 5000	S28406U	48	6G613404	PINION BEARING COLLAR
16 SALTIST NERO 5000	S28406U	49	6E262701	RATCHET
16 SALTIST NERO 5000	S28406U	50	6G613404	PINION BALL BEARING WASHER(A)
16 SALTIST NERO 5000	S28406U	51+68	6Z023041	PINION + DRIVGE GEAR UNIT
16 SALTIST NERO 5000	S28406U	52	6G522706	PINION BALL BEARING (B)
16 SALTIST NERO 5000	S28406U	53	6J320901	PINION BALL BEARING COLLAR
16 SALTIST NERO 5000	S28406U	54	6J461201	BODY ASS
16 SALTIST NERO 5000	S28406U	55	6G162801	MAIN SHAFT PIN
16 SALTIST NERO 5000	S28406U	56	6J421201	MAIN SHAFT
16 SALTIST NERO 5000	S28406U	57	6J320801	OSCILLATING POST
16 SALTIST NERO 5000	S28406U	58	6J321501	REAR CAP
16 SALTIST NERO 5000	S28406U	59	6J001801	REAR CAP SCREW
16 SALTIST NERO 5000	S28406U	60	6H243301	STOPER COLLAR

[illegible]