




16 SALTIST NERO 8000

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S28306U	16 SALTIST NERO 4500	S28306U
S28406U	16 SALTIST NERO 5000	S28406U
S28706U	16 SALTIST NERO 6500	S28706U
S28906U	16 SALTIST NERO 8000	S28906U

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
16 SALTIST NERO 8000	S28906U	1	6H374601	DRAG KNOB
16 SALTIST NERO 8000	S28906U	2	6F710001	DRAG RING
16 SALTIST NERO 8000	S28906U	3	6G165602	DRAG RATCHET
16 SALTIST NERO 8000	S28906U	4	6J562201	ATD DRAG WASHER ASS(5pcs pack)
16 SALTIST NERO 8000	S28906U	5	6G165902	DRAG LIP WASHER
16 SALTIST NERO 8000	S28906U	6	6G162702	DRAG DISC WASHER
16 SALTIST NERO 8000	S28906U	7	6G156801	SPOOL BALL BEARING
16 SALTIST NERO 8000	S28906U	8	6J466801	SPOOL ASSEMBLY(2-8)
16 SALTIST NERO 8000	S28906U	9	6G339401	SPOOL O RING
16 SALTIST NERO 8000	S28906U	10	6G341501	SPOOL WASHER
16 SALTIST NERO 8000	S28906U	11	6G341401	SPOOL CLICK LEAF SPRING
16 SALTIST NERO 8000	S28906U	12	6G341301	CLICK HOLDER
16 SALTIST NERO 8000	S28906U	13	6G339301	SPOOL METAL PIN
16 SALTIST NERO 8000	S28906U	14	6H378701	SPOOL METAL
16 SALTIST NERO 8000	S28906U	15	6G270801	ROTOR COVER SCREW
16 SALTIST NERO 8000	S28906U	16	6J310601	ROTOR COVER
16 SALTIST NERO 8000	S28906U	17	6J423001	ROTOR NUT PACKING
16 SALTIST NERO 8000	S28906U	18	6J432601	ROTOR NUT
16 SALTIST NERO 8000	S28906U	19	6J316501	ROTOR PLATE
16 SALTIST NERO 8000	S28906U	20	6J309401	ROTOR
16 SALTIST NERO 8000	S28906U	21	6H782801	ROTOR BRAKE SPRING
16 SALTIST NERO 8000	S28906U	22	6E272501	ROTOR BRAKE WASHER
16 SALTIST NERO 8000	S28906U	23	6H684601	ROTOR BRAKE SHAFT
16 SALTIST NERO 8000	S28906U	24	6H684701	ARM LEVER SPRING HOLDER
16 SALTIST NERO 8000	S28906U	25	6G418101	ARM LEVER SPRING
16 SALTIST NERO 8000	S28906U	26	6J309601	ARM LEVER WASHER
16 SALTIST NERO 8000	S28906U	27	6J309501	ARM LEVER SHAFT
16 SALTIST NERO 8000	S28906U	28	6H945501	ARM LEVER COLLAR
16 SALTIST NERO 8000	S28906U	29	6J309701	ARM LEVER
16 SALTIST NERO 8000	S28906U	30	6G455601	ARM LEVER COVER SCREW
16 SALTIST NERO 8000	S28906U	31	6J309802	ARM LEVER SPRING COVER
16 SALTIST NERO 8000	S28906U	32	6G270801	ARM LEVER SPRING COVER SCREW
16 SALTIST NERO 8000	S28906U	33	6J423601	BAIL ASS
16 SALTIST NERO 8000	S28906U	34	6G455601	BAIL HOLDER SCREW
16 SALTIST NERO 8000	S28906U	35	6J416001	ROLLAR BALL BEARING
16 SALTIST NERO 8000	S28906U	36	6H246103	LINE ROLLER
16 SALTIST NERO 8000	S28906U	37	6J310401	LINE ROLLAR COLLAR
16 SALTIST NERO 8000	S28906U	38	6F608901	LINE ROLLAR SCREW
16 SALTIST NERO 8000	S28906U	39	6J393301	MAGSEALED ASSEMBLY
16 SALTIST NERO 8000	S28906U	40	6J001601	MAGSEALED SCREW
16 SALTIST NERO 8000	S28906U	41	6J212901	MAGSEALED ORING
16 SALTIST NERO 8000	S28906U	42	6J393201	MAGSEALED CAP
16 SALTIST NERO 8000	S28906U	43	6J690401	CLUTCH RING
16 SALTIST NERO 8000	S28906U	44	6J309101	ONEWAY CLUTCH
16 SALTIST NERO 8000	S28906U	45	6J001601	PINION BEARING PLATE SCREW
16 SALTIST NERO 8000	S28906U	46	6J308401	PINION BEARING PLATE
16 SALTIST NERO 8000	S28906U	47	6G426301	PINION BALL BEARING(A)
16 SALTIST NERO 8000	S28906U	48	6H243901	PINION BEARING COLLAR
16 SALTIST NERO 8000	S28906U	49	6E262701	RATCHET
16 SALTIST NERO 8000	S28906U	50	6E339701	PINION BALL BEARING WASHER(A)
16 SALTIST NERO 8000	S28906U	51+68	6Z022625	PINION + DRIVGE GEAR UNIT
16 SALTIST NERO 8000	S28906U	52	6B861704	PINION BALL BEARING (B)
16 SALTIST NERO 8000	S28906U	53	6J308101	PINION BALL BEARING COLLAR
16 SALTIST NERO 8000	S28906U	54	6J466401	BODY ASS
16 SALTIST NERO 8000	S28906U	55	6G338901	MAIN SHAFT PIN
16 SALTIST NERO 8000	S28906U	56	6J422501	MAIN SHAFT
16 SALTIST NERO 8000	S28906U	57	6J308001	OSCILLATING POST
16 SALTIST NERO 8000	S28906U	58	6J308901	REAR CAP
16 SALTIST NERO 8000	S28906U	59	6J001801	REAR CAP SCREW
16 SALTIST NERO 8000	S28906U	60	6H243301	STOPER COLLAR

[illegible]