




SALTIST 6500H

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644

SALTIST 5000H/6000H/6500H



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
SALTIST 6500H		1	6H374601	Drag knob
SALTIST 6500H		2	6F710001	Drag washer retainer
SALTIST 6500H		3	6G165602	Drag knob click plate
SALTIST 6500H		4	6H247201	Drag washer
SALTIST 6500H		5	6G165902	Eared washer
SALTIST 6500H		6	6G162702	DRAG DISC WASHER
SALTIST 6500H		8	6G341501	Washer (A)
SALTIST 6500H		9	6G341301	Click leaf spring holder
SALTIST 6500H		10	6G341401	Spool click leaf spring
SALTIST 6500H		11	6G339301	Pin (A)
SALTIST 6500H		12	6H378701	Spool metal
SALTIST 6500H		13	6H428801	Rotor nut
SALTIST 6500H		14	6H050101	Collar (A)
SALTIST 6500H		15	6E492001	Screw (A)
SALTIST 6500H		16	6H324402	Rotor
SALTIST 6500H		17	6H325001	Bail holder nut
SALTIST 6500H		18	6H324801	Plate
SALTIST 6500H		19	63516105	Screw (B)
SALTIST 6500H		20	6H365301	Bail assembly
SALTIST 6500H		21	6H035502	Collar (B)
SALTIST 6500H		22	6H246103	Line roller
SALTIST 6500H		26	6H271201	Collar (C)
SALTIST 6500H		27	6H339602	Bail arm
SALTIST 6500H		28	63521106	Screw (C)
SALTIST 6500H		29	6F608901	Screw (D)
SALTIST 6500H		30	6G337501	Bail spring holder
SALTIST 6500H		31	6G418101	Bail spring
SALTIST 6500H		32	6H324701	Bail spring shaft
SALTIST 6500H		33	6H325401	Bail spring cover
SALTIST 6500H		34	63522510	Screw (E)
SALTIST 6500H		35	6G337601	Rotor brake spring
SALTIST 6500H		36	6H324901	Rotor brake spring cover
SALTIST 6500H		37	63522510	Screw (F)
SALTIST 6500H		38	63516101	Screw (G)
SALTIST 6500H		39	6H244202	Roller clutch retainer
SALTIST 6500H		40	6H244001	Clutch cam retainer
SALTIST 6500H		41	6H247601	Clutch cam
SALTIST 6500H		42	6G314501	Roller clutch
SALTIST 6500H		43	6H172703	Spacing sleeve
SALTIST 6500H		44	6G557101	Screw (H)
SALTIST 6500H		45	6H244501	Bearing retainer (A)
SALTIST 6500H		46	6G472501	Ball bearing (A)
SALTIST 6500H		47	6H243901	Collar (D)
SALTIST 6500H		48	6E262701	Ratchet
SALTIST 6500H		49	6E339701	Washer (D)
SALTIST 6500H		50	6H373901	Pinion gear
SALTIST 6500H		51	6H323501	Collar (E)
SALTIST 6500H		52	6G337101	Brake ring
SALTIST 6500H		53	6H373601	Body assembly
SALTIST 6500H		54	6G338901	Pin (B)
SALTIST 6500H		55	6H437201	Main shaft
SALTIST 6500H		56	6H323101	Oscillating gear (A)
SALTIST 6500H		57	6G157401	Oscillating gear spring
SALTIST 6500H		58	6H323001	Oscillating gear (B)
SALTIST 6500H		59	6G431001	Ball bearing (B)
SALTIST 6500H		60	6H347101	Screw (I)
SALTIST 6500H		61	6H243301	Collar (F)
SALTIST 6500H		62	6H339401	Anti-reverse pawl
SALTIST 6500H		63	63516401	Screw (J)
SALTIST 6500H		64	6H244401	Spring

[illegible]