




SALTIST MQ 3000DXH

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S45403U
S45603U
S45703U

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
SALTIST MQ 3000DXH	S45603U	1	6M084601	DRAW KNOB
SALTIST MQ 3000DXH	S45603U	2	6J547101	DRAW WASHER RETAINER
SALTIST MQ 3000DXH	S45603U	3	6M037701	DRAW KNOB WASHER
SALTIST MQ 3000DXH	S45603U	4	6J547001	KEY WASHER
SALTIST MQ 3000DXH	S45603U	5	6J546803	DRAW WASHER
SALTIST MQ 3000DXH	S45603U	6	6J546902	EARED WASHER
SALTIST MQ 3000DXH	S45603U	7	6J558101	LINE STOPPER PLATE
SALTIST MQ 3000DXH	S45603U	8	6J558001	LINE STOPPER
SALTIST MQ 3000DXH	S45603U	9	6J314801	LINE STOPPER SPRING
SALTIST MQ 3000DXH	S45603U	10	6M174101	SPOOL ASSY
SALTIST MQ 3000DXH	S45603U	11	6M037401	SPOOL BEARING WASHER (A)
SALTIST MQ 3000DXH	S45603U	12	6G469005	SPOOL BALL BEARING (A)
SALTIST MQ 3000DXH	S45603U	13	6B411706	SPOOL BEARING WASHER (B)
SALTIST MQ 3000DXH	S45603U	14	6E398003	SPOOL WASHER (A)
SALTIST MQ 3000DXH	S45603U	15	6E467101	SPOOL WASHER (B)
SALTIST MQ 3000DXH	S45603U	16	6M021401	CLICK HOLDER
SALTIST MQ 3000DXH	S45603U	17	6H416101	CLICK LEAF SPRING
SALTIST MQ 3000DXH	S45603U	18	6J703101	SPOOL WASHER (C)
SALTIST MQ 3000DXH	S45603U	19	6H986901	ROTOR NUT PACKING
SALTIST MQ 3000DXH	S45603U	20	6M181301	ROTOR NUT
SALTIST MQ 3000DXH	S45603U	21	6J808501	ROTOR NUT COLLAR
SALTIST MQ 3000DXH	S45603U	22	6H022701	ROTOR NUT SCREW
SALTIST MQ 3000DXH	S45603U	23	6J257101	ROTOR COVER
SALTIST MQ 3000DXH	S45603U	24	6H022701	ROTOR COVER SCREW
SALTIST MQ 3000DXH	S45603U	25	6J254307	ROTOR
SALTIST MQ 3000DXH	S45603U	26	6J435201	BAIL TRIP LEVER SPRING
SALTIST MQ 3000DXH	S45603U	27	6J339502	BAIL TRIP LEVER WASHER
SALTIST MQ 3000DXH	S45603U	28	6J254401	BAIL TRIP LEVER
SALTIST MQ 3000DXH	S45603U	29	6H417701	BAIL TRIP LEVER SCREW
SALTIST MQ 3000DXH	S45603U	30	6J254601	ARM LEVER SHAFT
SALTIST MQ 3000DXH	S45603U	31	6J254701	ARM LEVER SHAFT HOLDER
SALTIST MQ 3000DXH	S45603U	32	6J255101	ARM LEVER COVER
SALTIST MQ 3000DXH	S45603U	33	6J255201	ARM LEVER COVER SCREW
SALTIST MQ 3000DXH	S45603U	34	6J254812	ARM LEVER
SALTIST MQ 3000DXH	S45603U	35	6J254901	ARM LEVER COLLAR
SALTIST MQ 3000DXH	S45603U	36	6J255001	ARM LEVER SCREW
SALTIST MQ 3000DXH	S45603U	37	6J257001	ROLLER SCREW
SALTIST MQ 3000DXH	S45603U	38	6F897101	ROLLER WASHER
SALTIST MQ 3000DXH	S45603U	39	6M162601	ROLLER COLLAR (A)
SALTIST MQ 3000DXH	S45603U	40	6M162501	ROLLER COLLAR (B)
SALTIST MQ 3000DXH	S45603U	41	6J256502	LINE ROLLER
SALTIST MQ 3000DXH	S45603U	42	6J891101	BAIL
SALTIST MQ 3000DXH	S45603U	43	6J254901	BAIL HOLDER COLLAR
SALTIST MQ 3000DXH	S45603U	44	6J255001	BAIL HOLDER SCREW
SALTIST MQ 3000DXH	S45603U	45	6G471803	BAIL SPRING SHAFT
SALTIST MQ 3000DXH	S45603U	46	6G685401	BAIL SPRING WASHER
SALTIST MQ 3000DXH	S45603U	47	6J255301	BAIL SPRING
SALTIST MQ 3000DXH	S45603U	48	6G471602	BAIL SPRING HOLDER
SALTIST MQ 3000DXH	S45603U	49	6J255901	BAIL SPRING COVER
SALTIST MQ 3000DXH	S45603U	50	6J255201	BAIL SPRING COVER SCREW
SALTIST MQ 3000DXH	S45603U	51	6J777906	MAGSEALED CAP
SALTIST MQ 3000DXH	S45603U	52	6J777601	MAGSEALED PLATE
SALTIST MQ 3000DXH	S45603U	53	6J791001	MADSEALED CAP O RING
SALTIST MQ 3000DXH	S45603U	54	6J777802	MADSEALED COLLAR
SALTIST MQ 3000DXH	S45603U	55	6I639901	ONEWAY CLUTCH WASHER
SALTIST MQ 3000DXH	S45603U	56	6I388402	ONEWAY CLUTCH
SALTIST MQ 3000DXH	S45603U	57	6I536102	CLUTCH RING
SALTIST MQ 3000DXH	S45603U	58	6I536202	CLUTCH RING COLLAR
SALTIST MQ 3000DXH	S45603U	59	6J778201	BEARING PLATE
SALTIST MQ 3000DXH	S45603U	60	6J000901	BEARING PLATE SCREW

