


DAWA SPINNING REEL

SALTIST 4500-8000

Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part Name	Part No.	Part No.	Part No.	Part No.
1	DRAG KNOB	H36-8601	H36-8601	H37-4601	H37-4601
2	DRAG WASHER RET	F71-0001	F71-0001	F71-0001	F71-0001
3	DRAG KNOB CLICK PLATE	G16-5602	G16-5602	G16-5602	G16-5602
4	DRAG WASHER	H24-7205	H24-7205	H24-7205	H24-7205
5	KEY WASHER	G16-2702	G16-2702	G16-2702	G16-2702
6	EARED WASHER	G16-5902	G16-5902	G16-5902	G16-5902
7	BALL BEARING	E45-3902	E45-3902	G15-6803	G15-6803
2-8	SPOOL ASSEMBLY	J42-2001	J42-1801	J42-3301	J42-3101
9	O-RING	G16-3201	G16-3201	G33-9401	G33-9401
10	SPOOL WASHER	F13-7500	F13-7500	G34-1501	G34-1501
10	WASHER	B74-7701	B74-7701	G34-1500	G34-1500
11	CLICK LEAF SPRING	E12-2301	E12-2301	G34-1401	G34-1401
12	CLICK LEAF SPRING HOLDER	G22-4101	G22-4101	G33-9301	G33-9301
13	SPOOL METAL PIN	G20-3801	G20-3801	H37-8701	H37-8701
14	SPOOL METAL	G27-0801	G27-0801	G27-0801	G27-0801
15	SCREW	J32-2501	J32-2501	J31-0601	J31-0601
16	LINGE GUAR PLATE	H99-5201	H99-5201	J42-3001	J42-3001
17	PACKING	J39-4101	J39-4101	J43-2601	J43-2601
18	ROTOR NUT	G39-2202	G39-2202	J31-6501	J31-6501
19	ROTOR NUT PLATE	J32-1601	J32-1601	J30-9401	J30-9401
20	ROTOR	H50-3401	H50-3401	H78-2801	H78-2801
21	BAIL SPRING	G68-5401	G68-5401	E27-2501	E27-2501
22	BAIL SPRING WASHER	H50-3301	H50-3301	H68-4601	H68-4601
23	SHAFT	J32-2001	J32-2001	H68-4701	H68-4701
24	BAIL SPRING HOLDER	J32-1901	J32-1901	G41-8101	G41-8101
25	BAIL SPRING	J32-1801	J32-1801	J30-9601	J30-9601
26	WASHER	J32-1701	J32-1701	J30-9501	J30-9501
27	BAIL SPRING SHAFT	H94-5501	H94-5501	H94-5501	H94-5501
28	COLLAR	J30-9701	J30-9701	J30-9701	J30-9701
29	BAIL ARM	G45-5601	G45-5601	G45-5601	G45-5601
30	BAIL ARM SCREW	J32-2103	J32-2103	J30-9802	J30-9802
31	BAIL SPRING COVER	G27-0801	G27-0801	G27-0801	G27-0801
32	SCREW	J39-3602	J39-3602	J42-3601	J42-3601
33	BAIL	G45-5601	G45-5601	G45-5601	G45-5601
34	BAIL ARM SCREW	J41-6001	J41-6001	J41-6001	J41-6001
35	COLLAR	J42-1501	J42-1501	J42-1501	J42-1501
36	LINE ROLLER	J01-9302	J01-9302	J01-9302	J01-9302
37	BALL BEARING (MS)	J31-0401	J31-0401	J31-0401	J31-0401
38	COLLAR	F60-8901	F60-8901	F60-8901	F60-8901
39	SCREW	J39-3301	J39-3301	J39-3301	J39-3301
40	SEALED CAP	J00-1601	J00-1601	J00-1601	J00-1601
41	SCREW	J21-2901	J21-2901	J21-2901	J21-2901
42	O-RING	J39-3201	J39-3201	J39-3201	J39-3201
43	INFINITE COVER	J39-3001	J39-3001	J39-3001	J39-3001
44	SPACING SLEEVE	J30-9101	J30-9101	J30-9101	J30-9101
45	ROLLET CLUTCH	J00-1602	J00-1602	J00-1601	J00-1601
46	SCREW	J30-8401	J30-8401	J30-8401	J30-8401
47	BEARING RETAINER	G47-2501	G47-2501	G47-2501	G47-2501
48	BALL BEARING	G61-3404	G61-3404	H24-3901	H24-3901
49	WASHER	E26-2701	E26-2701	E26-2701	E26-2701
50	A/R RATCHET	G61-3404	G61-3404	E33-9701	E33-9701
51	WASHER	Z02-3041	Z02-3041	Z02-2625	Z02-2625
52+69	PINION + DRIVE GEAR UNIT	G52-2705	G52-2705	G43-1006	G43-1006
53	BALL BEARING	J32-0901	J32-0901	J30-8101	J30-8101
54	COLLAR	J42-0901	J42-0901	J42-2201	J42-2201
55	BODY	G16-2801	G16-2801	G33-8901	G33-8901
56	PIN	J42-1201	J42-1201	J42-2501	J42-2501
57	MAIN SHAFT	J32-0801	J32-0801	J30-8001	J30-8001
58	STABILIZER BAR	J32-1503	J32-1503	J30-8902	J30-8902
59	REAR COVER	J00-1801	J00-1801	J00-1801	J00-1801
60	SCREW	H24-3301	H24-3301	H24-3301	H24-3301
61	COLLAR	H24-3201	H24-3201	H33-9401	H33-9401
62	A/R PAWL	351-6401	351-6401	351-6401	351-6401
63	SCREW	J30-8601	J30-8601	J30-8601	J30-8601
64	SPRING	J32-0401	J32-0401	J30-7601	J30-7601
65	OSC GEAR	G46-7104	G46-7104	G43-1006	G43-1006
66	BALL BEARING	H27-2201	H27-2201	H34-7101	H34-7101
67	SCREW	J32-1201	J32-1201	J30-8501	J30-8501
68	O-RING	371-2800	371-2800	371-2800	371-2800
70	WASHER	G52-2803	G52-2803	G52-2803	G52-2803
71	BALL BEARING	J42-1401	J42-1401	J42-2701	J42-2701
72	BODY COVER	J42-3501	J42-3501	J42-3501	J42-3501
73	WASHER	351-6416	351-6416	351-6416	351-6416
74	SCREW	J39-6001	J39-6001	J43-2001	J43-2001
75	PACKING	G52-2803	G52-2803	G52-2803	G52-2803
76	BALL BEARING	H04-7201	H04-7201	H04-7201	H04-7201
77	RETAINER	J04-2501	J04-2501	J04-2501	J04-2501
78	O-RING	J39-4902	J39-4902	J39-4902	J39-4902
79	HANDLE SCREW CAP	J42-1601	J42-1601	J42-2801	J42-2801
80	HANDLE ASSEMBLY				