




Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

CONVENTIONAL REEL **SALTIST LD40HSH/LD50HSH**



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	H41-9701	Frame	37	H42-3401	Drag ratchet
2	H48-5901	Click button	38	E48-9001	Drag pawl
3	H42-0301	Click plate	39	H42-3501	Drag pawl retainer
4	H42-0401	Click spring (A)	40	G31-8503	Screw (C)
5	H42-0501	Click pawl	41	H53-0901	Spring (B)
6	F09-4802	Click button washer	42	H53-0801	Pin (A)
7	320-1402	Click pawl retainer	43	H42-3801	Washer (D)
8	H42-0601	Click spring (B)	44	H42-3901	Collar (A)
9	H42-0701	Frame plate	45	351-7801	Screw (D)
10	F50-5703	Screw (A)	46	G47-3704	Screw (E)
11	H43-5502	Spool	47	H49-0901	Drag lever
12	H42-1201	Drive shaft (A)	48	H48-1901	Drag lever plate
13	375-8500	Washer (A)	49	G31-8503	Screw (F)
14	H51-3101	Drag spring washer	50	H42-4501	Pin (B)
15	H42-8701	Ball bearing (A)	51	H42-4601	Pre-set cam (A)
16	G53-6001	Ball bearing (B)	52	171-1001	"O" ring
17	H51-2501	Spring (A)	53	H42-4701	Pre-set cam (B)
18	H42-1601	Drag click cap	54	F03-2401	Click leaf spring
19	G31-8501	Screw (B)	55	170-7701	Ring
20	G32-2701	Drive shaft pin (A)	56	H42-4802	Pre-set drag knob
21	H42-1705	Right side plate	57	H48-4801	Drag knob spring
22	F55-2703	Roller clutch	58	G52-2801	Ball bearing (F)
23	G47-2501	Ball bearing (C)	59	371-2800	Washer(E)
24	H43-5701	Drive shaft (8)	60	H42-5101	Collar (B)
25	372-7608	Washer (B)	61-68	H43-6302	Handle assembly
26	G16-3801	Drive shaft pin (B)	69	H49-1101	Handle nut
27	H49-0701	Drive gear	70	B88-4701	Handle plate
28	H43-5901	Drive shaft	71	354-0801	Handle screw
29	E17-5802	Ball bearing (D)			
30	375-8500	Washer (C)			
31	H49-0801	Pinion gear			
32	H48-2101	Metal			
33	H48-2201	Drag metal			
34	B55-7605	Drag metal screw			
35	H42-3301	Drag plate			
36	G62-6301	Ball bearing (E)			

SALTIST LD50HSH Special parts		
Key No.	Parts No.	Parts Name
1	H42-6801	Frame
11	H43-6602	Spool
12	H42-7201	Drive shaft (A)
21	H42-1706	Right side plate