


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



CONVENTIONAL REEL

SALTIST LW20LCHA·LW30LCHA



Key No.	Parts No.	Parts Name
1	E63-4702	Frame assembly
2	G21-1701	Pin
3	G42-7201	Ball bearing (A)
4	E65-4301	Spool assembly
5	E65-3601	Spool gear
6	320-1402	Retainer (A)
7	E65-7601	Left side plate
8	G21-2402	Washer (A)
9	F95-6702	Washer (B)
10	G42-7701	Ball bearing (B)
11	E61-0502	Washer (C)
12	E63-5201	Click spring retainer
13	E62-4601	Click spring
14	G99-8401	Screw (A)
15	E63-5302	Click button
16	E65-6201	Washer (D)
17	E61-7402	Washer (E)
18	373-1600	Washer (F)
19	E62-4801	Click pawl
20	320-1402	Retainer (B)
21	E65-0601	Idle gear
22	E45-4003	Screw (B)
23	E62-7202	Screw (C)
24	E63-5501	Worm shaft assembly
25	E57-3601	Worm shaft bush
26	E63-5701	Level wind guard
27	E62-9301	Washer (G)
28	320-1402	Retainer (C)
29	E57-3102	Line guide assembly
30	E57-4001	Line guide pawl
31	F95-0200	Washer (H)
32	E57-4102	Pawl cap
33	E63-5802	Stabilizer bar (A)
34	352-0601	Screw (D)
35	E63-5902	Stabilizer bar (B)
36	G27-9601	Ball bearing (C)
37	F73-3501	Washer (I)
38	E63-6001	Drive shaft
39	E62-2601	Drive shaft retainer
40	G21-2901	Screw (E)
41	E65-0701	Yoke plate
42	E65-1201	Collar (A)
43	353-4401	Screw (F)
44	E65-1401	Spring (A)
45	E62-4902	Yoke
46	E62-2801	Pinion gear
47	E61-5101	Washer (J)
48	F93-5201	Spring (B)
49	E65-1501	Anti-reverse ratchet
50	E64-3501	Anti-reverse pawl

Key No.	Parts No.	Parts Name
51	E62-5101	Washer (K)
52	E62-2901	Drive gear
53	E62-3002	Drag washer
54	E62-3101	Key washer (A)
55	E62-3201	Eared washer
56	E62-7301	Key washer (B)
57	E61-0701	Collar (B)
58	E63-6402	Right side plate
59	E63-3301	Handle metal
60	E60-8801	Bushing (A)
61	F03-2201	Bushing retainer
62	B05-5201	"O" ring
63	E65-4401	Clutch lever
64	E62-5401	Collar (C)
65	E62-6701	Clutch cam
66	320-7601	Retainer (D)
67	E62-5501	Spring (C)
68	E63-4301	Screw (G)
69	G52-3403	Ball bearing (D)
70	E60-8901	Washer (L)
71	E25-3501	Spring washer
72	F03-2401	Click leaf spring
73	G58-8601	Click leaf spring holder
74	G69-4201	Washer (M)
75	E65-2001	Star drag
76	E60-5101	Spacing sleeve
77	E65-4501	Handle assembly
78	G22-0305	Handle nut
79	G21-8201	Handle nut screw
80	E61-0902	Cast control cap
81	B17-5503	Spacer (A)
82	375-7501	Spacer (B)
83	E65-7901	Line counter gear
84	E65-4801	Bushing (B)
85	B86-4101	Retainer (E)
86	F54-2401	Counter
87	E65-2501	Counter cover
88	G39-1601	Screw (H)
89	E62-4501	Clamp bolt
90	E62-4401	Rod clamp
91	E62-6101	Clamp nut

SALTIST LW30LCHA SPECIAL PARTS

Key No.	Parts No.	Parts Name
1	E63-7002	Frame assembly
4	E65-4901	Spool assembly
24	E63-7501	Worm shaft assembly
26	E63-7701	Level wind guard
33	E63-7802	Stabilizer bar (A)
35	E63-7902	Stabilizer bar (B)
58	E63-6403	Right side plate