


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



CONVENTIONAL REEL

SALTIST LW40A·LW50A



Key No.	Parts No.	Parts Name
1	E63-1201	Frame assembly
2	G21-1701	Pin
3	G42-7201	Ball bearing (A)
4	E62-7801	Spool assembly
5	E62-8201	Spool gear
6	320-1402	Spool gear retainer
7	E62-8501	Left side plate
8	G27-6300	Bearing washer (A)
9	G21-2401	Bearing washer (B)
10	F95-6702	Bearing washer (C)
11	G42-7701	Ball bearing (B)
12	E61-0501	Bearing washer (D)
13	E62-8601	Click spring retainer
14	E61-0601	Click spring
15	351-7701	Click spring screw
16	E63-4201	Click button
17	E61-7301	Click button washer (A)
18	E61-7401	Click button washer (B)
19	E61-1001	Click pawl
20	373-1600	Click button washer (C)
21	320-1402	Click pawl retainer
22	E62-8701	Idle gear
23	375-3005	Idle gear washer
24	E45-4003	Idle gear screw
25	E62-7202	Left side plate screw
26	E62-9001	Worm shaft assembly
27	E57-3601	Worm shaft bush
28	E62-9401	Level wind guard
29	E62-9301	Worm shaft washer
30	320-7601	Worm shaft retainer
31	E57-3101	Line guide assembly
32	E57-4001	Line guide pawl
33	F95-0200	Line guide washer
34	E57-4101	Pawl cap
35	E62-9901	Stabilizer bar (A)
36	352-0601	Stabilizer bar screw
37	E63-0101	Stabilizer bar (B)
38	F73-3501	Drive shaft washer (A)
39	G27-9601	Ball bearing (C)
40	E63-0201	Drive shaft
41	G60-3602	Drive shaft retainer
42	G21-2901	Drive shaft retainer screw
43	E63-4601	Yoke plate
44	G60-3801	Yoke
45	G45-9701	Pinion gear
46	E61-5101	Yoke washer
47	F93-5201	Yoke spring

Key No.	Parts No.	Parts Name
48	G60-3901	Anti-reverse ratchet
49	E48-9001	Anti-reverse pawl
50	G60-4001	Drive shaft washer (B)
51	E63-0301	Drive gear
52	E63-0401	Drag washer
53	G60-4301	Key washer (A)
54	G60-4401	Eared washer
55	E63-4501	Key washer (B)
56	E61-0701	Collar
57	E63-1501	Right side plate
58	E63-3301	Handle metal
59	E60-8801	Bushing
60	F03-2201	Bushing retainer
61	B05-5201	"O" ring
62	E63-3401	Clutch lever
63	G60-5201	Clutch lever collar
64	E61-7601	Clutch Gam
65	320-7601	Clutch cam retainer
66	E61-1101	Clutch cam spring
67	E63-4301	Right side plate screw
68	G52-3403	Ball bearing (D)
69	E60-8901	Bearing washer (E)
70	E25-3501	Drag spring washer
71	G58-8601	Click leaf spring holder
72	F03-2401	Click leaf spring
73	G69-4201	Washer
74	E63-3701	Star drag
75	E60-5101	Spacing sleeve
76	E63-4101	Handle assembly
77	G22-0301	Handle nut
78	G21-8201	Handle nut screw
79	E61-0901	Cast control cap
80	B17-5503	Spacer (A)
81	375-7501	Spacer (B)
82	E62-4501	Clamp bolt
83	E62-4401	Rod clamp
84	E62-6101	Clamp nut

SALTIST LW50A SPECIAL PARTS

Key No.	Parts No.	Parts Name
1	E63-3001	Frame assembly
4	E63-2001	Spool assembly
26	E63-2301	Worm shaft assembly
28	E63-2501	Level wind guard
35	E63-2601	Stabilizer bar (A)
37	E63-2701	Stabilizer bar (B)
57	E63-3201	Right side plate