


Please order by parts number, not key number  
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



CONVENTIONAL REEL

## SALTIST LW40HA · LW50HA



| Key No | Parts No. | Parts Name                 | Key No. | Parts No. | Parts Name               |
|--------|-----------|----------------------------|---------|-----------|--------------------------|
| 1      | E62-7401  | Frame assembly             | 48      | G60-3901  | Anti-reverse ratchet     |
| 2      | G21-1701  | Pin                        | 49      | E48-9001  | Anti-reverse pawl        |
| 3      | G42-7201  | Ball bearing (A)           | 50      | G60-4001  | Drive shaft washer (B)   |
| 4      | E62-7801  | Spool assembly             | 51      | E61-1401  | Drive gear               |
| 5      | E62-8201  | Spool gear                 | 52      | E63-0401  | Drag washer              |
| 6      | 320-1402  | Spool gear retainer        | 53      | G60-4301  | Key washer (A)           |
| 7      | E62-8501  | Left side plate            | 54      | G60-4401  | Eared washer             |
| 8      | G27-6300  | Bearing washer (A)         | 55      | E63-4501  | Key washer (B)           |
| 9      | G21-2401  | Bearing washer (B)         | 56      | E61-0701  | Collar                   |
| 10     | F95-6702  | Bearing washer (C)         | 57      | E63-0601  | Right side plate         |
| 11     | G42-7701  | Ball bearing (B)           | 58      | E63-3301  | Handle metal             |
| 12     | E61-0501  | Bearing washer (D)         | 59      | E60-8801  | Bushing                  |
| 13     | E62-8601  | Click spring retainer      | 60      | F03-2201  | Bushing retainer         |
| 14     | E61-0601  | Click spring               | 61      | B05-5201  | "O" ring                 |
| 15     | 351-7701  | Click spring screw         | 62      | E63-3401  | Clutch lever             |
| 16     | E63-4201  | Click button               | 63      | G60-5201  | Clutch lever collar      |
| 17     | E61-7301  | Click button washer (A)    | 64      | E61-7601  | Clutch cam               |
| 18     | E61-7401  | Click button washer (B)    | 65      | 320-7601  | Clutch cam retainer      |
| 19     | E61-1001  | Click pawl                 | 66      | E61-1101  | Clutch cam spring        |
| 20     | 373-1600  | Click button washer (C)    | 67      | E63-4301  | Right side plate screw   |
| 21     | 320-1402  | Click pawl retainer        | 68      | G52-3403  | Ball bearing (D)         |
| 22     | E62-8701  | Idle gear                  | 69      | E60-8901  | Bearing washer (E)       |
| 23     | 375-3005  | Idle gear washer           | 70      | E25-3501  | Drag spring washer       |
| 24     | E45-4003  | Idle gear screw            | 71      | G58-8601  | Click leaf spring holder |
| 25     | E62-7202  | Left side plate screw      | 72      | F03-2401  | Click leaf spring        |
| 26     | E62-9001  | Worm shaft assembly        | 73      | G69-4201  | Washer                   |
| 27     | E57-3601  | Worm shaft bush            | 74      | E63-3701  | Star drag                |
| 28     | E62-9401  | Level wind guard           | 75      | E60-5101  | Spacing sleeve           |
| 29     | E62-9301  | Worm shaft washer          | 76      | E63-0801  | Handle assembly          |
| 30     | 320-7601  | Worm shaft retainer        | 77      | G22-0301  | Handle nut               |
| 31     | E57-3101  | Line guide assembly        | 78      | G21-8201  | Handle nut screw         |
| 32     | E57-4001  | Line guide pawl            | 79      | E61-0901  | Cast control cap         |
| 33     | F95-0200  | Line guide washer          | 80      | B17-5503  | Spacer(A)                |
| 34     | E57-4101  | Pawl cap                   | 81      | 375-7501  | Spacer (B)               |
| 35     | E62-9901  | Stabilizer bar (A)         | 82      | E62-4501  | Clamp bolt               |
| 36     | 352-0601  | Stabilizer bar screw       | 83      | E62-4401  | Rod clamp                |
| 37     | E63-0101  | Stabilizer bar (B)         | 84      | E62-6101  | Clamp nut                |
| 38     | F73-3501  | Drive shaft washer (A)     |         |           |                          |
| 39     | G27-9601  | Ball bearing (C)           |         |           |                          |
| 40     | E63-0201  | Drive shaft                |         |           |                          |
| 41     | G60-3602  | Drive shaft retainer       |         |           |                          |
| 42     | G21-2901  | Drive shaft retainer screw |         |           |                          |
| 43     | E63-4601  | Yoke plate                 |         |           |                          |
| 44     | G60-3802  | Yoke                       |         |           |                          |
| 45     | E61-1301  | Pinion gear                |         |           |                          |
| 46     | E61-5101  | Yoke washer                |         |           |                          |
| 47     | F93-5201  | Yoke spring                |         |           |                          |

### SALTIST LW50HA SPECIAL PARTS

| Key No. | Parts No. | Parts Name          |
|---------|-----------|---------------------|
| 1       | E63-1801  | Frame assembly      |
| 4       | E63-2001  | Spool assembly      |
| 26      | E63-2301  | Worm shaft assembly |
| 28      | E63-2501  | Level wind guard    |
| 35      | E63-2601  | Stabilizer bar (A)  |
| 37      | E63-2701  | Stabilizer bar (A)  |
| 57      | E63-2901  | Right side plate    |