


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



CONVENTIONAL REEL

SALTIST LW40LCHA·LW50LCHA



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	E62-7401	Frame assembly	51	E61-1401	Drive gear
2	G21-1701	Pin	52	E63-0401	Drag washer
3	G42-7201	Ball bearing (A)	53	G60-4301	Key washer (A)
4	E65-5001	Spool assembly	54	G60-4401	Eared washer
5	E65-8701	Spool gear	55	E63-1501	Key washer (B)
6	320-1402	Retainer (A)	56	E61-0701	Collar (B)
7	E65-7701	Left side plate	57	E63-0602	Right side plate
8	G27-6300	Washer (O)	58	F63-3301	Roller clutch
9	G21-2401	Washer (A)	59	C60-8801	Bushing (A)
10	F95-6702	Washer (B)	60	F03-2201	Bushing retainer
11	G42-7701	Ball bearing (B)	61	B05-5201	"O" ring
12	E61-0501	Washer (C)	62	E65-5201	Clutch lever
13	E62-8601	Click spring retainer	63	G60-5201	Collar (C)
14	E61-0601	Click spring	64	E61-7601	Clutch cam
15	G99-8401	Screw (A)	65	320-7601	Retainer (D)
16	C63-4202	Click button	66	C61-1101	Spring (C)
17	E61-7301	Washer (D)	67	E63-4301	Screw (G)
18	E61-7401	Washer (E)	68	G52-3403	Ball bearing (D)
19	373-1600	Washer (F)	69	E60-8901	Washer (L)
20	F61-1001	Click pawl	70	F25-3501	Spring washer
21	320-1402	Retainer (B)	71	F03-2401	Click leaf spring
22	E65-3501	Idle gear	72	G58-8601	Click leaf spring holder
23	E45-4003	Screw (B)	73	G69-4201	Washer (M)
24	E62-7202	Screw (C)	74	E65-5301	Star drag
25	E62-9001	Worm shaft assembly	75	E60-5101	Spacing sleeve
26	E57-3601	Worm shaft bush	76	E65-5401	Handle assembly
27	F62-9401	Level wind guard	77	G22-0305	Handle nut
28	C62-9301	Washer (G)	78	G21-8201	Handle nut screw
29	320-7601	Retainer (C)	79	E61-0902	Cast control cap
30	E57-3102	Line guide assembly	80	B17-5503	Spacer (A)
31	E57-4001	Line guide pawl	81	375-7501	Spacer (B)
32	F95-0200	Washer (H)	82	E65-7901	Gear
33	E57-4102	Pawl cap	83	E65-4801	Bushing (B)
34	E62-9902	Stabilizer bar (A)	84	B86-4101	Retainer (E)
35	352-0601	Screw (D)	85	F54-2401	Counter
36	E63-0102	Stabilizer bar (B)	86	E65-2501	Counter cover
37	G27-9601	Ball bearing (C)	87	G39-1601	Screw (H)
38	F73-3501	Washer (I)	88	E62-4501	Clamp bolt
39	F63-0201	Drive shaft	89	F62-4401	Rod clamp
40	G60-3602	Drive shaft retainer	90	C62-6101	Clamp nut
41	G21-2901	Screw (E)			
42	E65-3601	Yoke plate			
43	E65-5501	Spring (A)			
44	G60-3802	Yoke			
45	E61-1301	Pinion gear			
46	E61-5101	Washer (J)			
47	F93-5201	Spring (B)			
48	E65-4001	Anti-reverse ratchet			
49	E64-3501	Anti-reverse pawl			
50	G60-4001	Washer (K)			

SALTIST LW50LCHA SPECIAL PARTS

Key No.	Parts No.	Parts Name
1	E63-1801	Frame assembly
4	E65-5801	Spool assembly
25	E63-2301	Worm shaft assembly
27	E63-2501	Level wind guard
34	E63-2602	Stabilizer bar (A)
36	E63-2702	Stabilizer bar (B)
57	E63-0604	Right side plate