


Please order by parts number, not key number  
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



## CONVENTIONAL REEL SG27LC3B/27LC3BW/47LC3B/17LC3B



| KEY NO. | PART NAME               | SG27LC3B<br>PART NO. | SG27LC3BW<br>PART NO. | SG47LC3B<br>PART NO. | SG17LC3B<br>PART NO. |
|---------|-------------------------|----------------------|-----------------------|----------------------|----------------------|
| 2       | CLICK BUTTON            | F09-3711             | F09-3711              | F09-3711             | E57-7105             |
| 3       | LEFT SIDE PLATE SCREW   | B21-6602             | B21-6602              | B21-6602             | E57-7501             |
| 4       | LEFT SIDE OUTER RING    | G90-3501             | G90-3501              | G90-3501             | E73-6202             |
| 5       | CLICK PAWL              | F09-3903             | F09-3903              | F09-3903             | E67-8503             |
| 6       | WASHER(A)               | 030-6611             | 030-6611              | 030-6611             | E47-9901             |
| 7       | CLICK PAWL RETAINER     | 373-1600             | 373-1600              | 373-1600             | 373-1600             |
| 8       | IDLE GEAR               | 320-1402             | 320-1402              | 320-1402             | 320-1402             |
| 9       | IDLE GEAR COLLAR        | B21-5801             | B21-5801              | B21-5801             | E67-7601             |
| 10      | IDLE GEAR SCREW         | B66-6201             | B66-6201              | B66-6201             | B66-6201             |
| 11      | WASHER(B)               | E10-7401             | E10-7401              | E10-7401             | E10-7401             |
| 12      | BALL BEARING(A)         | 375-7405             | 375-7405              | 375-7405             | 375-7405             |
| 13      | CLICK SPRING            | G37-2102             | G37-2102              | G37-2102             | E57-7201             |
| 14      | CLICK SPRING RETAINER   | 150-7922             | 150-7922              | 150-7922             | E67-7401             |
| 15      | CLICK SPRING SCREW      | B21-5501             | B21-5501              | B21-5501             | E67-7301             |
| 16      | SPOOL GEAR RETAINER     | B53-4402             | B53-4402              | B53-4402             | B53-4402             |
| 17      | SPOOL GEAR              | 320-8002             | 320-8002              | 320-8002             | E67-8201             |
| 18      | WASHER(C)               | 403-2901             | 403-2901              | 403-2901             | E57-8401             |
| 19      | CLICK SPRING WASHER     | E15-4801             | E15-4801              | E15-4801             | E57-8301             |
| 20      | CLICK GEAR              | E36-1402             | E36-1402              | E36-1402             | E57-8201             |
| 21      | SPOOL                   | B21-6701             | B21-6701              | B21-6701             | E57-8101             |
| 22      | BUSHING(B)              | E67-2901             | E67-2901              | E67-2901             | E67-4001             |
| 23      | BUSHING RETAINER        | G38-7401             | G38-7401              | G38-7401             | E57-3001             |
| 24      | BALL BEARING            | B27-0501             | B27-0501              | B27-0501             | E57-2901             |
| 25      | FRAME ASSEMBLY          | E15-2801             | E15-2801              | E15-2801             | E67-3401             |
| 26      | STABILIZER BAR          | E67-2301             | E67-2301              | E67-2301             | F09-3001             |
| 27      | STABILIZER BAR RETAINER | F09-3001             | F09-3001              | F09-3001             | F09-3001             |
| 28      | WORM SHAFT ASSEMBLY     | 320-5901             | 320-5901              | 320-5901             | 320-5901             |
| 29      | WORM SHAFT HOLDER(A)    | F09-2501             | F09-2501              | F09-2501             | F09-2501             |
| 30      | LEVEL WIND GUARD        | E14-4801             | E14-4801              | E14-4801             | E673-601             |
| 31      | LINE CLAMP              | F09-2801             | F09-2801              | F09-2801             | E67-1101             |
| 32      | WORM SHAFT HOLDER(B)    | E36-2401             | E36-2401              | E36-2401             | E67-1001             |
| 33      | COUNTER GEAR(A)         | E14-4801             | E14-4801              | E14-4801             | E57-3601             |
| 34      | WORM SHAFT HOLDER W/    | F09-2901             | F09-2901              | F09-2901             | E57-3801             |
| 35      | WORM SHAFT RETAINER     | B41-1702             | B41-1702              | B41-1702             | E67-3001             |
| 36      | LINE GUIDE PAWL         | 320-5901             | 320-5901              | 320-5901             | 320-5901             |
| 37      | LINE GUIDE WASHER       | 122-0501             | 122-0501              | 122-0501             | E57-4001             |
| 38      | PAWL CAP                | F95-0200             | F95-0200              | F95-0200             | E67-4001             |
| 39      | ANTI-REVERSE PAWL PIN   | E35-4101             | E35-4101              | E35-4101             | E57-4101             |
| 40      | ANTI-REVERSE PAWL SPR   | E25-2301             | E25-2301              | E25-2301             | E57-5001             |
| 41      | ANTI-REVERSE PAWL SPR   | B62-6801             | B62-6801              | B62-6801             | E67-6801             |
| 42      | PINION GEAR             | E23-4201             | E23-4201              | E23-4201             | E57-5201             |
| 43      | YOKE                    | F13-5401             | F13-5401              | F13-5401             | E57-4801             |
| 44      | YOKE WASHER             | F09-3101             | F09-3101              | F09-3101             | E57-4401             |
| 45      | YOKE SPRING             | E25-9101             | E25-9101              | E25-9101             | E57-4401             |
| 46      | COUNTER ASSEMBLY        | E03-7706             | E03-7706              | E03-7706             | E57-4501             |
| 47      | COUNTER PLATE           | F33-5301             | F33-5301              | F33-5301             | E67-6801             |
| 48      | COUNTER WASHER          | F09-2101             | F09-2101              | F09-2101             | E57-1801             |
| 49      | COUNTER SCREW           | E24-1801             | E24-1801              | E24-1801             | E57-1801             |
| 50      | COUNTER GEAR(B)         | 373-1300             | 373-1300              | 373-1300             | 373-1300             |
| 51      | COUNTER GEAR COLLAR     | E31-6701             | E31-6701              | E31-6701             | E31-6701             |
| 52      | COUNTER GEAR SCREW      | E24-1901             | E24-1901              | E24-1901             | E57-2101             |
| 53      | COUNTER GEAR(C)         | B66-6201             | B66-6201              | B66-6201             | E57-2101             |
| 54      | RIGHT TENSION SPRING    | E10-7401             | E10-7401              | E10-7401             | E57-3201             |
| 55      | WASHER(D)               | F09-2201             | F09-2201              | F09-2201             | E67-3201             |
| 56      | CAST CONTROL CAP        | E67-2201             | E67-2201              | E67-2201             | B93-9601             |
| 57      | CLUTCH SPRING           | B93-9601             | B93-9601              | B93-9601             | 375-7405             |
| 58      | CLUTCH CAM              | 375-7405             | 375-7405              | 375-7405             | B93-9702             |
| 59      | CLUTCH LEVER            | E32-2301             | E32-2301              | E32-2301             | E57-1301             |
| 60      | CLUTCH LEVER LOCK WAS   | F09-2001             | F09-2001              | F09-2001             | E57-1401             |
| 61      | CLUTCH LEVER SCREW      | E42-3805             | E42-3805              | E42-3805             | E57-1401             |
| 62      | RIGHT SIDE PLATE SCREW  | 160-8001             | 160-8001              | 160-8001             | E57-1401             |
| 63      | RIGHT SIDE PLATE SCREW  | E00-7802             | E00-7802              | E00-7802             | 160-8001             |
| 64      | RIGHT SIDE PLATE SCREW  | F09-3601             | F09-3601              | F09-3601             | E00-7802             |
| 65      | RIGHT SIDE PLATE SCREW  | B00-9702             | B00-9702              | B00-9702             | F09-3601             |
| 66      | DRIVE SHAFT RETAINER    | E11-0601             | E11-0601              | E11-0601             | F73-6202             |
| 67      | DRIVE SHAFT WASHER(A)   | 320-7602             | 320-7602              | 320-7602             | B00-8602             |
| 68      | DRIVE SHAFT WASHER(B)   | 375-5805             | 375-5805              | 375-5805             | G35-2302             |
| 69      | DRIVE SHAFT WASHER(C)   | E25-2501             | E25-2501              | E25-2501             | -                    |
| 70      | DRIVE SHAFT WASHER(D)   | -                    | -                     | -                    | E57-5501             |
| 71      | DRIVE SHAFT WASHER(E)   | -                    | -                     | -                    | E57-5601             |
| 72      | DRIVE SHAFT WASHER(F)   | -                    | -                     | -                    | E57-5601             |
| 73      | DRIVE SHAFT WASHER(G)   | -                    | -                     | -                    | E57-5601             |
| 74      | DRIVE SHAFT WASHER(H)   | -                    | -                     | -                    | E57-5601             |
| 75      | DRIVE SHAFT WASHER(I)   | -                    | -                     | -                    | E57-5601             |
| 76      | DRIVE SHAFT WASHER(J)   | -                    | -                     | -                    | E57-5601             |
| 77      | DRIVE SHAFT WASHER(K)   | -                    | -                     | -                    | E57-5601             |
| 78      | DRIVE SHAFT WASHER(L)   | -                    | -                     | -                    | E57-5601             |
| 79      | DRIVE SHAFT WASHER(M)   | -                    | -                     | -                    | E57-5601             |
| 80      | DRIVE SHAFT WASHER(N)   | -                    | -                     | -                    | E57-5601             |
| 81      | DRIVE SHAFT WASHER(O)   | -                    | -                     | -                    | E57-5601             |
| 82      | DRIVE SHAFT WASHER(P)   | -                    | -                     | -                    | E57-5601             |
| 83      | DRIVE SHAFT WASHER(Q)   | -                    | -                     | -                    | E57-5601             |
| 84      | DRIVE SHAFT WASHER(R)   | -                    | -                     | -                    | E57-5601             |
| 85      | DRIVE SHAFT WASHER(S)   | -                    | -                     | -                    | E57-5601             |
| 86      | DRIVE SHAFT WASHER(T)   | -                    | -                     | -                    | E57-5601             |
| 87      | DRIVE SHAFT WASHER(U)   | -                    | -                     | -                    | E57-5601             |
| 88      | DRIVE SHAFT WASHER(V)   | -                    | -                     | -                    | E57-5601             |
| 89      | DRIVE SHAFT WASHER(W)   | -                    | -                     | -                    | E57-5601             |
| 90      | DRIVE SHAFT WASHER(X)   | -                    | -                     | -                    | E57-5601             |
| 91      | DRIVE SHAFT WASHER(Y)   | -                    | -                     | -                    | E57-5601             |
| 92      | DRIVE SHAFT WASHER(Z)   | -                    | -                     | -                    | E57-5601             |
| 93      | DRIVE SHAFT WASHER(A)   | -                    | -                     | -                    | E57-5601             |
| 94      | DRIVE SHAFT WASHER(B)   | -                    | -                     | -                    | E57-5601             |
| 95      | DRIVE SHAFT WASHER(C)   | -                    | -                     | -                    | E57-5601             |