


SEALINE-4550BR / 5050BR



Key No.	Parts No.	Parts Name
1	G29-0601	SPOOL
1	F72-5203	SPOOL (EXTRA)
2	L00-3402	SPOOL WASHER
3	E81-0001	MAIN SHAFT PLT
4	F72-2701	MAIN SHAFT
5	L01-1702	ROTOR NUT HOLD PLT SCREW
6	B02-1601	ROTOR NUT HOLD PLT
7	340-8301	ROTOR NUT
8	F71-2502	ROTOR
9	F60-7302	LINE ROLLER SCREW
10	F71-2701	BAIL ARM
11	F44-6302	LINE ROLLER COLLAR
12	F44-6202	LINE ROLLER WASHER
13	F05-5601	BALL BEARING A
14	F45-4902	LINE ROLLER
15	F72-3702	BAIL
16	E00-7601	BAIL ARM SCREW
17	E81-1001	BAIL HOLDER COVER SCREW
18	F71-2801	BAIL SPRING COVER
19	F71-2901	BAIL HOLDER COVER
20	F72-3401	BAIL SPRING SHAFT
21	F72-3601	BAIL SPRING
22	E80-8901	BAIL SPRING HOLDER
23	E80-0802	BAIL TRIP LEVER SCREW
24	F71-2601	BAIL TRIP LEVER
25	F72-3301	BAIL TRIP LEVER SPRING
26	F71-1801	ROLLER CLUTCH WASHER
27	F72-2601	ROLLER CLUTCH
28	F70-9801	SPACING SLEEVE
29	F71-1701	BEARING RET WASHER
30	E80-0802	BEARING RET SCREW
31	F71-1601	BEARING RET
32	637-6101	BALL BEARING B
33	F72-2501	PINION GEAR
34	F75-4101	A/R PAWL SCREW
35	F54-2101	A/R PAWL
36	F72-1701	A/R PAWL SPRING
37	E80-0502	A/R LEVER SCREW
38	E80-0401	A/R LEVER
39	E80-0601	A/R CAM
40	E80-0701	A/R CAM SPRING
41	G29-0301	BODY
42	L00-9108	HANDLE SCREW
43	F73-1601	HANDLE COLLAR
44	G29-0501	HANDLE
45	E52-9701	CLUTCH LEVER SCREW A
46	E80-4301	CLUTCH LEVER WASHER
47	E80-3907	CLUTCH LEVER A
48	E80-4107	CLUTCH LEVER BRIDGE
49	E80-4006	CLUTCH LEVER B
50	B83-5001	SIDE COVER SCREW A
51	E80-3201	SIDE COVER SCREW B

Key No.	Parts No.	Parts Name
52	G29-0401	SIDE COVER
53	320-1402	YOKE PLT STOPPER RET
54	E85-0502	YOKE PLT STOPPER
55	B54-6001	BALL BEARING C
56	371-2824	DRIVE GEAR WASHER
60	F71-2202	DRIVE GEAR
61	E80-5401	TENSION CONTROL RET
62	E80-4903	TENSION CONTROL DIAL
63	E52-9800	TENSION CONTROL WASHER
64	E80-5101	CLICK LEAF SPRING
65	E80-5301	TENSION SPRING
66	E80-5201	TENSION CONTROL SHOE
67	F71-2101	OSC SLIDER RET
68	F72-2901	OSC SLIDER WASHER
69	F72-2801	OSC PAWL
70	F71-2001	OSC PAWL COLLAR
71	F71-1301	OSC SLIDER
72	F71-1501	WORM SHAFT RET
73	F95-8101	WORM SHAFT
74	F71-1201	WORM SHAFT COLLAR
76	F72-2400	WORM SHAFT WASHER
77	F71-1101	WORM SHAFT BUSH
78	F71-1001	CLUTCH TRIP LEVER
79	E80-3501	CLUTCH TRIP LEVER SPRING
80	E80-3401	CLUTCH TRIP LEVER COLLAR
81	F72-4901	CLUTCH TRIP LEVER PIN
82	F72-2201	YOKE PLT PIN
83	E80-4702	YOKE PLT SPRING
84	F72-2101	YOKE
85	E80-3702	CLUTCH CAM
86	F72-2001	CLUTCH CAM SPRING
87	F71-0801	YOKE PLT
88	E80-5502	CLUTCH METAL A
89	E80-5602	CLICK GEAR
90	E80-6701	DRAG KNOB SCREW
91	F71-0702	DRAG KNOB
92	F72-1901	DRAG WASHER RET
93	F75-4201	DRAG COLLAR
94	F72-1801	DRAG COIL SPRING
95	F71-0601	KEY WASHER
96	F71-0501	DRAG WASHER
97	F71-0401	EARED WASHER
98	E80-5901	CLUTCH METAL WASHER
99	E80-5701	CLUTCH METAL B
100	E80-5801	CLICK GEAR WASHER
101	E80-4201	CLUTCH LEVER SCREW B

SL5050BR SPECIAL PARTS

Key No.	Parts No.	Parts Name
1	G29-0701	SPOOL
1	F72-5403	SPOOL (EXTRA)