


SEALINE LW50H/LW60H



Key No.	Part No.	Part Name
1	230-2540	LEFT SIDE PLATE
2	330-2860	CLICK BUTTON
3	460-5270	LEFT SIDE PLATE SCREW
5	190-1140	CLICK PAWL
6	540-4170	WASHER (A)
7	200-0580	CLICK PAWL RET
8	240-2890	IDLE GEAR
9	460-2150	IDLE GEAR SCREW
10	540-3200	WASHER (B)
11	150-1350	BALL BEARING
12	510-5120	CLICK SPRING
13	410-3040	CLICK SPRING RET
14	460-2260	CLICK SPRING SCREW
15	200-0870	SPOOL GEAR RET
16	240-2230	SPOOL GEAR
17	540-5580	WASHER "C"
18	540-5570	CLICK SPRING WASHER
19	240-2850	CLICK GEAR
20	700-9650	SPOOL ASSEMBLY
21	700-0750	FRAME ASSEMBLY
22	400-2710	STABILIZER BAR
23	200-0570	STABILIZER BAR RET
24	470-2070	WORM SHAFT
25	150-1790	WORM SHAFT HOLDER
26	270-0850	LEVEL WIND GUARD
27	490-1090	LINE GUIDE
28	150-1790	WORM SHAFT HOLDER
29	200-0590	WORM SHAFT RET
30	400-2580	LINE GUIDE PAWL
31	540-3980	LINE GUIDE WASHER
32	380-1740	PAWL CAP
33	400-2560	A/R PAWL PIN
34	410-3050	YOKE PLATE
35	410-3030	YOKE
36	540-5480	YOKE WASHER
37	510-4560	YOKE SPRING
38	510-5350	CLUTCH SPRING
39	170-1340	CLUTCH CAM
40	260-1960	PINION GEAR
41	530-0790	A/R PAWL
42	230-2531	RIGHT SIDE COVER
43	150-3060	BUSHING
44	430-1060	RET
45	430-1000	O-RING

Key No.	Part No.	Part Name
46	540-6460	WASHER
47	540-5980	WASHER (D)
48	380-1890	CAST CONTROL CAP
49	330-2750	CLUTCH LEVER
50	540-5440	CLUTCH LEVER WASHER
51	460-4330	CLUTCH LEVER SCREW
53	460-7030	RIGHT SIDE PLATE SCREW
54	200-0590	DRIVE SHAFT RET
55	540-6980	DRIVE SHAFT WASHER
56	150-1760	DRIVE SHAFT BUSHING
57	470-3180	DRIVE SHAFT
58	240-2540	A/R RATCHET
59	540-7110	DRIVE SHAFT WASHER
60	250-1520	DRIVE GEAR
61	540-7080	DRAG WASHER
62	540-6180	KEY WASHER
63	540-6190	EARDE WASHER
64	540-6580	WASHER
65	150-2250	COLLAR
66	140-1890	ROLLER CLUTCH
69	540-7210	WASHER (E)
70	210-0750	SPACING SLEEVE
71	150-1820	BUSHING
74	510-4590	DRAG SPRING WASHER
76	320-1180	STAR DRAG
77	210-0990	SPACING SLEEVE
78	700-8510	HANDLE ASSEMBLY
79	380-1441	HANDLE NUT
80	460-4790	HANDLE NUT PLATE SCREW

SEALINE LW60H SPECIAL PARTS

Key No.	Part No.	Part Name
1	230-2620	LEFT SIDE PLATE
8	240-2900	IDLE GEAR
20	700-9270	SPOOL ASSEMBLY
21	700-0810	FRAME ASSEMBLY
22	400-2730	STABILIZER BAR
24	470-2080	WORM SHAFT ASSEMBLY
26	700-0890	LEVEL WIND GUARD
34	410-3060	YOKE PLATE
42	230-2611	RIGHT SIDE COVER
67	400-2730	STABILIZER BAR
68	200-0570	RET