




STEEZ A TW 1016HL

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



B33301J	STEEZ A TW 1016HL
B33302J	STEEZ A TW 1016SHL
B33303J	STEEZ A TW 1016XHL
B33304J	STEEZ A TW 1016L-CC

B33301J
B33302J
B33303J
B33304J

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
STEEZ A TW 1016HL		1	6J444501	RS PLATE
STEEZ A TW 1016HL		2	6J631901	LEVER PLATE SPRING
STEEZ A TW 1016HL		3	6J286301	LEVER PLATE PIN
STEEZ A TW 1016HL		4	6J444901	LEVER PLATE (A)
STEEZ A TW 1016HL		5	6J286101	LEVER PLATE (B)
STEEZ A TW 1016HL		6	6G940402	BRAKE DIAL SCREW
STEEZ A TW 1016HL		7	6H159201	BRAKE DIAL WASHER
STEEZ A TW 1016HL		8	6J282602	BRAKE DIAL
STEEZ A TW 1016HL		9	6H663401	BRAKE DIAL LEAF SPRING
STEEZ A TW 1016HL		10	6J444701	SET PLATE ASS
STEEZ A TW 1016HL		11	6J296701	MAG HOLDER
STEEZ A TW 1016HL		12	6H666002	SET PLATE SCREW
STEEZ A TW 1016HL		13	6J315701	MAG HOLDER RING
STEEZ A TW 1016HL		14	63757404	RS BEARING WASHER(A)
STEEZ A TW 1016HL		15	63757411	RS BEARING WASHER(B)
STEEZ A TW 1016HL		16	6G185101	RS BEARING WASHER(C)
STEEZ A TW 1016HL		17	6G511506	RS BALL BEARING
STEEZ A TW 1016HL		18	6F032201	RS BEARING RING
STEEZ A TW 1016HL		19	63208202	SPOOL HOLDER SPRING RETAINER
STEEZ A TW 1016HL		20	6G150301	SPOOL HOLDER SPRING WASHER
STEEZ A TW 1016HL		21	6H537301	SPOOL HOLDER SPRING
STEEZ A TW 1016HL		22	6H167801	SPOOL HOLDER
STEEZ A TW 1016HL		23	6H454901	SPOOL HOLDER COLLAR
STEEZ A TW 1016HL		24	6F574303	SPOOL HOLDER WASHER
STEEZ A TW 1016HL		25	6Z023246	SPOOL ASSEMBLY (19-28)
STEEZ A TW 1016HL		26	6H665301	SPOOL HOLDER PIN
STEEZ A TW 1016HL		27	6J252301	SPOOL PIN
STEEZ A TW 1016HL		28	6G498511	SPOOL BALL BEARING
STEEZ A TW 1016HL		29	6J444001	FRAME
STEEZ A TW 1016HL		30	6J281802	FRONT COVER
STEEZ A TW 1016HL		31	6H531508	FRONT COVER SCREW
STEEZ A TW 1016HL		32	6J442301	CLUTCH LEVER
STEEZ A TW 1016HL		33	6J442101	CLUTCH LEVER PLATE(R)
STEEZ A TW 1016HL		34	6J442201	CLUTCH LEVER PLATE(L)
STEEZ A TW 1016HL		35	6J281902	O/C POST
STEEZ A TW 1016HL		36	6H704101	O/C POST RETAINER
STEEZ A TW 1016HL		37	6G431002	CLUTCH CAM BALL BEARING
STEEZ A TW 1016HL		38	6H266601	CLUTCH CAM BEARING COLLAR
STEEZ A TW 1016HL		39	6J333601	KICK LEVER PLATE(A)
STEEZ A TW 1016HL		40	6H531508	KICK LEVER PLATE SCREW
STEEZ A TW 1016HL		41	6J407801	KICK LEVER PLATE SPRING
STEEZ A TW 1016HL		42	6J333701	KICK LEVER
STEEZ A TW 1016HL		43	6J333501	CLUTCH CAM PLATE
STEEZ A TW 1016HL		44	6H928801	CLUTCH CAM PLATE SPRING
STEEZ A TW 1016HL		45	6J055201	CLUTCH CAM PLATE PIN
STEEZ A TW 1016HL		46	6J333001	CLUTCH CAM
STEEZ A TW 1016HL		47	6H159201	CLUTCH CAM PLATE WASHER(A)
STEEZ A TW 1016HL		48	63522510	CLUTCH CAM PLATE SCREW
STEEZ A TW 1016HL		49	6H659101	KICK LEVER PLATE (B)
STEEZ A TW 1016HL		50	6B032904	KICK LEVER PLATE (B) SCREW
STEEZ A TW 1016HL		51	6H944401	CLUTCH PLATE
STEEZ A TW 1016HL		52	6J313901	CLUTCH SPRING
STEEZ A TW 1016HL		53	6Z023302	PINION + DRIVE GEAR UNIT
STEEZ A TW 1016HL		54	6H448401	PINION RING
STEEZ A TW 1016HL		55	6J073501	PINION BEARING WASHER
STEEZ A TW 1016HL		56	6J019301	PINION BALL BEARING
STEEZ A TW 1016HL		57	6H159502	PINION BEARIG COLLAR
STEEZ A TW 1016HL		58	6H440201	CLUTCH CAM SP COVER PLATE
STEEZ A TW 1016HL		59	6J443801	LS PLATE
STEEZ A TW 1016HL		60	6J279701	MECHANICAL BRAKE O RING

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
STEEZ A TW 1016HL		61	6J198801	PINION SHAFT
STEEZ A TW 1016HL		62	6H161001	MECHANICAL BRAKE WASHER(A)
STEEZ A TW 1016HL		63	6B175503	MECHANICAL BRAKE WASHER(B)
STEEZ A TW 1016HL		64	6J279602	MECHANICAL BRAKE KNOB
STEEZ A TW 1016HL		65	6G040822	LS PLATE SCREW
STEEZ A TW 1016HL		66	63205901	WORM SHAFT RETAINER
STEEZ A TW 1016HL		67	6B411702	WORM SHAFT WASHER
STEEZ A TW 1016HL		68	6G469001	WORM SHAFT BEARING
STEEZ A TW 1016HL		69	6J442501	LEVEL WIND
STEEZ A TW 1016HL		70	61214212	PAWL
STEEZ A TW 1016HL		71	63731303	PAWL WASHER
STEEZ A TW 1016HL		72	6F402801	PAWL HOLDER NUT
STEEZ A TW 1016HL		73	6J333801	WORM SHIELD
STEEZ A TW 1016HL		74	6J243601	WORM SHAFT
STEEZ A TW 1016HL		75	6G469001	WORM SHAFT BEARING
STEEZ A TW 1016HL		76	6J281401	WORM SHAFT GEAR
STEEZ A TW 1016HL		77	6B339801	WORM SHAFT GEAR RETAINER
STEEZ A TW 1016HL		78	6G099801	GEAR SHAFT WASHER
STEEZ A TW 1016HL		79	63208002	GEAR SHAFT RETAINER
STEEZ A TW 1016HL		80	6G466201	GEAR SHAFT BALL BEARING
STEEZ A TW 1016HL		81	6J281101	GEAR SHAFT PLATE(A)
STEEZ A TW 1016HL		82	6E134509	GEAR SHAFT PLATE SCREW
STEEZ A TW 1016HL		83	6J281001	WORM GEAR
STEEZ A TW 1016HL		84	6J442402	GEAR SHAFT
STEEZ A TW 1016HL		85	6F657801	GEAR SHAFT O RING
STEEZ A TW 1016HL		86	6H660901	RATCHET
STEEZ A TW 1016HL		87	6H661101	RATCHET WASHER
STEEZ A TW 1016HL		88	6H661001	DRIVE GEAR WASHER
STEEZ A TW 1016HL		89	6Z023302	PINION + DRIVE GEAR UNT
STEEZ A TW 1016HL		90	6H359001	DRAG WASHER
STEEZ A TW 1016HL		91	6J443001	DRIVE COLLAR
STEEZ A TW 1016HL		92	6J410801	DRIVE COLLAR PIN SPRING
STEEZ A TW 1016HL		93	6J566201	DRIVE COLLAR PIN
STEEZ A TW 1016HL		94	6J458101	DRIVE COLLAR O RING
STEEZ A TW 1016HL		95	6G011401	DRAG COLLAR
STEEZ A TW 1016HL		96	6G819801	ONEWAY CLUTCH
STEEZ A TW 1016HL		97	6G431002	HANDLE BALL BEARING
STEEZ A TW 1016HL		98	6B553801	HANDLE BEARING WASHER
STEEZ A TW 1016HL		99	6F028203	DRAG HOLDER
STEEZ A TW 1016HL		100	6F032401	DRAG HOLDER LEAF SPRING
STEEZ A TW 1016HL		101	61508901	DRAG SP WASHER
STEEZ A TW 1016HL		102	6H929501	STAR DRAG WASHER
STEEZ A TW 1016HL		103	6J141002	DRAG NUT
STEEZ A TW 1016HL		104	6J011901	DRAG NUT SPRING
STEEZ A TW 1016HL		105	6J140004	STAR DRAG
STEEZ A TW 1016HL		106	6F576601	HANDLE WASHER
STEEZ A TW 1016HL		107	6J458201	HANDLE
STEEZ A TW 1016HL		108	6J295502	HANDLE SCREW
STEEZ A TW 1016HL		109	6H834508	HANDLE LOCK PLATE
STEEZ A TW 1016HL		110	6G835501	HANDLE LOCK PLATE SCREW
STEEZ A TW 1016HL		200	6B411703	HANDLE KNOB WASHER
STEEZ A TW 1016HL		201	6H929801	HANDLE KNOB
STEEZ A TW 1016HL		202	6G720001	HANDLE KNOB COLLAR
STEEZ A TW 1016HL		203	6B679308	HANDLE KNOB SCREW
STEEZ A TW 1016HL		204	6G935805	HANDLE KNOB CAP