


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



BAITCASTING REEL

STEEZ EX 100XS/100HS/100H



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	H87-4801	L/S PLATE	69	320-5901	RETAINER
2	F57-7902	SCREW	70	G75-5203	WASHER
3	E16-7101	SPRING	71	G46-6202	BALL BEARING
4	F77-0709	WASHER	72	H14-7201	PLATE
5	G75-7401	DIAL	73	E13-4503	SCREW
6	B33-9801	RETAINER	74	G87-5801	SCREW
7	F63-7701	COLLAR	75	H25-6701	SPRING
8	F05-1701	LEAF SPRING	76	G75-5001	GEAR SHAFT
9	F61-3401	PLATE	77	G75-6001	RATCHET
10	G75-7002	SET PLATE	78	G87-8301	GEAR
11	G75-7702	MAGNET HOLDER	79	H76-5601	WASHER
12	351-0906	SCREW	80	G79-1302	DRIVE GEAR
13	G75-7801	RETAINER	81	G79-1402	WASHER
14	G75-7404	WASHER	82	F90-4903	WASHER
15	G75-7411	WASHER	83	H03-3001	WASHER
16	G18-5101	WASHER	84	B36-0306	WASHER
17	G51-1503	BALL BEARING	85	G01-1401	COLLAR
18	F03-2201	RING	86	G81-9801	ROLLER CLUTCH
19	320-8202	RETAINER	87	G75-6301	BALL BEARING
20	G15-0301	WASHER	88	B50-3201	WASHER
21	H02-9901	SPRING	89	F02-8201	CAP
22	H02-3102	INDUCT ROTOR	90	F03-2401	LEAF SPRING
23	G95-4701	BALANCER	91	150-8901	SPRING WASHER
24	F57-4303	WASHER	92	373-7810	WASHER
19-28	Z02-1098	SPOOL ASSEMBLY	93	G77-5113	STAR DRAG
26	H02-2901	PIN	94	H85-0402	COLLAR
27	G49-8604	BALL BEARING	95	H87-4601	HANDLE ASSY.
28	G71-7501	PIN	96	040-3217	PLATE
29	H87-1301	FRAME	97	G83-5502	SCREW
30	G75-4301	PLATE	98	G77-9101	SCREW
31	G75-4605	CLUTCH BAR	99	375-4104	WASHER
32	G75-4401	PLATE(L)	100	F62-5502	WASHER
33	320-5901	RETAINER	101	F77-0710	WASHER
34	F05-5501	WASHER			
35	B71-5601	BUSH			
36	F83-6502	LEVEL WIND GUARD			
37	G75-5704	LEVELWIND			
38	121-4212	LEVELWIND PIN			
39	G73-1300	WASHER			
40	F40-2801	NUT			
41	G46-6202	BALL BEARING			
42	G01-0701	COLLAR			
43	G85-0901	WORM SHAFT			
44	G35-8703	SCREW			
45	G75-6802	FRONT PLATE			
46	G43-1004	BALL BEARING			
47	G35-7101	CLUTCH CAM			
48	G75-4802	PLATE			
49	G75-5301	SPRING			
50	H14-7101	KICK LEVER			
51	G53-9401	WASHER			
52	320-5901	RETAINER			
53	G35-7901	CLUTCH PLATE			
54	G35-8001	SPRING			
55	H76-5501	PINION GEAR			
56	E21-9701	R/S PLATE			
57	G46-6202	BALL BEARING			
58	H87-1201	PLATE			
59	G26-2301	PLATE			
60	G04-0822	SCREW			
61	G04-0823	SCREW			
62	G04-0821	SCREW			
63	F26-2701	LEAF SPRING			
64	G01-5501	SHAFT			
65	B17-5401	WASHER			
66	B17-5503	WASHER			
67	G77-4711	CAST CONTROL CAP			
68					

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
69	320-5901	RETAINER	69	320-5901	RETAINER
70	G75-5203	WASHER	70	G75-5203	WASHER
71	G46-6202	BALL BEARING	71	G46-6202	BALL BEARING
72	H14-7201	PLATE	72	H14-7201	PLATE
73	E13-4503	SCREW	73	E13-4503	SCREW
74	G87-5801	SCREW	74	G87-5801	SCREW
75	H25-6701	SPRING	75	H25-6701	SPRING
76	G75-5001	GEAR SHAFT	76	G75-5001	GEAR SHAFT
77	G75-6001	RATCHET	77	G75-6001	RATCHET
78	G87-8301	GEAR	78	G87-8301	GEAR
79	H76-5601	WASHER	79	H76-5601	WASHER
80	G79-1302	DRIVE GEAR	80	G79-1302	DRIVE GEAR
81	G79-1402	WASHER	81	G79-1402	WASHER
82	F90-4903	WASHER	82	F90-4903	WASHER
83	H03-3001	WASHER	83	H03-3001	WASHER
84	B36-0306	WASHER	84	B36-0306	WASHER
85	G01-1401	COLLAR	85	G01-1401	COLLAR
86	G81-9801	ROLLER CLUTCH	86	G81-9801	ROLLER CLUTCH
87	G75-6301	BALL BEARING	87	G75-6301	BALL BEARING
88	B50-3201	WASHER	88	B50-3201	WASHER
89	F02-8201	CAP	89	F02-8201	CAP
90	F03-2401	LEAF SPRING	90	F03-2401	LEAF SPRING
91	150-8901	SPRING WASHER	91	150-8901	SPRING WASHER
92	373-7810	WASHER	92	373-7810	WASHER
93	G77-5113	STAR DRAG	93	G77-5113	STAR DRAG
94	H85-0402	COLLAR	94	H85-0402	COLLAR
95	H87-4601	HANDLE ASSY.	95	H87-4601	HANDLE ASSY.
96	040-3217	PLATE	96	040-3217	PLATE
97	G83-5502	SCREW	97	G83-5502	SCREW
98	G77-9101	SCREW	98	G77-9101	SCREW
99	375-4104	WASHER	99	375-4104	WASHER
100	F62-5502	WASHER	100	F62-5502	WASHER
101	F77-0710	WASHER	101	F77-0710	WASHER

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
19-28	Z02-1110	SPOOL ASSEMBLY	19-28	Z02-1110	SPOOL ASSEMBLY
31	G75-4606	CLUTCH BAR	31	G75-4606	CLUTCH BAR
37	G75-5703	LEVELWIND	37	G75-5703	LEVELWIND
54	G35-7901	CLUTCH PLATE	54	G35-7901	CLUTCH PLATE
56	H14-7401	PINION GEAR	56	H14-7401	PINION GEAR
59	H87-6001	R/S PLATE	59	H87-6001	R/S PLATE
80	H14-7301	DRIVE GEAR	80	H14-7301	DRIVE GEAR
97	G83-5502	PLATE	97	G83-5502	PLATE
98	G77-9101	SCREW	98	G77-9101	SCREW
99	375-4104	WASHER	99	375-4104	WASHER
100	F62-5502	WASHER	100	F62-5502	WASHER
101	F77-0710	WASHER	101	F77-0710	WASHER

Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
4	F77-0704	WASHER	4	F77-0704	WASHER
10	G75-7001	SET PLATE	10	G75-7001	SET PLATE
11	G75-7701	MAGNET HOLDER	11	G75-7701	MAGNET HOLDER
19-28	Z02-1103	SPOOL ASSEMBLY	19-28	Z02-1103	SPOOL ASSEMBLY
29	H88-3001	FRAME	29	H88-3001	FRAME
31	G75-4801	CLUTCH BAR	31	G75-4801	CLUTCH BAR
37	G75-5703	LEVELWIND	37	G75-5703	LEVELWIND
48	G75-4801	PLATE	48	G75-4801	PLATE
51	G75-4901	KICK LEVER	51	G75-4901	KICK LEVER
56	G89-7101	PINION GEAR	56	G89-7101	PINION GEAR
59	H87-5101	R/S PLATE	59	H87-5101	R/S PLATE
60	G26-2301	PLATE	60	G26-2301	PLATE
72	G75-5101	SPRING	72	G75-5101	SPRING
75	G75-5401	DRIVE GEAR	75	G75-5401	DRIVE GEAR
80	G75-6201	WASHER	80	G75-6201	WASHER
81	F79-6102	WASHER	81	F79-6102	WASHER
82	H03-2901	WASHER	82	H03-2901	WASHER