




18 TATULA 100HSL

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 TATULA 100HSL		1	6J716301	BRAKE DIAL SCREW
18 TATULA 100HSL		2	6E167101	BRAKE DIAL SPRING
18 TATULA 100HSL		3	6J694902	BRAKE DIAL
18 TATULA 100HSL		4	6B339801	BRAKE DIAL RETAINER(A)
18 TATULA 100HSL		5	6F637701	BRAKE DIAL COLLAR
18 TATULA 100HSL		6	6H663401	BRAKE DIAL LEAF SPRING
18 TATULA 100HSL		7	6J716101	RS PLATE
18 TATULA 100HSL		8	6H915501	BRAKE DIAL RETAINER(B)
18 TATULA 100HSL		9	6G939301	BRAKE DIAL RETAINER(B)SCREW
18 TATULA 100HSL		10	6J695001	MAGNET HOLDER
18 TATULA 100HSL		11	63757404	RS BEARING WASHER(A)(0.1MM)
18 TATULA 100HSL		12	63757411	RS BEARING WASHER(B)
18 TATULA 100HSL		13	6G185101	RS BEARING WASHER(C)
18 TATULA 100HSL		14	6G511503	RS BALL BEARING
18 TATULA 100HSL		15	6F032201	RS BEARING RETAINER
18 TATULA 100HSL		16-24	6Z024117	SPOOL UNIT (16- 24)
18 TATULA 100HSL		25	6J715301	FRAME
18 TATULA 100HSL		26	6J694601	FRONT COVER
18 TATULA 100HSL		27	6H531508	FRONT COVER SCREW
18 TATULA 100HSL		28	6J693301	CLUTCH LEVER
18 TATULA 100HSL		29	6J692801	CLUTCH LEVER PLATE (L)
18 TATULA 100HSL		30	6J692701	CLUTCH LEVER PLATE (R)
18 TATULA 100HSL		31	6J281902	OSCILLATING POST
18 TATULA 100HSL		32	6H704101	OSCILLATING POST RETAINER
18 TATULA 100HSL		33	6J693401	CLUTCH CAM PLATE PIN SPRING COLLAR
18 TATULA 100HSL		34	6H928801	CLUTCH CAM PLATE PIN SPRING
18 TATULA 100HSL		35	6J055201	CLUTCH CAM PLATE PIN
18 TATULA 100HSL		36	6B861704	CLUTCH CAM BALL BEARING
18 TATULA 100HSL		37	6J715701	KICK LEVER PLATE (A)
18 TATULA 100HSL		38	6H531508	KICK LEVER PLATE (A) SCREW
18 TATULA 100HSL		39	6J407801	KICK LEVER SPRING
18 TATULA 100HSL		40	6J638601	KICK LEVER
18 TATULA 100HSL		41	6J715401	CLUTCH CAM
18 TATULA 100HSL		42	6H159201	CLUTCH CAM SCREW WASHER
18 TATULA 100HSL		43	63522501	CLUTCH CAM SCREW
18 TATULA 100HSL		44	6H659101	KICK LEVER PLATE (B)
18 TATULA 100HSL		45	6B032904	KICK LEVER PLATE (B) SCREW
18 TATULA 100HSL		46	6H944401	CLUTCH PLATE
18 TATULA 100HSL		47	6J313901	CLUTCH SPRING
18 TATULA 100HSL		48	6J716402	PINION GEAR
18 TATULA 100HSL		49	6H180501	PINON RETAINER
18 TATULA 100HSL		50	6G431102	PINION BALL BEARING
18 TATULA 100HSL		51	6J715102	LS PLATE
18 TATULA 100HSL		52	6B055201	MECHANICAL BRAKE O-RING
18 TATULA 100HSL		53	6J213101	MECHANICAL BRAKE WASHER (A)
18 TATULA 100HSL		54	6B175503	MECHANICAL BRAKE WASHER (B)
18 TATULA 100HSL		55	6J692501	ZERO ADJUSTE KNOB(MCNICL.BR.KNOB)
18 TATULA 100HSL		56	6G040828	LS PLATE SCREW (A)
18 TATULA 100HSL		57	63205901	WORM SHAFT RETAINER
18 TATULA 100HSL		58	6B411702	WORM SHAFT WASHER(0.1MM)
18 TATULA 100HSL		59	6G720001	WORM SHAFT COLLAR
18 TATULA 100HSL		60	6J243303	LEVEL WIND
18 TATULA 100HSL		61	61214212	PAWL
18 TATULA 100HSL		62	63731300	PAWL WASHER(0.1MM)
18 TATULA 100HSL		63	6F402801	PAWL HOLDER NUT
18 TATULA 100HSL		64	6J715801	WORM SHIELD
18 TATULA 100HSL		65	6J243601	WORM SHAFT
18 TATULA 100HSL		66	6G720001	WORM SHAFT COLLAR
18 TATULA 100HSL		67	6J693901	WORM SHAFT GEAR
18 TATULA 100HSL		68	6B339801	WORM SHAFT GEAR RETAINER

[illegible]