




BAITCASTING REEL

TATULA CT 100HL/ 100HSL

Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	H93-0401	SET PLS CREW	58	320-5901	RET
2	E16-7101	SPRING	59	B41-1700	WASHER
3	H93-0234	BRAKE ADJ KNOB	60	G72-0001	WORM SHAFT BEARING
4	B33-9801	RET	61	J24-3303	T-LEVEL WIND
5	F63-7701	BRAKE DIAL WASHER	62	121-4212	LINE GUIDE PAWL
6	H66-3401	BRAKE CLICK SPRING	63	373-1300	WASHER
7	H94-4903	R/S PLT	64	F40-2801	PAWL CAP
8	H91-5501	BRAKE DIAL RET	65	J24-7601	LEVEL WIND GUARD
9	G93-9301	SCREW	66	J24-3601	WORM SHAFT
10	H93-0501	MAGNET HOLDER	67	G72-0001	WORM SHAFT SPACER
11	375-7400	SPACER (A)	68	H91-0501	WORM GEAR
12	375-7411	SPACER (B)	69	B33-9801	RET
13	G18-5101	SPACER ©	70	G09-9800	WASHER
14	G51-1503	BALL BEARING	71	320-8002	RET
15	F03-2201	BEARING RETAINER	72	B35-8607	BALL BEARING
16-24	Z02-2784	SPOOL ASSEMBLY	73	H92-8901	PLATE
25	J33-8001	FRAME	74	E13-4509	SCREW
26	J24-4002	FRONT PLT	75	H91-2701	DRIVE SHAFT GEAR
27	H84-2803	SCREW	76	H91-1602	DRIVE SHAFT
28	J33-5001	CLUTCH LEVER	77	H92-9401	A/R RATCHET
29	H91-5701	CLUTCH LEVER PLT	78	J08-5101	DIVE SHAFT WASHER
30	H91-5601	CLUTCH LEVER PLT	79	H94-4802	DRIVE GEAR
31	J24-4101	STABILIZER BAR	80	H45-2602	WASHER
32	H70-4101	RET	81	H91-3201	KEY WASHER
33	H91-0601	COLLAR	82	J37-7801	GEAR SHAFT COLLAR
34	H92-8801	SPRING	83	G81-9801	ROLLER CLUTCH
35	J05-5201	PIN	84	B86-1704	BALL BEARING
36	B86-1704	BALL BEARING	85	B55-3801	WASHER
37	J24-7401	PLATE (A)	86	F02-8203	CLICK LEAF SPRING HOLDER
38	H29-4101	SCREW	87	F03-2401	BRAKE CLICK SPRING
39	J24-7501	CLUTCH CAM SPRING	88	150-8901	SPRING WASHER
40	J22-1501	CLUTCH TRIP LEVER	89	H92-9501	WASHER
41	J24-7201	CLUTCH CAM	90	H91-2002	NUT
42	H15-9201	WASHER	91	J01-1901	SPRING C
43	352-2501	SCREW	92	H91-1901	STAR DRAG
44	H65-9101	CLUTCH CAM PLT	93	F57-6601	HANDLE COLLAR
45	B03-2904	SCREW	94	J14-2801	HANDLE ASSEMBLY
46	H94-4401	YOKE	95	G79-3302	HANDLE NUT
47	H58-2001	YOKE SPRING	96	H83-4512	HANDLE NUT PLT
48	H94-4701	PINION GEAR	97	353-8301	HANDLE NUT PLT SCREW
49	H18-0501	BEARING RETAINER			
50	G43-1102	BALL BEARING			
51	J21-4407	L/S PLT			
52	B05-5201	O-RING			
53	J21-3101	SPACER (F)			
54	B17-5503	CAP RUBBER WASHER			
55	J28-8202	CAST CONTROL CAP			
56	G04-0814	PLT SCREW			
57	G04-0801	PLT SCREW			

TATULA CT 100HSL SPECIAL PARTS		
Key No.	Part No.	Part Name
3	H93-0220	BRAKE ADJ KNOB
48	J00-4301	PINION GEAR
51	J21-4408	L/S PLT
79	J00-4102	DRIVE GEAR
96	H83-4504	HANDLE NUT PLT